

Interactive System Board Viewer

HP EliteOne 800 G4 AiO

Welcome to the interactive System Board for the
HP EliteOne 800 G4 AiO

Here's how to use it...

[Zoomable View](#) (Click the link to navigate to the viewer)

On the Zoomable View page, you will find the viewer's zoom navigation links above the viewer on the left-hand side. You can choose from four levels of magnification: 1x, 2x, 3x, and 4x.

1x: The default magnification is 1x and at this magnification you can view the location of a feature by selecting it from the numbered list on the left.

2x, 3x, 4x: When you choose a greater magnification level, you use the navigation arrows and numbered features list to focus on the feature that you wish to review.


That's it!

[Back to Welcome page](#)





1 X View

1 X 2 X 3 X 4 X




Back to Welcome page




1 X **2 X** 3 X 4 X

2 X View




1. Clear CMOS button
2. M.2 WLAN socket
3. Backlight converter
4. LVDS connector
5. Power button, Fingerprint reader, Touch controller combo connector
6. 2 DDR4 SODIMM sockets
7. M.2 SSD socket
8. System fan connector
9. USB 3.1 Gen 2 Type-C port
10. Media card reader
11. RTC battery socket
12. DisplayPort (upper)
13. HDMI port (lower)
14. 4 USB 3.1 Gen 2 ports
15. RJ-45 (Ethernet) port
16. Audio line-out
17. USB 3.1 Gen 2 charging port
18. USB 3.1 Gen 2 port
19. Speaker connector
20. Side audio connector
21. M.2 SSD socket
22. HDD SATA and power connector
23. ODD SATA and power connector
24. 12-pin power input
25. CPU
26. Password jumper
27. Webcam/Microphone connector
28. Hood sensor

[Back to Welcome page](#)




1 X **2 X** 3 X 4 X

2 X View




1. Clear CMOS button
2. M.2 WLAN socket
3. Backlight converter
4. LVDS connector
5. Power button, Fingerprint reader, Touch controller combo connector
6. 2 DDR4 SODIMM sockets
7. M.2 SSD socket
8. System fan connector
9. USB 3.1 Gen 2 Type-C port
10. Media card reader
11. RTC battery socket
12. DisplayPort (upper)
13. HDMI port (lower)
14. 4 USB 3.1 Gen 2 ports
15. RJ-45 (Ethernet) port
16. Audio line-out
17. USB 3.1 Gen 2 charging port
18. USB 3.1 Gen 2 port
19. Speaker connector
20. Side audio connector
21. M.2 SSD socket
22. HDD SATA and power connector
23. ODD SATA and power connector
24. 12-pin power input
25. CPU
26. Password jumper
27. Webcam/Microphone connector
28. Hood sensor

[Back to Welcome page](#)




1 X **2 X** 3 X 4 X

2 X View




1. Clear CMOS button
2. M.2 WLAN socket
3. Backlight converter
4. LVDS connector
5. Power button, Fingerprint reader, Touch controller combo connector
6. 2 DDR4 SODIMM sockets
7. M.2 SSD socket
8. System fan connector
9. USB 3.1 Gen 2 Type-C port
10. Media card reader
11. RTC battery socket
12. DisplayPort (upper)
13. HDMI port (lower)
14. 4 USB 3.1 Gen 2 ports
15. RJ-45 (Ethernet) port
16. Audio line-out
17. USB 3.1 Gen 2 charging port
18. USB 3.1 Gen 2 port
19. Speaker connector
20. Side audio connector
21. M.2 SSD socket
22. HDD SATA and power connector
23. ODD SATA and power connector
24. 12-pin power input
25. CPU
26. Password jumper
27. Webcam/Microphone connector
28. Hood sensor

[Back to Welcome page](#)




1 X **2 X** 3 X 4 X

2 X View




1. Clear CMOS button
2. M.2 WLAN socket
3. Backlight converter
4. LVDS connector
5. Power button, Fingerprint reader, Touch controller combo connector
6. 2 DDR4 SODIMM sockets
7. M.2 SSD socket
8. System fan connector
9. USB 3.1 Gen 2 Type-C port
10. Media card reader
11. RTC battery socket
12. DisplayPort (upper)
13. HDMI port (lower)
14. 4 USB 3.1 Gen 2 ports
15. RJ-45 (Ethernet) port
16. Audio line-out
17. USB 3.1 Gen 2 charging port
18. USB 3.1 Gen 2 port
19. Speaker connector
20. Side audio connector
21. M.2 SSD socket
22. HDD SATA and power connector
23. ODD SATA and power connector
24. 12-pin power input
25. CPU
26. Password jumper
27. Webcam/Microphone connector
28. Hood sensor

Back to Welcome page




1 X 2 X **3 X** 4 X

3 X View




1. Clear CMOS button
2. M.2 WLAN socket
3. Backlight converter
4. LVDS connector
5. Power button, Fingerprint reader, Touch controller combo connector
6. 2 DDR4 SODIMM sockets
7. M.2 SSD socket
8. System fan connector
9. USB 3.1 Gen 2 Type-C port
10. Media card reader
11. RTC battery socket
12. DisplayPort (upper)
13. HDMI port (lower)
14. 4 USB 3.1 Gen 2 ports
15. RJ-45 (Ethernet) port
16. Audio line-out
17. USB 3.1 Gen 2 charging port
18. USB 3.1 Gen 2 port
19. Speaker connector
20. Side audio connector
21. M.2 SSD socket
22. HDD SATA and power connector
23. ODD SATA and power connector
24. 12-pin power input
25. CPU
26. Password jumper
27. Webcam/Microphone connector
28. Hood sensor

[Back to Welcome page](#)




1 X 2 X **3 X** 4 X

3 X View




1. Clear CMOS button
2. M.2 WLAN socket
3. Backlight converter
4. LVDS connector
5. Power button, Fingerprint reader, Touch controller combo connector
6. 2 DDR4 SODIMM sockets
7. M.2 SSD socket
8. System fan connector
9. USB 3.1 Gen 2 Type-C port
10. Media card reader
11. RTC battery socket
12. DisplayPort (upper)
13. HDMI port (lower)
14. 4 USB 3.1 Gen 2 ports
15. RJ-45 (Ethernet) port
16. Audio line-out
17. USB 3.1 Gen 2 charging port
18. USB 3.1 Gen 2 port
19. Speaker connector
20. Side audio connector
21. M.2 SSD socket
22. HDD SATA and power connector
23. ODD SATA and power connector
24. 12-pin power input
25. CPU
26. Password jumper
27. Webcam/Microphone connector
28. Hood sensor

[Back to Welcome page](#)




1 X 2 X **3 X** 4 X

3 X View




1. Clear CMOS button
2. M.2 WLAN socket
3. Backlight converter
4. LVDS connector
5. Power button, Fingerprint reader, Touch controller combo connector
6. 2 DDR4 SODIMM sockets
7. M.2 SSD socket
8. System fan connector
9. USB 3.1 Gen 2 Type-C port
10. Media card reader
11. RTC battery socket
12. DisplayPort (upper)
13. HDMI port (lower)
14. 4 USB 3.1 Gen 2 ports
15. RJ-45 (Ethernet) port
16. Audio line-out
17. USB 3.1 Gen 2 charging port
18. USB 3.1 Gen 2 port
19. Speaker connector
20. Side audio connector
21. M.2 SSD socket
22. HDD SATA and power connector
23. ODD SATA and power connector
24. 12-pin power input
25. CPU
26. Password jumper
27. Webcam/Microphone connector
28. Hood sensor

Back to Welcome page




1 X 2 X **3 X** 4 X

3 X View




1. Clear CMOS button
2. M.2 WLAN socket
3. Backlight converter
4. LVDS connector
5. Power button, Fingerprint reader, Touch controller combo connector
6. 2 DDR4 SODIMM sockets
7. M.2 SSD socket
8. System fan connector
9. USB 3.1 Gen 2 Type-C port
10. Media card reader
11. RTC battery socket
12. DisplayPort (upper)
13. HDMI port (lower)
14. 4 USB 3.1 Gen 2 ports
15. RJ-45 (Ethernet) port
16. Audio line-out
17. USB 3.1 Gen 2 charging port
18. USB 3.1 Gen 2 port
19. Speaker connector
20. Side audio connector
21. M.2 SSD socket
22. HDD SATA and power connector
23. ODD SATA and power connector
24. 12-pin power input
- 25. CPU**
26. Password jumper
27. Webcam/Microphone connector
28. Hood sensor

Back to Welcome page




1 X 2 X 3 X **4 X**

4 X View




1. Clear CMOS button
2. M.2 WLAN socket
3. Backlight converter
4. LVDS connector
5. Power button, Fingerprint reader, Touch controller combo connector
6. 2 DDR4 SODIMM sockets
7. M.2 SSD socket
8. System fan connector
9. USB 3.1 Gen 2 Type-C port
10. Media card reader
11. RTC battery socket
12. DisplayPort (upper)
13. HDMI port (lower)
14. 4 USB 3.1 Gen 2 ports
15. RJ-45 (Ethernet) port
16. Audio line-out
17. USB 3.1 Gen 2 charging port
18. USB 3.1 Gen 2 port
19. Speaker connector
20. Side audio connector
21. M.2 SSD socket
22. HDD SATA and power connector
23. ODD SATA and power connector
24. 12-pin power input
25. CPU
26. Password jumper
27. Webcam/Microphone connector
28. Hood sensor

[Back to Welcome page](#)




1 X 2 X 3 X **4 X**

4 X View




1. Clear CMOS button
2. M.2 WLAN socket
3. Backlight converter
4. LVDS connector
5. Power button, Fingerprint reader, Touch controller combo connector
6. 2 DDR4 SODIMM sockets
7. M.2 SSD socket
8. System fan connector
9. USB 3.1 Gen 2 Type-C port
10. Media card reader
11. RTC battery socket
12. DisplayPort (upper)
13. HDMI port (lower)
14. 4 USB 3.1 Gen 2 ports
15. RJ-45 (Ethernet) port
16. Audio line-out
17. USB 3.1 Gen 2 charging port
18. USB 3.1 Gen 2 port
19. Speaker connector
20. Side audio connector
21. M.2 SSD socket
22. HDD SATA and power connector
23. ODD SATA and power connector
24. 12-pin power input
- 25. CPU**
26. Password jumper
27. Webcam/Microphone connector
28. Hood sensor

[Back to Welcome page](#)




1 X 2 X 3 X **4 X**

4 X View




1. Clear CMOS button
2. M.2 WLAN socket
3. Backlight converter
4. LVDS connector
5. Power button, Fingerprint reader, Touch controller combo connector
6. 2 DDR4 SODIMM sockets
7. M.2 SSD socket
8. System fan connector
9. USB 3.1 Gen 2 Type-C port
10. Media card reader
11. RTC battery socket
12. DisplayPort (upper)
13. HDMI port (lower)
14. 4 USB 3.1 Gen 2 ports
15. RJ-45 (Ethernet) port
16. Audio line-out
17. USB 3.1 Gen 2 charging port
18. USB 3.1 Gen 2 port
19. Speaker connector
20. Side audio connector
21. M.2 SSD socket
- 22. HDD SATA and power connector**
- 23. ODD SATA and power connector**
- 24. 12-pin power input**
25. CPU
26. Password jumper
27. Webcam/Microphone connector
28. Hood sensor

[Back to Welcome page](#)




1 X 2 X 3 X **4 X**

4 X View




1. Clear CMOS button
2. M.2 WLAN socket
3. Backlight converter
4. LVDS connector
5. Power button, Fingerprint reader, Touch controller combo connector
6. 2 DDR4 SODIMM sockets
7. M.2 SSD socket
8. System fan connector
9. USB 3.1 Gen 2 Type-C port
10. Media card reader
11. RTC battery socket
12. DisplayPort (upper)
13. HDMI port (lower)
14. 4 USB 3.1 Gen 2 ports
15. RJ-45 (Ethernet) port
16. Audio line-out
17. USB 3.1 Gen 2 charging port
18. USB 3.1 Gen 2 port
19. Speaker connector
20. Side audio connector
21. M.2 SSD socket
22. HDD SATA and power
23. ODD SATA and power connector
24. 12-pin power input connector
25. CPU
26. Password jumper
27. Webcam/Microphone connector
28. Hood sensor

[Back to Welcome page](#)




1 X 2 X 3 X **4 X**

4 X View




1. Clear CMOS button
2. M.2 WLAN socket
3. Backlight converter
4. LVDS connector
5. Power button, Fingerprint reader, Touch controller combo connector
6. 2 DDR4 SODIMM sockets
7. M.2 SSD socket
8. System fan connector
9. USB 3.1 Gen 2 Type-C port
10. Media card reader
11. RTC battery socket
12. DisplayPort (upper)
13. HDMI port (lower)
14. 4 USB 3.1 Gen 2 ports
15. RJ-45 (Ethernet) port
16. Audio line-out
17. USB 3.1 Gen 2 charging port
18. USB 3.1 Gen 2 port
19. Speaker connector
20. Side audio connector
21. M.2 SSD socket
22. HDD SATA and power connector
23. ODD SATA and power connector
24. 12-pin power input
25. CPU
26. Password jumper
27. Webcam/Microphone connector
28. Hood sensor

Back to Welcome page




1 X 2 X 3 X **4 X**

4 X View




1. Clear CMOS button
2. M.2 WLAN socket
3. Backlight converter
4. LVDS connector
5. Power button, Fingerprint reader, Touch controller combo connector
6. 2 DDR4 SODIMM sockets
7. M.2 SSD socket
8. System fan connector
9. USB 3.1 Gen 2 Type-C port
10. Media card reader
11. RTC battery socket
12. DisplayPort (upper)
13. HDMI port (lower)
14. 4 USB 3.1 Gen 2 ports
15. RJ-45 (Ethernet) port
16. Audio line-out
17. USB 3.1 Gen 2 charging port
18. USB 3.1 Gen 2 port
19. Speaker connector
20. Side audio connector
21. M.2 SSD socket
22. HDD SATA and power connector
23. ODD SATA and power connector
24. 12-pin power input
25. CPU
26. Password jumper
27. Webcam/Microphone connector
28. Hood sensor

[Back to Welcome page](#)



1 X 2 X 3 X **4 X**



4 X View




1. Clear CMOS button
2. M.2 WLAN socket
3. Backlight converter
4. LVDS connector
5. Power button, Fingerprint reader, Touch controller combo connector
6. 2 DDR4 SODIMM sockets
7. M.2 SSD socket
8. System fan connector
9. USB 3.1 Gen 2 Type-C port
10. Media card reader
11. RTC battery socket
12. DisplayPort (upper)
13. HDMI port (lower)
14. 4 USB 3.1 Gen 2 ports
15. RJ-45 (Ethernet) port
16. Audio line-out
17. USB 3.1 Gen 2 charging port
18. USB 3.1 Gen 2 port
19. Speaker connector
20. Side audio connector
21. M.2 SSD socket
22. HDD SATA and power connector
23. ODD SATA and power connector
24. 12-pin power input
25. CPU
26. Password jumper
27. Webcam/Microphone connector
28. Hood sensor

[Back to Welcome page](#)

4 X View




1 X 2 X 3 X **4 X**




1. Clear CMOS button
2. M.2 WLAN socket
3. Backlight converter
4. LVDS connector
5. Power button, Fingerprint reader, Touch controller combo connector
6. 2 DDR4 SODIMM sockets
7. M.2 SSD socket
8. System fan connector
9. USB 3.1 Gen 2 Type-C port
10. Media card reader
11. RTC battery socket
12. DisplayPort (upper)
13. HDMI port (lower)
14. 4 USB 3.1 Gen 2 ports
15. RJ-45 (Ethernet) port
16. Audio line-out
17. USB 3.1 Gen 2 charging port
18. USB 3.1 Gen 2 port
19. Speaker connector
20. Side audio connector
21. M.2 SSD socket
22. HDD SATA and power connector
23. ODD SATA and power connector
24. 12-pin power input
25. CPU
26. Password jumper
27. Webcam/Microphone connector
28. Hood sensor

[Back to Welcome page](#)



1X 2X 3X **4X**

4 X View



1. Clear CMOS button
2. M.2 WLAN socket
3. Backlight converter
4. LVDS connector
5. Power button, Fingerprint reader, Touch controller combo connector
6. 2 DDR4 SODIMM sockets
7. M.2 SSD socket
8. System fan connector
9. USB 3.1 Gen 2 Type-C port
10. Media card reader
11. RTC battery socket
12. DisplayPort (upper)
13. HDMI port (lower)
14. 4 USB 3.1 Gen 2 ports
15. RJ-45 (Ethernet) port
16. Audio line-out
17. USB 3.1 Gen 2 charging port
18. USB 3.1 Gen 2 port
19. Speaker connector
20. Side audio connector
21. M.2 SSD socket
22. HDD SATA and power connector
23. ODD SATA and power connector
24. 12-pin power input
25. CPU
26. Password jumper
27. Webcam/Microphone connector
28. Hood sensor