

# Interactive Part Locator

## HP ENVY Curved 34-b1xx All-in-One PC

Welcome to this interactive part locator

### **Here's how to use it...**

[External Views](#) (Click the link to navigate to the views)

On this page you will find large icons of each of the external views of this product. To view a specific view in greater detail, simply click that view.

[Parts List](#) (Click the link to navigate to the parts)

On this page, you will find a list of all of the replaceable parts for this product. To view a specific part and its location in the product, click the part name in the list.

**That's it! On every page there is a link that brings you back to either the External Views or the Parts List, enabling you to navigate to whatever view or part you wish to review.**

# External Views

[Back to Welcome page](#)



Front



Left



Right



Rear




Display



Top



Bottom




Internal

[Go to Parts List](#)

# Front View

[Back to External Views](#)



[Go to Parts List](#)

# Left View


[Back to External Views](#)



[Go to Parts List](#)

# Right View

[Back to External Views](#)



[Go to Parts List](#)

# Rear View

[Back to External Views](#)



[Go to Parts List](#)

# Display View


[Back to External Views](#)



[Go to Parts List](#)

# Top View

[Back to External Views](#)



Volume dial


Microphones

[Go to Parts List](#)



# Bottom View


[Back to External Views](#)



[Go to Parts List](#)

# Internal View

[Back to External Views](#)



[Go to Parts List](#)

## Rubber Inserts

- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU
- GPU
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board
- Speakers
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel



## Rubber Inserts



[Go to External Views](#)

Rubber Inserts

**Stand Bottom Cover**

System Memory

M.2 Solid State Drive

Wireless LAN Module

Hard Drive Assembly

Fan

Heat Sink

CPU

GPU

Wireless Charger Board

Speaker Mesh

Alexa LED Board

Speakers

Wireless Charger LED Board

Motherboard (top)

Motherboard (bottom)

Wireless Dongle

Volume Dial Board

Stand Hinge Brace

Stand Top Cover

Stand Arm Cover

Stand Arm

Display Assembly Rear Cover

Scalar Board Shield

Scalar Board

Wireless LAN Antennas

Webcam Assembly and Brackets

Webcam

Microphone Board

Display Assembly Hinge Bracket

Webcam Assembly Base Pan

Display Panel Chin Plate

Display Panel Cover

Display Panel

**Go to External Views**


## Stand Bottom Cover





- Rubber Inserts
- Stand Bottom Cover
- System Memory**
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU
- GPU
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board
- Speakers
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel

# System Memory



[Go to External Views](#)



- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive**
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU
- GPU
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board
- Speakers
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel

## M.2 Solid State Drive



[Go to External Views](#)



- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module**
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU
- GPU
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board
- Speakers
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel

# Wireless LAN Module




[Go to External Views](#)



- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly**
- Fan
- Heat Sink
- CPU
- GPU
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board
- Speakers
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel

# Hard Drive Assembly



[Go to External Views](#)




Rubber Inserts  
Stand Bottom Cover  
System Memory  
M.2 Solid State Drive  
Wireless LAN Module  
Hard Drive Assembly

**Fan**

Heat Sink  
CPU  
GPU  
Wireless Charger Board  
Speaker Mesh  
Alexa LED Board  
Speakers  
Wireless Charger LED Board  
Motherboard (top)  
Motherboard (bottom)  
Wireless Dongle  
Volume Dial Board  
Stand Hinge Brace  
Stand Top Cover  
Stand Arm Cover  
Stand Arm  
Display Assembly Rear Cover  
Scalar Board Shield  
Scalar Board  
Wireless LAN Antennas  
Webcam Assembly and Brackets  
Webcam  
Microphone Board  
Display Assembly Hinge Bracket  
Webcam Assembly Base Pan  
Display Panel Chin Plate  
Display Panel Cover  
Display Panel

# Fan



[Go to External Views](#)

- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink**
- CPU
- GPU
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board
- Speakers
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel

# Heat Sink



[Go to External Views](#)



- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU**
- GPU
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board
- Speakers
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel

## CPU




[Go to External Views](#)



- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU
- GPU**
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board
- Speakers
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel

## GPU





[Go to External Views](#)



# Wireless Charger Board

- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU
- GPU
- Wireless Charger Board**
- Speaker Mesh
- Alexa LED Board
- Speakers
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel



[Go to External Views](#)

- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU
- GPU
- Wireless Charger Board
- Speaker Mesh**
- Alexa LED Board
- Speakers
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel

# Speaker Mesh



[Go to External Views](#)



- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU
- GPU
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board**
- Speakers
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel


# Alexa LED Board



[Go to External Views](#)

# Speakers

- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU
- GPU
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board
- Speakers**
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel




[Go to External Views](#)



# Wireless Charger LED Board

- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU
- GPU
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board
- Speakers
- Wireless Charger LED Board**
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel




[Go to External Views](#)



- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU
- GPU
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board
- Speakers
- Wireless Charger LED Board
- Motherboard (top)**
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel

## Motherboard (top)




[Go to External Views](#)



- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU
- GPU
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board
- Speakers
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)**
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel

## Motherboard (bottom)



[Go to External Views](#)



# Wireless Dongle


- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU
- GPU
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board
- Speakers
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle**
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel



Go to External Views

- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU
- GPU
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board
- Speakers
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board**
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel

# Volume Dial Board




Go to External Views



# Stand Hinge Brace

- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU
- GPU
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board
- Speakers
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace**
- Stand Top Cover
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel



[Go to External Views](#)

# Stand Top Cover

- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU
- GPU
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board
- Speakers
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover**
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel



[Go to External Views](#)

# Stand Arm Cover

- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU
- GPU
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board
- Speakers
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover**
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel



[Go to External Views](#)



- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU
- GPU
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board
- Speakers
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover
- Stand Arm**
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel

# Stand Arm



[Go to External Views](#)

# Display Assembly Rear Cover

- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU
- GPU
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board
- Speakers
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover**
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel





[Go to External Views](#)



# Scalar Board Shield

- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU
- GPU
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board
- Speakers
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield**
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel




[Go to External Views](#)



# Scalar Board

- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU
- GPU
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board
- Speakers
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board**
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel




[Go to External Views](#)



# Wireless LAN Antennas


- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU
- GPU
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board
- Speakers
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas**
- Webcam Assembly and Brackets
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel



[Go to External Views](#)

# Webcam Assembly and Brackets

- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU
- GPU
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board
- Speakers
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets**
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel




[Go to External Views](#)



# Webcam


- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU
- GPU
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board
- Speakers
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam**
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel



[Go to External Views](#)

# Microphone Board

- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU
- GPU
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board
- Speakers
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam
- Microphone Board**
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel




[Go to External Views](#)



# Display Assembly Hinge Bracket

- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU
- GPU
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board
- Speakers
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket**
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel





[Go to External Views](#)



# Webcam Assembly Base Pan

- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU
- GPU
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board
- Speakers
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan**
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel




Go to External Views



# Display Panel Chin Plate


- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU
- GPU
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board
- Speakers
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate**
- Display Panel Cover
- Display Panel



[Go to External Views](#)

# Display Panel Cover

- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU
- GPU
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board
- Speakers
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover**
- Display Panel




[Go to External Views](#)



# Display Panel

- Rubber Inserts
- Stand Bottom Cover
- System Memory
- M.2 Solid State Drive
- Wireless LAN Module
- Hard Drive Assembly
- Fan
- Heat Sink
- CPU
- GPU
- Wireless Charger Board
- Speaker Mesh
- Alexa LED Board
- Speakers
- Wireless Charger LED Board
- Motherboard (top)
- Motherboard (bottom)
- Wireless Dongle
- Volume Dial Board
- Stand Hinge Brace
- Stand Top Cover
- Stand Arm Cover
- Stand Arm
- Display Assembly Rear Cover
- Scalar Board Shield
- Scalar Board
- Wireless LAN Antennas
- Webcam Assembly and Brackets
- Webcam
- Microphone Board
- Display Assembly Hinge Bracket
- Webcam Assembly Base Pan
- Display Panel Chin Plate
- Display Panel Cover
- Display Panel**



[Go to External Views](#)