

# Interactive Part Locator

## HP Pavilion 24-r0xx All-in-One Desktop PC

Welcome to the interactive part locator

### **Here's how to use it...**

[External Views](#) (Click the link to navigate to the views)

On this page you will find large icons of each of the external views of this product. To view a specific view in greater detail, simply click that view.

[Parts List](#) (Click the link to navigate to the parts)

On this page, you will find a list of all of the replaceable parts for this product. To view a specific part and its location in the product, click the part name in the list.

**That's it! On every page there is a link that brings you back to either the External Views or the Parts List, enabling you to navigate to whatever view or part you wish to review.**

# External Views

[Back to Welcome page](#)



Front



Left




Right



Rear



Display



Internal



Bottom

[Go to Parts List](#)

# Front View

[Back to External Views](#)



QHD Panel  
(touch or non-touch)

Speaker

Speaker

[Go to Parts List](#)

## Left View

[Back to External Views](#)



[Go to Parts List](#)

## Right View


[Back to External Views](#)



[Go to Parts List](#)

# Rear View

[Back to External Views](#)



Optical drive

USB 3.1 port charging

USB 2.0 ports

USB 3.1 port

System stand

Rear cover

Security lock slot

DC power input

HDMI in


Ethernet port

HDMI out

[Go to Parts List](#)

# Display View


[Back to External Views](#)



[Go to Parts List](#)

# Internal View

[Back to External Views](#)



[Go to Parts List](#)

# Bottom View

[Back to External Views](#)



[Go to Parts List](#)

## Stand

- Rear Cover
- Hard Drive
- Optical Drive
- Stand Hinge
- Motherboard EMI Shield
- System Memory
- RTC Battery
- Power Button Board
- HDMI Select Button Board
- Webcam/Microphone Assembly
- M.2 Solid State Drive
- M.2 Wireless LAN Card
- Wireless LAN Antennas
- Fan
- Heat Sink
- CPU
- Speakers
- Motherboard
- Middle Frame
- LCD Panel (non-touch)
- Touch Panel
- QHD Panel (touch or non-touch)



## Stand



[Go to External Views](#)

Stand

Rear Cover

Hard Drive

Optical Drive

Stand Hinge

Motherboard EMI Shield

System Memory

RTC Battery

Power Button Board

HDMI Select Button Board

Webcam/Microphone Assembly

M.2 Solid State Drive

M.2 Wireless LAN Card

Wireless LAN Antennas

Fan

Heat Sink

CPU

Speakers

Motherboard

Middle Frame


LCD Panel (non-touch)

Touch Panel

QHD Panel (touch or non-touch)

[Go to External Views](#)

## Rear Cover



# Hard Drive


- Stand
- Rear Cover
- Hard Drive**
- Optical Drive
- Stand Hinge
- Motherboard EMI Shield
- System Memory
- RTC Battery
- Power Button Board
- HDMI Select Button Board
- Webcam/Microphone Assembly
- M.2 Solid State Drive
- M.2 Wireless LAN Card
- Wireless LAN Antennas
- Fan
- Heat Sink
- CPU
- Speakers
- Motherboard
- Middle Frame
- LCD Panel (non-touch)
- Touch Panel
- QHD Panel (touch or non-touch)



[Go to External Views](#)

# Optical Drive


- Stand
- Rear Cover
- Hard Drive
- Optical Drive**
- Stand Hinge
- Motherboard EMI Shield
- System Memory
- RTC Battery
- Power Button Board
- HDMI Select Button Board
- Webcam/Microphone Assembly
- M.2 Solid State Drive
- M.2 Wireless LAN Card
- Wireless LAN Antennas
- Fan
- Heat Sink
- CPU
- Speakers
- Motherboard
- Middle Frame
- LCD Panel (non-touch)
- Touch Panel
- QHD Panel (touch or non-touch)



[Go to External Views](#)

# Stand Hinge


- Stand
- Rear Cover
- Hard Drive
- Optical Drive
- Stand Hinge**
- Motherboard EMI Shield
- System Memory
- RTC Battery
- Power Button Board
- HDMI Select Button Board
- Webcam/Microphone Assembly
- M.2 Solid State Drive
- M.2 Wireless LAN Card
- Wireless LAN Antennas
- Fan
- Heat Sink
- CPU
- Speakers
- Motherboard
- Middle Frame
- LCD Panel (non-touch)
- Touch Panel
- QHD Panel (touch or non-touch)



[Go to External Views](#)

# Motherboard EMI Shield

- Stand
- Rear Cover
- Hard Drive
- Optical Drive
- Stand Hinge
- Motherboard EMI Shield**
- System Memory
- RTC Battery
- Power Button Board
- HDMI Select Button Board
- Webcam/Microphone Assembly
- M.2 Solid State Drive
- M.2 Wireless LAN Card
- Wireless LAN Antennas
- Fan
- Heat Sink
- CPU
- Speakers
- Motherboard
- Middle Frame
- LCD Panel (non-touch)
- Touch Panel
- QHD Panel (touch or non-touch)



[Go to External Views](#)

# System Memory


- Stand
- Rear Cover
- Hard Drive
- Optical Drive
- Stand Hinge
- Motherboard EMI Shield
- System Memory**
- RTC Battery
- Power Button Board
- HDMI Select Button Board
- Webcam/Microphone Assembly
- M.2 Solid State Drive
- M.2 Wireless LAN Card
- Wireless LAN Antennas
- Fan
- Heat Sink
- CPU
- Speakers
- Motherboard
- Middle Frame
- LCD Panel (non-touch)
- Touch Panel
- QHD Panel (touch or non-touch)



[Go to External Views](#)

# RTC Battery


- Stand
- Rear Cover
- Hard Drive
- Optical Drive
- Stand Hinge
- Motherboard EMI Shield
- System Memory
- RTC Battery**
- Power Button Board
- HDMI Select Button Board
- Webcam/Microphone Assembly
- M.2 Solid State Drive
- M.2 Wireless LAN Card
- Wireless LAN Antennas
- Fan
- Heat Sink
- CPU
- Speakers
- Motherboard
- Middle Frame
- LCD Panel (non-touch)
- Touch Panel
- QHD Panel (touch or non-touch)



[Go to External Views](#)

# Power Button Board

- Stand
- Rear Cover
- Hard Drive
- Optical Drive
- Stand Hinge
- Motherboard EMI Shield
- System Memory
- RTC Battery
- Power Button Board**
- HDMI Select Button Board
- Webcam/Microphone Assembly
- M.2 Solid State Drive
- M.2 Wireless LAN Card
- Wireless LAN Antennas
- Fan
- Heat Sink
- CPU
- Speakers
- Motherboard
- Middle Frame
- LCD Panel (non-touch)
- Touch Panel
- QHD Panel (touch or non-touch)



[Go to External Views](#)

# HDMI Select Button Board


- Stand
- Rear Cover
- Hard Drive
- Optical Drive
- Stand Hinge
- Motherboard EMI Shield
- System Memory
- RTC Battery
- Power Button Board
- HDMI Select Button Board**
- Webcam/Microphone Assembly
- M.2 Solid State Drive
- M.2 Wireless LAN Card
- Wireless LAN Antennas
- Fan
- Heat Sink
- CPU
- Speakers
- Motherboard
- Middle Frame
- LCD Panel (non-touch)
- Touch Panel
- QHD Panel (touch or non-touch)



[Go to External Views](#)

# Webcam/Microphone Assembly


- Stand
- Rear Cover
- Hard Drive
- Optical Drive
- Stand Hinge
- Motherboard EMI Shield
- System Memory
- RTC Battery
- Power Button Board
- HDMI Select Button Board
- Webcam/Microphone Assembly**
- M.2 Solid State Drive
- M.2 Wireless LAN Card
- Wireless LAN Antennas
- Fan
- Heat Sink
- CPU
- Speakers
- Motherboard
- Middle Frame
- LCD Panel (non-touch)
- Touch Panel
- QHD Panel (touch or non-touch)



[Go to External Views](#)

# M.2 Solid State Drive


- Stand
- Rear Cover
- Hard Drive
- Optical Drive
- Stand Hinge
- Motherboard EMI Shield
- System Memory
- RTC Battery
- Power Button Board
- HDMI Select Button Board
- Webcam/Microphone Assembly
- M.2 Solid State Drive**
- M.2 Wireless LAN Card
- Wireless LAN Antennas
- Fan
- Heat Sink
- CPU
- Speakers
- Motherboard
- Middle Frame
- LCD Panel (non-touch)
- Touch Panel
- QHD Panel (touch or non-touch)



[Go to External Views](#)

# M.2 Wireless LAN Card


- Stand
- Rear Cover
- Hard Drive
- Optical Drive
- Stand Hinge
- Motherboard EMI Shield
- System Memory
- RTC Battery
- Power Button Board
- HDMI Select Button Board
- Webcam/Microphone Assembly
- M.2 Solid State Drive
- M.2 Wireless LAN Card**
- Wireless LAN Antennas
- Fan
- Heat Sink
- CPU
- Speakers
- Motherboard
- Middle Frame
- LCD Panel (non-touch)
- Touch Panel
- QHD Panel (touch or non-touch)



[Go to External Views](#)

# Wireless LAN Antennas



- Stand
- Rear Cover
- Hard Drive
- Optical Drive
- Stand Hinge
- Motherboard EMI Shield
- System Memory
- RTC Battery
- Power Button Board
- HDMI Select Button Board
- Webcam/Microphone Assembly
- M.2 Solid State Drive
- M.2 Wireless LAN Card
- Wireless LAN Antennas**
- Fan
- Heat Sink
- CPU
- Speakers
- Motherboard
- Middle Frame
- LCD Panel (non-touch)
- Touch Panel
- QHD Panel (touch or non-touch)



[Go to External Views](#)

# Fan



- Stand
- Rear Cover
- Hard Drive
- Optical Drive
- Stand Hinge
- Motherboard EMI Shield
- System Memory
- RTC Battery
- Power Button Board
- HDMI Select Button Board
- Webcam/Microphone Assembly
- M.2 Solid State Drive
- M.2 Wireless LAN Card
- Wireless LAN Antennas
- Fan**
- Heat Sink
- CPU
- Speakers
- Motherboard (top)
- Middle Frame
- LCD Panel (non-touch)
- Touch Panel
- QHD Panel (touch or non-touch)



[Go to External Views](#)

# Heat Sink

- Stand
- Rear Cover
- Hard Drive
- Optical Drive
- Stand Hinge
- Motherboard EMI Shield
- System Memory
- RTC Battery
- Power Button Board
- HDMI Select Button Board
- Webcam/Microphone Assembly
- M.2 Solid State Drive
- M.2 Wireless LAN Card
- Wireless LAN Antennas
- Fan
- Heat Sink**
- CPU
- Speakers
- Motherboard (top)
- Middle Frame
- LCD Panel (non-touch)
- Touch Panel
- QHD Panel (touch or non-touch)



[Go to External Views](#)

- Stand
- Rear Cover
- Hard Drive
- Optical Drive
- Stand Hinge
- Motherboard EMI Shield
- System Memory
- RTC Battery
- Power Button Board
- HDMI Select Button Board
- Webcam/Microphone Assembly
- M.2 Solid State Drive
- M.2 Wireless LAN Card
- Wireless LAN Antennas
- Fan
- Heat Sink
- CPU**
- Speakers
- Motherboard (top)
- Middle Frame
- LCD Panel (non-touch)
- Touch Panel
- QHD Panel (touch or non-touch)


## CPU



[Go to External Views](#)

# Speakers



- Stand
- Rear Cover
- Hard Drive
- Optical Drive
- Stand Hinge
- Motherboard EMI Shield
- System Memory
- RTC Battery
- Power Button Board
- HDMI Select Button Board
- Webcam/Microphone Assembly
- M.2 Solid State Drive
- M.2 Wireless LAN Card
- Wireless LAN Antennas
- Fan
- Heat Sink
- CPU
- Speakers**
- Motherboard
- Middle Frame
- LCD Panel (non-touch)
- Touch Panel
- QHD Panel (touch or non-touch)



[Go to External Views](#)

- Stand
- Rear Cover
- Hard Drive
- Optical Drive
- Stand Hinge
- Motherboard EMI Shield
- System Memory
- RTC Battery
- Power Button Board
- HDMI Select Button Board
- Webcam/Microphone Assembly
- M.2 Solid State Drive
- M.2 Wireless LAN Card
- Wireless LAN Antennas
- Fan
- Heat Sink
- CPU
- Speakers
- Motherboard**
- Middle Frame
- LCD Panel (non-touch)
- Touch Panel
- QHD Panel (touch or non-touch)


# Motherboard



[Go to External Views](#)

# Middle Frame

- Stand
- Rear Cover
- Hard Drive
- Optical Drive
- Stand Hinge
- Motherboard EMI Shield
- System Memory
- RTC Battery
- Power Button Board
- HDMI Select Button Board
- Webcam/Microphone Assembly
- M.2 Solid State Drive
- M.2 Wireless LAN Card
- Wireless LAN Antennas
- Fan
- Heat Sink
- CPU
- Speakers
- Motherboard
- Middle Frame**
- LCD Panel (non-touch)
- Touch Panel
- QHD Panel (touch or non-touch)



[Go to External Views](#)

## LCD Panel (non-touch)

- Stand
- Rear Cover
- Hard Drive
- Optical Drive
- Stand Hinge
- Motherboard EMI Shield
- System Memory
- RTC Battery
- Power Button Board
- HDMI Select Button Board
- Webcam/Microphone Assembly
- M.2 Solid State Drive
- M.2 Wireless LAN Card
- Wireless LAN Antennas
- Fan
- Heat Sink
- CPU
- Speakers
- Motherboard
- Middle Frame
- LCD Panel (non-touch)**
- Touch Panel
- QHD Panel (touch or non-touch)



[Go to External Views](#)

# Touch Panel

- Stand
- Rear Cover
- Hard Drive
- Optical Drive
- Stand Hinge
- Motherboard EMI Shield
- System Memory
- RTC Battery
- Power Button Board
- HDMI Select Button Board
- Webcam/Microphone Assembly
- M.2 Solid State Drive
- M.2 Wireless LAN Card
- Wireless LAN Antennas
- Fan
- Heat Sink
- CPU
- Speakers
- Motherboard
- Middle Frame
- LCD Panel (non-touch)
- Touch Panel**
- QHD Panel (touch or non-touch)



[Go to External Views](#)

# QHD Panel (touch or non-touch)

- Stand
- Rear Cover
- Hard Drive
- Optical Drive
- Stand Hinge
- Motherboard EMI Shield
- System Memory
- RTC Battery
- Power Button Board
- HDMI Select Button Board
- Webcam/Microphone Assembly
- M.2 Solid State Drive
- M.2 Wireless LAN Card
- Wireless LAN Antennas
- Fan
- Heat Sink
- CPU
- Speakers
- Motherboard
- Middle Frame
- LCD Panel (non-touch)
- Touch Panel
- QHD Panel (touch or non-touch)**



Go to External Views