#### Interactive Part Locator

### HP 20-c4XX All-in-One PC

### Welcome to the interactive part locator

#### Here's how to use it...

External Views (Click the link to navigate to the views)

On this page you will find large icons of each of the external views of this product. To view a specific view in greater detail, simply click that view.

Parts List (Click the link to navigate to the parts)

On this page, you will find a list of all of the replaceable parts for this product. To view a specific part and its location in the product, click the part name in the list.

That's it! On every page there is a link that brings you back to either the External Views or the Parts List, enabling you to navigate to whatever view or part you wish to review.

## **External Views**

### Back to Welcome page







Left



Right



Rear



Display



Internal

Go to Parts List

# **Front View**

Back to External Views



Go to Parts List


**Left View** 

**Back to External Views** 




# Right View

**Back to External Views** 




## **Rear View**




Go to Parts List

# **Display View**

#### **Back to External Views**



## **Internal View**



Go to Parts List

**Rear Cover** 

**Hard Drive** 

**Optical Drive** 

System Memory

Battery

Fan

**Heat Sink** 

CPU

Wireless LAN Board

Wireless LAN Antennas

Speakers

Card Reader/

**Power Button Board** 

Webcam/Microphone

Assembly

Motherboard (top)

Motherboard (bottom)

Stand Hinge

Motherboard EMI Shield

LCD Panel

Front Bezel

Panel Brackets

Go to External Views

## Stand



#### **Rear Cover**

**Hard Drive** 

**Optical Drive** 

System Memory

Battery

Fan

**Heat Sink** 

CPU

Wireless LAN Board

Wireless LAN Antennas

Speakers

Card Reader/

**Power Button Board** 

Webcam/Microphone

Assembly

Motherboard (top)

Motherboard (bottom)

Stand Hinge

Motherboard EMI Shield

LCD Panel

Front Bezel

Panel Brackets

Go to External Views

### **Rear Cover**





#### Stand Rear Cover

#### **Hard Drive**

Optical Drive System Memory Battery

Fan

**Heat Sink** 

CPU

Wireless LAN Board

Wireless LAN Antennas

Speakers

Card Reader/

Power Button Board

Webcam/Microphone

Assembly

Motherboard (top)

Motherboard (bottom)

**Stand Hinge** 

Motherboard EMI Shield


LCD Panel

Front Bezel

**Panel Brackets** 

Go to External Views

### **Hard Drive**



**Rear Cover** 

**Hard Drive** 

#### Optical Drive

System Memory

Battery

Fan

**Heat Sink** 

CPU

Wireless LAN Board

Wireless LAN Antennas

Speakers

Card Reader/

**Power Button Board** 

Webcam/Microphone

Assembly

Motherboard (top)

Motherboard (bottom)

Stand Hinge

Motherboard EMI Shield

LCD Panel

Front Bezel

Panel Brackets

Go to External Views

## **Optical Drive**



**Rear Cover** 

**Hard Drive** 

Optical Drive

#### System Memory

Battery

Fan

**Heat Sink** 

CPU

Wireless LAN Board

Wireless LAN Antennas

Speakers

Card Reader/

**Power Button Board** 

Webcam/Microphone

Assembly

Motherboard (top)

Motherboard (bottom)

Stand Hinge

Motherboard EMI Shield

LCD Panel

Front Bezel

**Panel Brackets** 

Go to External Views

## System Memory





Stand
Rear Cover
Hard Drive
Optical Drive
System Memory

#### Battery

Fan Heat Sink CPU

Wireless LAN Board Wireless LAN Antennas

Speakers
Card Reader/

Power Button Board

Webcam/Microphone

Assembly

Motherboard (top)

Motherboard (bottom)

Stand Hinge

Motherboard EMI Shield

LCD Panel

Front Bezel

**Panel Brackets** 

Go to External Views

## **Battery**





Stand
Rear Cover
Hard Drive
Optical Drive
System Memory

#### Fan

Battery


Heat Sink
CPU
Wireless LAN Board

Wireless LAN Antennas
Speakers
Card Reader/
Power Button Board
Webcam/Microphone
Assembly
Motherboard (top)
Motherboard (bottom)
Stand Hinge
Motherboard EMI Shield
LCD Panel

Front Bezel Panel Brackets

Go to External Views

## Fan





**Rear Cover** 

**Hard Drive** 

Optical Drive

System Memory

Battery

Fan

#### **Heat Sink**

CPU

Wireless LAN Board

Wireless LAN Antennas

Speakers

Card Reader/

**Power Button Board** 

Webcam/Microphone

Assembly

Motherboard (top)

Motherboard (bottom)

Stand Hinge

Motherboard EMI Shield


LCD Panel

Front Bezel

**Panel Brackets** 

Go to External Views

## **Heat Sink**





**Rear Cover** 

**Hard Drive** 

Optical Drive

System Memory

Battery

Fan

**Heat Sink** 

#### CPU

Wireless LAN Board Wireless LAN Antennas

Speakers

Card Reader/

Power Button Board Webcam/Microphone

Assembly

Motherboard (top)

Motherboard (bottom)

Stand Hinge

Motherboard EMI Shield

LCD Panel

Front Bezel

**Panel Brackets** 

Go to External Views

## CPU





## Wireless LAN Board

Stand
Rear Cover
Hard Drive
Optical Drive
System Memory
Battery
Fan
Heat Sink
CPU

#### Wireless LAN Board

Wireless LAN Antennas

Speakers

Card Reader/

Power Button Board Webcam/Microphone

Assembly

Motherboard (top)

Motherboard (bottom)

**Stand Hinge** 

Motherboard EMI Shield

LCD Panel

Front Bezel

**Panel Brackets** 





### Wireless LAN Antennas

Stand
Rear Cover
Hard Drive
Optical Drive
System Memory
Battery

Fan

Heat Sink

CPU

Wireless LAN Board

#### Wireless LAN Antennas

Speakers

Card Reader/

Power Button Board Webcam/Microphone

Assembly

Motherboard (top)

Motherboard (bottom)


Stand Hinge

Motherboard EMI Shield

LCD Panel

Front Bezel

**Panel Brackets** 



**Rear Cover** 

**Hard Drive** 

Optical Drive

System Memory

Battery

Fan

**Heat Sink** 

CPU

Wireless LAN Board

Wireless LAN Antennas

#### Speakers

Card Reader/

Power Button Board Webcam/Microphone

Assembly

Motherboard (top)

Motherboard (bottom)

**Stand Hinge** 

Motherboard EMI Shield


LCD Panel

Front Bezel

**Panel Brackets** 

Go to External Views

## **Speakers**



## Card Reader/ Power Button Board

Stand
Rear Cover
Hard Drive
Optical Drive
System Memory
Battery
Fan
Heat Sink
CPU

Wireless LAN Board Wireless LAN Antennas

Speakers

Card Reader/

**Power Button Board** 

Webcam/Microphone

Assembly

Motherboard (top)

Motherboard (bottom)


**Stand Hinge** 

Motherboard EMI Shield

LCD Panel

Front Bezel

**Panel Brackets** 



## Webcam/Microphone Assembly

Stand

**Rear Cover** 

**Hard Drive** 

Optical Drive

System Memory

Battery

Fan

**Heat Sink** 

CPU

Wireless LAN Board

Wireless LAN Antennas

Speakers

Card Reader/

**Power Button Board** 

Webcam/Microphone

Assembly

Motherboard (top)

Motherboard (bottom)

Stand Hinge

Motherboard EMI Shield

LCD Panel

Front Bezel

**Panel Brackets** 



**Rear Cover** 

**Hard Drive** 

Optical Drive

System Memory

Battery

Fan

**Heat Sink** 

CPU

Wireless LAN Board

Wireless LAN Antennas

Speakers

Card Reader/

**Power Button Board** 

Webcam/Microphone

Assembly

#### Motherboard (top)

Motherboard (bottom)

Stand Hinge

Motherboard EMI Shield


LCD Panel

Front Bezel

**Panel Brackets** 

Go to External Views

## Motherboard (top)





**Rear Cover** 

**Hard Drive** 

Optical Drive

System Memory

Battery

Fan

**Heat Sink** 

CPU

Wireless LAN Board

Wireless LAN Antennas

Speakers

Card Reader/

**Power Button Board** 

Webcam/Microphone

Assembly

Motherboard (top)

#### Motherboard (bottom)

Stand Hinge

Motherboard EMI Shield


LCD Panel

Front Bezel

**Panel Brackets** 

Go to External Views

## Motherboard (bottom)





**Rear Cover** 

**Hard Drive** 

Optical Drive

System Memory

Battery

Fan

**Heat Sink** 

CPU

Wireless LAN Board

Wireless LAN Antennas

Speakers

Card Reader/

Power Button Board

Webcam/Microphone

Assembly

Motherboard (top)

Motherboard (bottom)

#### Stand Hinge

Motherboard EMI Shield

LCD Panel

Front Bezel

**Panel Brackets** 

Go to External Views

## **Stand Hinge**





### Motherboard EMI Shield

Stand Rear Cover Hard Drive Optical Drive System Memory

Battery

Fan

**Heat Sink** 

CPU

Wireless LAN Board

Wireless LAN Antennas

Speakers

Card Reader/

Power Button Board Webcam/Microphone

Assembly

Motherboard (top)

Motherboard (bottom)

Stand Hinge


#### Motherboard EMI Shield

LCD Panel

Front Bezel

**Panel Brackets** 





## **LCD** Panel

Stand **Rear Cover Hard Drive Optical Drive** System Memory Battery

Fan

**Heat Sink** 

CPU

Wireless LAN Board

Wireless LAN Antennas

Speakers

Card Reader/

**Power Button Board** Webcam/Microphone

Assembly

Motherboard (top)

Motherboard (bottom)

**Stand Hinge** 

Motherboard EMI Shield

#### LCD Panel

Front Bezel

Panel Brackets



### Front Bezel

Stand
Rear Cover
Hard Drive
Optical Drive
System Memory
Battery

Fan

**Heat Sink** 

CPU

Wireless LAN Board Wireless LAN Antennas

Speakers

Card Reader/

Power Button Board Webcam/Microphone

Assembly

Motherboard (top)

Motherboard (bottom)

Stand Hinge

Motherboard EMI Shield

LCD Panel

#### **Front Bezel**

**Panel Brackets** 



**Rear Cover** 

**Hard Drive** 

Optical Drive

System Memory

Battery

Fan

**Heat Sink** 

CPU

Wireless LAN Board

Wireless LAN Antennas

Speakers

Card Reader/

**Power Button Board** 

Webcam/Microphone

Assembly

Motherboard (top)

Motherboard (bottom)

Stand Hinge

Motherboard EMI Shield

LCD Panel

Front Bezel

#### Panel Brackets

Go to External Views

### **Panel Brackets**

