Interactive BIOS simulator

HP Z1 Entry Tower Workstation

Welcome to the interactive BIOS simulator for the HP Z1 Entry Tower Workstation

Here's how to use it...

BIOS Utility Menus: (Click the link to navigate to the individual menus) On this page you will find thumbnail images of each of the product's BIOS utility menus. To view a specific menu in greater detail, simply click that thumbnail. Just as in the live BIOS, on each menu, you can select the tab of each of the other utility menus to navigate directly to that menu.

Menu options:


While the menu options cannot be toggled, many of them offer item specific information about that option. To view this information, use the cursor to rollover the option and the information will present in a pane on the right of the BIOS screen.

That's it!

On every page there is a link that brings you back to either this <u>Welcome</u> page or the <u>BIOS Utility Menus</u> page enabling you to navigate to whatever BIOS option you wish to review.

BIOS Utility Menus

Back to Welcome Page



UEFI Drivers

Main Menu

Back to BIOS Utility Menus

| Main | Cocurity | Advanced | |
|------|----------|----------|--------------|
| Main | Security | Advanced | UEFI Drivers |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

Back to Welcome Page

| hp |
|--------------------------|
| HP computer setup |
| Item Specific Help |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| Onur Links Evil |
| Save Help Exit |

Security Menu

Back to BIOS Utility Menus

Main Security Advanced UEFI Drivers

Administrator Tools

Security Configuration

TXT cannot be enabled unless VTx, VTd, and TPM are enabled first.

Utilities

Activation Status: Inactive Absolute [®] Persistance Module Permanent Disable: No

Back to Welcome Page



HP computer setup

| Item Specific Help | |
|--------------------|--|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| Savo | Help | Evit |
|------|------|------|
| Save | neip | LAIL |

Advanced Menu

Back to BIOS Utility Menus

| Main Security | Advanced | UEFI Drivers |
|---------------|----------|--------------|
|---------------|----------|--------------|

Remote HP PC Hardware Diagnostics

Back to Welcome Page



HP computer setup

| Item Specific Help | |
|--------------------|--|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

UEFI Drivers

Back to BIOS Utility Menus

Main | Security | Advanced | UEFI Drivers

This wil restart the system into the 3rd Party Option ROM Management application. You can get this application by pressing F3 during startup.

Back to Welcome Page



HP computer setup

| Item Specific Help | |
|--------------------|--|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| Caus | Help | Envit |
|------|------|-------|
| Save | | - X() |


System Information

Back to BIOS Utility Menus

| BASIC SYSTEM INFORMATION | | Item Specific Help |
|--|--|--------------------|
| Product Name Processor 1 Memory Size System BIOS SERVICE | HP Z1 Entry Tower Workstation Genuine Intel(R) CPU 0000 @ 2.90GHz 8192 MB Q01 Ver.00.18.00 12/06/2017 | |
| Born On Date Serial Number SKU Number Universally Unique Identifier (UUID) Asset Tracking Number | 12/21/2017 TBW2030063 2UZ41AV B1852B1B-9B18-3CFD-7F62-2704204ECF6B TBW2030063 | |
| Press Escape to Return | | |

System Diagnostics

Back to BIOS Utility Menus



Back to Welcome Page

Item Specific Help