

# Interactive Part Locator

## HP Chromebook 14 G6

Welcome to the interactive part locator for the  
HP Chromebook 14 G6

### **Here's how to use it...**

[External Views](#) (Click the link to navigate to the views)

On this page you will find large icons of each of the external views of this product. To view a specific view in greater detail, simply click that view.

[Parts List](#) (Click the link to navigate to the parts)

On this page, you will find a list of all of the replaceable parts for this product. To view a specific part and its location in the product, click the part name in the list.

**That's it! On every page there is a link that brings you back to either the External Views or the Parts List, enabling you to navigate to whatever view or part you wish to review.**

# External Views

Front

Left

Right

Rear


Internal

# Parts List


# Front View



# Left View




## Right View



## Rear View




# Internal View 1






# Internal View 2




# Top Cover




# Touchpad Board



# Speakers




# Battery







# USB/Power Button Board



# Motherboard





# Display Panel




# Sensor Board



# Webcam Board



# Display Panel Hinges



# Hinge Cap



# LCD Bracket



# Display Bezel

