

Interactive Part Locator

HP 22/24/27 All-in-One PC

Welcome to the interactive part locator for the
HP 22/24/27 All-in-One PC

Here's how to use it...

[External Views](#) (Click the link to navigate to the views)

On this page you will find large icons of each of the external views of this product. To view a specific view in greater detail, simply click that view.

[Parts List](#) (Click the link to navigate to the parts)

On this page, you will find a list of all of the replaceable parts for this product. To view a specific part and its location in the product, click the part name in the list.

That's it! On every page there is a link that brings you back to either the External Views or the Parts List, enabling you to navigate to whatever view or part you wish to review.

External Views

Front

Left

Right

Rear

Internal

Parts List

Front View




Left View




Right View




Rear View



Internal View 1



Internal View 2



Display Stand



Display Stand

Speaker Cover

Speaker Cover



LCD Panel

LCD Panel



System Memory Module(s)




M.2 Solid State Drive




CMOS Battery




Power Button/Card Reader Board



Wireless LAN Module




Speakers




Fan




Heatsink




GPU/Video Card



Optical Drive



Hard Disk Drive




Webcam Board



Wireless LAN Antennas



Motherboard



Hinge Assembly



Motherboard Shielding

