Interactive Part Locator

HP Chromebook x360 14c-ca0000 PC

Welcome to the interactive part locator for the HP Chromebook x360 14c-ca0000 PC

Here's how to use it...

External Views (Click the link to navigate to the views)

On this page you will find large icons of each of the external views of this product. To view a specific view in greater detail, simply click that view.


Parts List (Click the link to navigate to the parts)

On this page, you will find a list of all of the replaceable parts for this product. To view a specific part and its location in the product, click the part name in the list.

That's it! On every page there is a link that brings you back to either the External Views or the Parts List, enabling you to navigate to whatever view or part you wish to review.

External Views

Back to Welcome page




Go to Parts List

Front View

Back to External Views




Left View



Go to Parts List

Right View

Back to External Views



Go to Parts List


Rear View

Back to External Views




Display View


Back to External Views



Top View




Internal View



Go to Parts List

Bottom View



Go to Parts List

Battery
System Fan
Heat Sink

Touchpad Board

Fingerprint Reader

USB Board

System Board (top)

System Board (bottom)

Camera Privacy Switch

Speakers

Top Cover

Display Panel

Sensor Board


Display Panel Cable

Display Panel Hinges

Webcam

Wireless LAN Antennas

Base Enclosure





Battery

System Fan Heat Sink

Touchpad Board Fingerprint Reader

USB Board

System Board (top)

System Board (bottom)

Camera Privacy Switch

Speakers

Top Cover

Display Panel

Sensor Board


Display Panel Cable

Display Panel Hinges

Webcam

Wireless LAN Antennas

Battery



Battery

System Fan

Heat Sink

Touchpad Board

Fingerprint Reader

USB Board

System Board (top)

System Board (bottom)

Camera Privacy Switch

Speakers

Top Cover

Display Panel

Sensor Board


Display Panel Cable

Display Panel Hinges

Webcam

Wireless LAN Antennas

System Fan





Battery

System Fan

Heat Sink

Touchpad Board

Fingerprint Reader

USB Board

System Board (top)

System Board (bottom)

Camera Privacy Switch

Speakers

Top Cover

Display Panel

Sensor Board

Display Panel Cable

Display Panel Hinges

Webcam

Wireless LAN Antennas

Heat Sink





Touchpad Board

Base Enclosure

Battery System Fan

Heat Sink

Touchpad Board

Fingerprint Reader

USB Board

System Board (top)

System Board (bottom)

Camera Privacy Switch

Speakers

Top Cover

Display Panel

Sensor Board


Display Panel Cable

Display Panel Hinges

Webcam

Wireless LAN Antennas





Battery System Fan Heat Sink

Touchpad Board

Fingerprint Reader

USB Board

System Board (top)

System Board (bottom)

Camera Privacy Switch

Speakers

Top Cover

Display Panel

Sensor Board


Display Panel Cable


Display Panel Hinges

Webcam

Wireless LAN Antennas

Fingerprint Reader





USB Board

Base Enclosure

Battery System Fan Heat Sink

Touchpad Board

Fingerprint Reader

USB Board

System Board (top)
System Board (bottom)
Camera Privacy Switch

Speakers

Top Cover Display Panel


Sensor Board


Display Panel Cable

Display Panel Hinges

Webcam

Wireless LAN Antennas





Battery
System Fan
Heat Sink
Touchpad Board
Fingerprint Reader
USB Board

System Board (top)

System Board (bottom) Camera Privacy Switch Speakers

Top Cover Display Panel

Sensor Board

Display Panel Cable

Display Panel Hinges

Webcam

Wireless LAN Antennas

System Board (top)





Battery

System Fan

Heat Sink

Touchpad Board

Fingerprint Reader

USB Board

System Board (top)

System Board (bottom)

Camera Privacy Switch

Speakers
Top Cover

Display Panel

Sensor Board


Display Panel Cable

Display Panel Hinges

Webcam

Wireless LAN Antennas

System Board (bottom)





Camera Privacy Switch

Base Enclosure

Battery

System Fan

Heat Sink

Touchpad Board

Fingerprint Reader

USB Board

System Board (top)

System Board (bottom)

Camera Privacy Switch

Speakers

Top Cover

Display Panel


Sensor Board

Display Panel Cable

Display Panel Hinges

Webcam

Wireless LAN Antennas



Battery

System Fan

Heat Sink

Touchpad Board

Fingerprint Reader

USB Board

System Board (top)

System Board (bottom)

Camera Privacy Switch

Speakers

Top Cover Display Panel

Sensor Board

ochool board


Display Panel Cable


Display Panel Hinges

Webcam

Wireless LAN Antennas

Speakers





Battery

System Fan

Heat Sink

Touchpad Board

Fingerprint Reader

USB Board

System Board (top)

System Board (bottom)

Camera Privacy Switch

Speakers

Top Cover

Display Panel

Sensor Board

Display Panel Cable

Display Panel Hinges

Webcam

Wireless LAN Antennas

Top Cover



Battery

System Fan

Heat Sink

Touchpad Board

Fingerprint Reader

USB Board

System Board (top)

System Board (bottom)

Camera Privacy Switch

Speakers

Top Cover

Display Panel

Sensor Board

Display Panel Cable

Display Panel Hinges

Webcam

Wireless LAN Antennas

Display Panel



Battery

System Fan

Heat Sink

Touchpad Board

Fingerprint Reader

USB Board

System Board (top)

System Board (bottom)

Camera Privacy Switch

Speakers

Top Cover

Display Panel

Sensor Board

Display Panel Cable

Display Panel Hinges

Webcam

Wireless LAN Antennas

Sensor Board



Battery

System Fan

Heat Sink

Touchpad Board

Fingerprint Reader

USB Board

System Board (top)

System Board (bottom)

Camera Privacy Switch

Speakers

Top Cover

Display Panel

Sensor Board


Display Panel Cable

Display Panel Hinges

Webcam

Wireless LAN Antennas

Display Panel Cable



Display Panel Hinges

Base Enclosure

Battery

System Fan

Heat Sink

Touchpad Board

Fingerprint Reader

USB Board

System Board (top)

System Board (bottom)

Camera Privacy Switch

Speakers

Top Cover

Display Panel


Sensor Board

Display Panel Cable

Display Panel Hinges

Webcam

Wireless LAN Antennas



Battery

System Fan

Heat Sink

Touchpad Board

Fingerprint Reader

USB Board

System Board (top)

System Board (bottom)

Camera Privacy Switch

Speakers

Top Cover

Display Panel

Sensor Board

Display Panel Cable

Display Panel Hinges

Webcam

Wireless LAN Antennas

Webcam



Battery

System Fan

Heat Sink

Touchpad Board

Fingerprint Reader

USB Board

System Board (top)

System Board (bottom)

Camera Privacy Switch

Speakers

Top Cover

Display Panel

Sensor Board

Display Panel Cable

Display Panel Hinges

Webcam

Wireless LAN Antennas

Wireless LAN Antennas

