


# Interactive LED Diagnostic

## HP EliteBook 840 G7 Notebook PC

Welcome to the interactive LED diagnostic viewer for the  
HP EliteBook 840 G7 Notebook PC

### **Here's how to use it...**

[LED Diagnostic](#) (Click the link to navigate this platform's LED diagnostic states)

On this page you will find an image viewer with a menu of this product's external views. To identify the location of the LEDs for each view, simply click that view. To learn more about the diagnostic behavior of each LED, hover over the information icon (  ) above the LED and review the information that presents in the right-hand pane.

**That's it! On every page there is a link that brings you back to the Welcome page.**


# Top View

Top View

Right Edge

Display View

Hover your mouse over the information icons to learn more about the item.



[Back to Welcome page](#)

# Right Edge

Top View

Right Edge

Display View

Hover your mouse over the information icons to learn more about the item.



[Back to Welcome page](#)

# Display View

Top View

Right Edge

Display View

Hover your mouse over the information icons to learn more about the item.



[Back to Welcome page](#)