Interactive Part Locator

HP EliteBook x360 1030 G7 Notebook PC

Welcome to the interactive part locator for the HP EliteBook x360 1030 G7 Notebook PC

Here's how to use it...

External Views (Click the link to navigate to the views)

On this page you will find large icons of each of the external views of this product. To view a specific view in greater detail, simply click that view.


Parts List (Click the link to navigate to the parts)

On this page, you will find a list of all of the replaceable parts for this product. To view a specific part and its location in the product, click the part name in the list.

That's it! On every page there is a link that brings you back to either the External Views or the Parts List, enabling you to navigate to whatever view or part you wish to review.

External Views

Back to Welcome page




Front View


Back to External Views




Left View



Right View



Display View




Rear View




Top View



Internal View



Bottom View



Base Enclosure

Base Enclosure

Battery

M.2 Solid State Drive

Thermal Module

Wireless WAN Module

USB Board

Right Speaker

Left Speaker

Wireless WAN antenna

Touchpad


NFC Module

Display Panel Assembly

System Board (top)

System Board (bottom)

Thermal Sensor Board



Battery

Base Enclosure

Battery

M.2 Solid State Drive

Thermal Module

Wireless WAN Module

USB Board

Right Speaker

Left Speaker

Wireless WAN antenna

Touchpad

NFC Module

Display Panel Assembly

System Board (top)

System Board (bottom)

Thermal Sensor Board





M.2 Solid State Drive

Base Enclosure

Battery

M.2 Solid State Drive

Thermal Module

Wireless WAN Module

USB Board

Right Speaker

Left Speaker

Wireless WAN antenna

Touchpad

NFC Module

Display Panel Assembly

System Board (top)

System Board (bottom)

Thermal Sensor Board





Thermal Module

Base Enclosure

Battery

M.2 Solid State Drive

Thermal Module

Wireless WAN Module

USB Board

Right Speaker

Left Speaker

Wireless WAN antenna

Touchpad

NFC Module

Display Panel Assembly

System Board (top)

System Board (bottom)

Thermal Sensor Board





Wireless WAN Module

Base Enclosure

Battery

M.2 Solid State Drive

Thermal Module

Wireless WAN Module

USB Board

Right Speaker

Left Speaker

Wireless WAN antenna

Touchpad

NFC Module

Display Panel Assembly

System Board (top)

System Board (bottom)

Thermal Sensor Board





USB Board

Base Enclosure

Battery

M.2 Solid State Drive

Thermal Module

Wireless WAN Module

USB Board

Right Speaker

Left Speaker

Wireless WAN antenna

Touchpad


NFC Module

Display Panel Assembly

System Board (top)

System Board (bottom)

Thermal Sensor Board





Right Speaker

Base Enclosure

Battery

M.2 Solid State Drive

Thermal Module

Wireless WAN Module

USB Board

Right Speaker

Left Speaker

Wireless WAN antenna

Touchpad

NFC Module


Display Panel Assembly

System Board (top)

System Board (bottom)

Thermal Sensor Board





Left Speaker

Base Enclosure

Battery

M.2 Solid State Drive

Thermal Module

Wireless WAN Module

USB Board

Right Speaker

Left Speaker

Wireless WAN antenna

Touchpad


NFC Module


Display Panel Assembly

System Board (top)

System Board (bottom)

Thermal Sensor Board





Wireless WAN antenna

Base Enclosure

Battery

M.2 Solid State Drive

Thermal Module

Wireless WAN Module

USB Board

Right Speaker

Left Speaker

Wireless WAN antenna

Touchpad

NFC Module


Display Panel Assembly

System Board (top)

System Board (bottom)

Thermal Sensor Board





Touchpad

Base Enclosure

Battery

M.2 Solid State Drive

Thermal Module

Wireless WAN Module

USB Board

Right Speaker

Left Speaker

Wireless WAN antenna

Touchpad


NFC Module


Display Panel Assembly

System Board (top)

System Board (bottom)

Thermal Sensor Board





NFC Module

Base Enclosure

Battery

M.2 Solid State Drive

Thermal Module

Wireless WAN Module

USB Board

Right Speaker

Left Speaker

Wireless WAN antenna

Touchpad


NFC Module


Display Panel Assembly

System Board (top)

System Board (bottom)

Thermal Sensor Board





Display Panel Assembly

Base Enclosure

Battery

M.2 Solid State Drive

Thermal Module

Wireless WAN Module

USB Board

Right Speaker

Left Speaker

Wireless WAN antenna

Touchpad


NFC Module

Display Panel Assembly

System Board (top)

System Board (bottom)

Thermal Sensor Board



System Board (top)

Base Enclosure

Battery

M.2 Solid State Drive

Thermal Module

Wireless WAN Module

USB Board

Right Speaker

Left Speaker

Wireless WAN antenna

Touchpad

NFC Module


Display Panel Assembly

System Board (top)

System Board (bottom)

Thermal Sensor Board

Top Cover with Keyboard





Go to External Views

System Board (bottom)

Base Enclosure

Battery

M.2 Solid State Drive

Thermal Module

Wireless WAN Module

USB Board

Right Speaker

Left Speaker

Wireless WAN antenna

Touchpad


NFC Module

Display Panel Assembly

System Board (top)

System Board (bottom)

Thermal Sensor Board





Thermal Sensor Board

Base Enclosure

Battery

M.2 Solid State Drive

Thermal Module

Wireless WAN Module

USB Board

Right Speaker

Left Speaker

Wireless WAN antenna

Touchpad


NFC Module

Display Panel Assembly

System Board (top)

System Board (bottom)

Thermal Sensor Board



Top Cover with Keyboard

Base Enclosure

Battery

M.2 Solid State Drive

Thermal Module

Wireless WAN Module

USB Board

Right Speaker

Left Speaker

Wireless WAN antenna

Touchpad

NFC Module

Display Panel Assembly

System Board (top)

System Board (bottom)

Thermal Sensor Board

