

Interactive Part Locator

HP Z2 Mini G5 Workstation

Welcome to the interactive part locator for the
HP Z2 Mini G5 Workstation

Here's how to use it...

[External Views](#) (Click the link to navigate to the views)

On this page you will find large icons of each of the external views of this product. To view a specific view in greater detail, simply click that view.

[Parts List](#) (Click the link to navigate to the parts)

On this page, you will find a list of all of the replaceable parts for this product. To view a specific part and its location in the product, click the part name in the list.

That's it! On every page there is a link that brings you back to either the External Views or the Parts List, enabling you to navigate to whatever view or part you wish to review.

External Views

Front

Left

Right

Rear

Internal


Parts List

Front View



Power Button


Left View




Right View




Rear View



Internal View 1




Internal View 2



Top Cover

Top Cover



Bottom Cover



Bottom Cover

Primary Memory Module




Primary Memory Module




Storage Drive Assembly




CPU Fan




GPU Fan




GPU Heat Sink




CPU Heat Sink




Upper Option Board




M.2 Solid State Drive Assembly




Hood Sensor




Wireless LAN Antennas



Thermal Sensor



System Speaker




MXM Graphics Card




Power Button and HDD Activity LED



Secondary Memory Module



Lower Option Board



CPU



Motherboard

