

# Interactive Part Locator

## HP Chromebook x360 14a-ca0000 Convertible PC

Welcome to the interactive part locator for the  
HP Chromebook x360 14a-ca0000 Convertible PC

### Here's how to use it...

[External Views](#) (Click the link to navigate to the views)

On this page you will find large icons of each of the external views of this product. To view a specific view in greater detail, simply click that view.

[Parts List](#) (Click the link to navigate to the parts)

On this page, you will find a list of all of the replaceable parts for this product. To view a specific part and its location in the product, click the part name in the list.

**That's it! On every page there is a link that brings you back to either the External Views or the Parts List, enabling you to navigate to whatever view or part you wish to review.**

# External Views

[Back to Welcome page](#)



Front



Back



Left



Right



Top



Bottom




Internal

[Go to Parts List](#)

# Front View

[Back to External Views](#)

Microphone



Webcam

Microphone

Webcam LED

[Go to Parts List](#)

# Back View

[Back to External Views](#)




Hinges

[Go to Parts List](#)

# Left View


[Back to External Views](#)



[Go to Parts List](#)

# Right View

[Back to External Views](#)



USB-C 3.2 Gen  
1 charging port

Charging LED

USB-A 3.2 Gen  
1 port

Volume control  
button

[Go to Parts List](#)

# Top View

[Back to External Views](#)



[Go to Parts List](#)

# Bottom View

[Back to External Views](#)

Rubber feet



Hinges

Service tag

Screw covers

[Go to Parts List](#)




# Internal View

[Back to External Views](#)

Wireless LAN Module

USB Board

Speakers



System board

Battery

[Go to Parts List](#)

# Base Enclosure

## Base Enclosure

- Battery
- Wireless LAN Module
- USB Board
- Speakers
- Touchpad
- Top Cover with Keyboard/Dis-
- Thermal Pad
- Display Panel Assembly
- Top Cover with Keyboard
- Display Bezel
- Display Panel
- Hinges
- Hinge Caps
- Sensor Board
- Webcam
- Display Panel Cable
- Webcam Cable
- Wireless Antennas



[Go to External Views](#)

# Battery

Base Enclosure

**Battery**

Wireless LAN Module

USB Board

Speakers

Touchpad

Top Cover with Keyboard/Dis-

Thermal Pad

Display Panel Assembly

Top Cover with Keyboard

Display Bezel

Display Panel

Hinges

Hinge Caps

Sensor Board

Webcam

Display Panel Cable

Webcam Cable

Wireless Antennas



Go to External Views

# Wireless LAN Module


- Base Enclosure
- Battery
- Wireless LAN Module**
- USB Board
- Speakers
- Touchpad
- Top Cover with Keyboard/Dis-
- Thermal Pad
- Display Panel Assembly
- Top Cover with Keyboard
- Display Bezel
- Display Panel
- Hinges
- Hinge Caps
- Sensor Board
- Webcam
- Display Panel Cable
- Webcam Cable
- Wireless Antennas



[Go to External Views](#)

# USB Board

- Base Enclosure
- Battery
- Wireless LAN Module
- USB Board**
- Speakers
- Touchpad
- Top Cover with Keyboard/Dis-  
Thermal Pad
- Display Panel Assembly
- Top Cover with Keyboard
- Display Bezel
- Display Panel
- Hinges
- Hinge Caps
- Sensor Board
- Webcam
- Display Panel Cable
- Webcam Cable
- Wireless Antennas



[Go to External Views](#)

# Speakers

Base Enclosure

Battery

Wireless LAN Module

USB Board

**Speakers**

Touchpad

Top Cover with Keyboard/Dis-

Thermal Pad

Display Panel Assembly

Top Cover with Keyboard

Display Bezel

Display Panel

Hinges

Hinge Caps


Sensor Board

Webcam

Display Panel Cable

Webcam Cable

Wireless Antennas



[Go to External Views](#)

# Touchpad

Base Enclosure

Battery

Wireless LAN Module

USB Board

Speakers

**Touchpad**

Top Cover with Keyboard/Dis-

Thermal Pad

Display Panel Assembly

Top Cover with Keyboard

Display Bezel

Display Panel

Hinges

Hinge Caps



Sensor Board

Webcam

Display Panel Cable

Webcam Cable

Wireless Antennas



[Go to External Views](#)

# Top Cover with Keyboard/

Base Enclosure

Battery

Wireless LAN Module

USB Board

Speakers

Touchpad

**Top Cover with Keyboard/Dis-**

Thermal Pad

Display Panel Assembly

Top Cover with Keyboard

Display Bezel

Display Panel

Hinges

Hinge Caps

Sensor Board

Webcam

Display Panel Cable

Webcam Cable

Wireless Antennas




Go to External Views



- Base Enclosure
- Battery
- Wireless LAN Module
- USB Board
- Speakers
- Touchpad
- Top Cover with Keyboard/Dis-
- Thermal Pad**
- Display Panel Assembly
- Top Cover with Keyboard
- Display Bezel
- Display Panel
- Hinges
- Hinge Caps
- Sensor Board
- Webcam
- Display Panel Cable
- Webcam Cable
- Wireless Antennas

## Thermal Pad



[Go to External Views](#)

# Display Panel Assembly

- Base Enclosure
- Battery
- Wireless LAN Module
- USB Board
- Speakers
- Touchpad
- Top Cover with Keyboard/Dis-
- Thermal Pad
- Display Panel Assembly**
- Top Cover with Keyboard
- Display Bezel
- Display Panel
- Hinges
- Hinge Caps
- Sensor Board
- Webcam
- Display Panel Cable
- Webcam Cable
- Wireless Antennas



[Go to External Views](#)

# Top Cover with Keyboard


- Base Enclosure
- Battery
- Wireless LAN Module
- USB Board
- Speakers
- Touchpad
- Top Cover with Keyboard/Dis-
- Thermal Pad
- Display Panel Assembly
- Top Cover with Keyboard**
- Display Bezel
- Display Panel
- Hinges
- Hinge Caps
- Sensor Board
- Webcam
- Display Panel Cable
- Webcam Cable
- Wireless Antennas



[Go to External Views](#)

- Base Enclosure
- Battery
- Wireless LAN Module
- USB Board
- Speakers
- Touchpad
- Top Cover with Keyboard/Dis-
- Thermal Pad
- Display Panel Assembly
- Top Cover with Keyboard
- Display Bezel**
- Display Panel
- Hinges
- Hinge Caps
- Sensor Board
- Webcam
- Display Panel Cable
- Webcam Cable
- Wireless Antennas


## Display Bezel



[Go to External Views](#)

# Display Panel


- Base Enclosure
- Battery
- Wireless LAN Module
- USB Board
- Speakers
- Touchpad
- Top Cover with Keyboard/Dis-
- Thermal Pad
- Display Panel Assembly
- Top Cover with Keyboard
- Display Bezel
- Display Panel**
- Hinges
- Hinge Caps
- Sensor Board
- Webcam
- Display Panel Cable
- Webcam Cable
- Wireless Antennas



[Go to External Views](#)

# Hinges


- Base Enclosure
- Battery
- Wireless LAN Module
- USB Board
- Speakers
- Touchpad
- Top Cover with Keyboard/Dis-
- Thermal Pad
- Display Panel Assembly
- Top Cover with Keyboard
- Display Bezel
- Display Panel
- Hinges**
- Hinge Caps
- Sensor Board
- Webcam
- Display Panel Cable
- Webcam Cable
- Wireless Antennas



[Go to External Views](#)

# Hinge Caps



- Base Enclosure
- Battery
- Wireless LAN Module
- USB Board
- Speakers
- Touchpad
- Top Cover with Keyboard/Dis-
- Thermal Pad
- Display Panel Assembly
- Top Cover with Keyboard
- Display Bezel
- Display Panel
- Hinges
- Hinge Caps**
- Sensor Board
- Webcam
- Display Panel Cable
- Webcam Cable
- Wireless Antennas



[Go to External Views](#)

- Base Enclosure
- Battery
- Wireless LAN Module
- USB Board
- Speakers
- Touchpad
- Top Cover with Keyboard/Dis-
- Thermal Pad
- Display Panel Assembly
- Top Cover with Keyboard
- Display Bezel
- Display Panel
- Hinges
- Hinge Caps
- Sensor Board**
- Webcam
- Display Panel Cable
- Webcam Cable
- Wireless Antennas

## Sensor Board



[Go to External Views](#)



# Webcam

- Base Enclosure
- Battery
- Wireless LAN Module
- USB Board
- Speakers
- Touchpad
- Top Cover with Keyboard/Dis-
- Thermal Pad
- Display Panel Assembly
- Top Cover with Keyboard
- Display Bezel
- Display Panel
- Hinges
- Hinge Caps
- Sensor Board
- Webcam**
- Display Panel Cable
- Webcam Cable
- Wireless Antennas



[Go to External Views](#)

# Display Panel Cable

- Base Enclosure
- Battery
- Wireless LAN Module
- USB Board
- Speakers
- Touchpad
- Top Cover with Keyboard/Dis-
- Thermal Pad
- Display Panel Assembly
- Top Cover with Keyboard
- Display Bezel
- Display Panel
- Hinges
- Hinge Caps
- Sensor Board
- Webcam
- Display Panel Cable**
- Webcam Cable
- Wireless Antennas



[Go to External Views](#)

# Webcam Cable


- Base Enclosure
- Battery
- Wireless LAN Module
- USB Board
- Speakers
- Touchpad
- Top Cover with Keyboard/Dis-
- Thermal Pad
- Display Panel Assembly
- Top Cover with Keyboard
- Display Bezel
- Display Panel
- Hinges
- Hinge Caps
- Sensor Board
- Webcam
- Display Panel Cable
- Webcam Cable**
- Wireless Antennas



[Go to External Views](#)

# Wireless Antennas

- Base Enclosure
- Battery
- Wireless LAN Module
- USB Board
- Speakers
- Touchpad
- Top Cover with Keyboard/Dis-
- Thermal Pad
- Display Panel Assembly
- Top Cover with Keyboard
- Display Bezel
- Display Panel
- Hinges
- Hinge Caps
- Sensor Board
- Webcam
- Display Panel Cable
- Webcam Cable
- Wireless Antennas**



[Go to External Views](#)