Interactive Part Locator

HP ENVY x360 13-bd0000 Convertible PC

Welcome to the interactive part locator for the HP ENVY x360 13-bd0000 Convertible PC

Here's how to use it...

External Views (Click the link to navigate to the views)

On this page you will find large icons of each of the external views of this product. To view a specific view in greater detail, simply click that view.


Parts List (Click the link to navigate to the parts)

On this page, you will find a list of all of the replaceable parts for this product. To view a specific part and its location in the product, click the part name in the list.

That's it! On every page there is a link that brings you back to either the External Views or the Parts List, enabling you to navigate to whatever view or part you wish to review.

External Views


Back to Welcome page




Front View




Left View




Right View




Rear View




Display View




Top View



Bottom View



Internal View



Base Enclosure

Base Enclosure

Battery

Speaker Assembly

Touchpad Board

Touchpad Bracket

M.2 Solid State Drive

Fan

Heat Sink

IR Board

DC-in Connector

System Board (top)

System Board (bottom)

Top Cover with Keyboard

Display Panel

Webcam

Touch Control Board


Touch Control Board Cable

Display Panel Cable

Wireless Antennas

Hinges

Hinge Caps



Battery

Base Enclosure

Battery

Speaker Assembly

Touchpad Board

Touchpad Bracket

M.2 Solid State Drive

Fan

Heat Sink

IR Board

DC-in Connector

System Board (top)

System Board (bottom)

Top Cover with Keyboard

Display Panel

Webcam

Touch Control Board

Touch Control Board Cable

Display Panel Cable

Wireless Antennas

Hinges

Hinge Caps





Speaker Assembly

Base Enclosure Battery

Speaker Assembly

Touchpad Board
Touchpad Bracket
M.2 Solid State Drive

Fan

Heat Sink

IR Board

DC-in Connector

System Board (top)

System Board (bottom)

Top Cover with Keyboard

Display Panel

Webcam

Touch Control Board


Touch Control Board Cable


Display Panel Cable

Wireless Antennas

Hinges

Hinge Caps





Touchpad Board

Base Enclosure
Battery
Speaker Assembly

Touchpad Board

Touchpad Bracket
M.2 Solid State Drive

Fan

Heat Sink

IR Board

DC-in Connector

System Board (top)

System Board (bottom)

Top Cover with Keyboard

Display Panel

Webcam

Touch Control Board


Touch Control Board Cable


Display Panel Cable

Wireless Antennas

Hinges

Hinge Caps





Touchpad Bracket

Base Enclosure
Battery
Speaker Assembly
Touchpad Board

Touchpad Bracket

M.2 Solid State Drive

Fan

Heat Sink

IR Board

DC-in Connector

System Board (top)

System Board (bottom)

Top Cover with Keyboard

Display Panel

Webcam

Touch Control Board


Touch Control Board Cable

Display Panel Cable

Wireless Antennas

Hinges

Hinge Caps




M.2 Solid State Drive


Base Enclosure
Battery
Speaker Assembly
Touchpad Board
Touchpad Bracket

M.2 Solid State Drive

Fan
Heat Sink
IR Board
DC-in Connector
System Board (top)
System Board (bottom)
Top Cover with Keyboard
Display Panel
Webcam
Touch Control Board
Touch Control Board Cable
Display Panel Cable
Wireless Antennas
Hinges

Hinge Caps






Fan

Base Enclosure
Battery
Speaker Assembly
Touchpad Board
Touchpad Bracket
M.2 Solid State Drive

Fan

Heat Sink
IR Board
DC-in Connector
System Board (top)
System Board (bottom)
Top Cover with Keyboard
Display Panel
Webcam
Touch Control Board
Touch Control Board Cable
Display Panel Cable
Wireless Antennas
Hinges
Hinge Caps
Display Enclosure





Heat Sink

Base Enclosure
Battery
Speaker Assembly
Touchpad Board
Touchpad Bracket
M.2 Solid State Drive
Fan

Heat Sink

IR Board
DC-in Connector
System Board (top)
System Board (bottom)
Top Cover with Keyboard
Display Panel
Webcam
Touch Control Board


Touch Control Board Cable

Display Panel Cable Wireless Antennas

Hinges

Hinge Caps







IR Board

Base Enclosure
Battery
Speaker Assembly
Touchpad Board
Touchpad Bracket
M.2 Solid State Drive
Fan
Heat Sink

IR Board

DC-in Connector
System Board (top)
System Board (bottom)
Top Cover with Keyboard
Display Panel
Webcam
Touch Control Board
Touch Control Board Cable
Display Panel Cable
Wireless Antennas
Hinges
Hinge Caps
Display Enclosure





DC-in Connector

Base Enclosure

Battery

Speaker Assembly

Touchpad Board

Touchpad Bracket

M.2 Solid State Drive

Fan

Heat Sink

IR Board

DC-in Connector

System Board (top)

System Board (bottom)

Top Cover with Keyboard

Display Panel

Webcam

Touch Control Board


Touch Control Board Cable

Display Panel Cable

Wireless Antennas

Hinges

Hinge Caps



System Board (top)

Base Enclosure

Battery

Speaker Assembly

Touchpad Board

Touchpad Bracket

M.2 Solid State Drive

Fan

Heat Sink

IR Board

DC-in Connector

System Board (top)

System Board (bottom)

Top Cover with Keyboard

Display Panel

Webcam

Touch Control Board

Touch Control Board Cable


Display Panel Cable


Wireless Antennas

Hinges

Hinge Caps

Display Enclosure





Go to External Views

System Board (bottom)

Base Enclosure

Battery

Speaker Assembly

Touchpad Board

Touchpad Bracket

M.2 Solid State Drive

Fan

Heat Sink

IR Board

DC-in Connector

System Board (top)

System Board (bottom)

Top Cover with Keyboard

Display Panel

Webcam

Touch Control Board

Touch Control Board Cable


Display Panel Cable


Wireless Antennas

Hinges

Hinge Caps

Display Enclosure





Go to External Views

Top Cover with Keyboard

Base Enclosure

Battery

Speaker Assembly

Touchpad Board

Touchpad Bracket

M.2 Solid State Drive

Fan

Heat Sink

IR Board

DC-in Connector

System Board (top)

System Board (bottom)

Top Cover with Keyboard

Display Panel

Webcam

Touch Control Board

Touch Control Board Cable

Display Panel Cable

Wireless Antennas

Hinges

Hinge Caps



Display Panel

Base Enclosure

Battery

Speaker Assembly

Touchpad Board

Touchpad Bracket

M.2 Solid State Drive

Fan

Heat Sink

IR Board

DC-in Connector

System Board (top)

System Board (bottom)

Top Cover with Keyboard

Display Panel

Webcam

Touch Control Board


Touch Control Board Cable

Display Panel Cable

Wireless Antennas

Hinges

Hinge Caps



Webcam

Base Enclosure

Battery

Speaker Assembly

Touchpad Board

Touchpad Bracket

M.2 Solid State Drive

Fan

Heat Sink

IR Board

DC-in Connector

System Board (top)

System Board (bottom)

Top Cover with Keyboard

Display Panel

Webcam

Touch Control Board


Touch Control Board Cable

Display Panel Cable

Wireless Antennas

Hinges

Hinge Caps



Touch Control Board

Base Enclosure

Battery

Speaker Assembly

Touchpad Board

Touchpad Bracket

M.2 Solid State Drive

Fan

Heat Sink

IR Board

DC-in Connector

System Board (top)

System Board (bottom)

Top Cover with Keyboard

Display Panel

Webcam

Touch Control Board

Touch Control Board Cable

Display Panel Cable

Wireless Antennas

Hinges

Hinge Caps





Touch Control Board Cable

Base Enclosure

Battery

Speaker Assembly

Touchpad Board

Touchpad Bracket

M.2 Solid State Drive

Fan

Heat Sink

IR Board

DC-in Connector

System Board (top)

System Board (bottom)

Top Cover with Keyboard

Display Panel

Webcam

Touch Control Board

Touch Control Board Cable

Display Panel Cable

Wireless Antennas

Hinges

Hinge Caps



Display Panel Cable

Base Enclosure

Battery

Speaker Assembly

Touchpad Board

Touchpad Bracket

M.2 Solid State Drive

Fan

Heat Sink

IR Board

DC-in Connector

System Board (top)

System Board (bottom)

Top Cover with Keyboard

Display Panel

Webcam

Touch Control Board

Touch Control Board Cable

Display Panel Cable

Wireless Antennas

Hinges

Hinge Caps



Wireless Antennas

Base Enclosure

Battery

Speaker Assembly

Touchpad Board

Touchpad Bracket

M.2 Solid State Drive

Fan

Heat Sink

IR Board

DC-in Connector

System Board (top)

System Board (bottom)

Top Cover with Keyboard

Display Panel

Webcam

Touch Control Board


Touch Control Board Cable

Display Panel Cable

Wireless Antennas

Hinges

Hinge Caps



Hinges

Base Enclosure

Battery

Speaker Assembly

Touchpad Board

Touchpad Bracket

M.2 Solid State Drive

Fan

Heat Sink

IR Board

DC-in Connector

System Board (top)

System Board (bottom)

Top Cover with Keyboard

Display Panel

Webcam

Touch Control Board


Touch Control Board Cable

Display Panel Cable

Wireless Antennas

Hinges

Hinge Caps Display Enclosure



Hinge Caps

Base Enclosure

Battery

Speaker Assembly

Touchpad Board

Touchpad Bracket

M.2 Solid State Drive

Fan

Heat Sink

IR Board

DC-in Connector

System Board (top)

System Board (bottom)

Top Cover with Keyboard

Display Panel

Webcam

Touch Control Board


Touch Control Board Cable

Display Panel Cable

Wireless Antennas

Hinges

Hinge Caps



Display Enclosure

Base Enclosure

Battery

Speaker Assembly

Touchpad Board

Touchpad Bracket

M.2 Solid State Drive

Fan

Heat Sink

IR Board

DC-in Connector

System Board (top)

System Board (bottom)

Top Cover with Keyboard

Display Panel

Webcam

Touch Control Board

Touch Control Board Cable

Display Panel Cable

Wireless Antennas

Display Enclosure

Hinges

Hinge Caps



