

Interactive Part Locator

HP Chromebook 11MK G9 Education Edition

Welcome to the interactive part locator for the
HP Chromebook 11MK G9 Education Edition

Here's how to use it...

[External Views](#) (Click the link to navigate to the views)

On this page you will find large icons of each of the external views of this product. To view a specific view in greater detail, simply click that view.

[Parts List](#) (Click the link to navigate to the parts)

On this page, you will find a list of all of the replaceable parts for this product. To view a specific part and its location in the product, click the part name in the list.

That's it! On every page there is a link that brings you back to either the External Views or the Parts List, enabling you to navigate to whatever view or part you wish to review.

External Views

[Back to Welcome page](#)



Front



Left



Right



Rear



Display



Top



Bottom



Internal

[Go to Parts List](#)

Front View

[Back to External Views](#)



[Go to Parts List](#)

Left View

[Back to External Views](#)




Security lock slot

[Go to Parts List](#)

Right View

[Back to External Views](#)



[Go to Parts List](#)

Rear View

[Back to External Views](#)



Chromebook logo

HP logo

[Go to Parts List](#)

Display View

[Back to External Views](#)



[Go to Parts List](#)

Top View


[Back to External Views](#)



[Go to Parts List](#)

Bottom View


[Back to External Views](#)



[Go to Parts List](#)

Internal View

[Back to External Views](#)



[Go to Parts List](#)

Top Cover with Keyboard

Top Cover with Keyboard

- Touchpad
- Speakers
- Battery
- Hall Sensor Board
- System Board (Top)
- System Board (Bottom)
- Heat Sink
- Hinge Cap
- Base Enclosure
- Display Bezel
- Display Panel
- LCD Bracket
- Webcam Board
- Display Panel Hinges
- Display Panel Cable
- Webcam Cable



[Go to External Views](#)

Touchpad

Top Cover with Keyboard

Touchpad

Speakers

Battery

Hall Sensor Board

System Board (Top)

System Board (Bottom)

Heat Sink

Hinge Cap

Base Enclosure

Display Bezel

Display Panel



LCD Bracket

Webcam Board

Display Panel Hinges

Display Panel Cable

Webcam Cable



[Go to External Views](#)

Speakers

Top Cover with Keyboard

Touchpad

Speakers

Battery

Hall Sensor Board

System Board (Top)

System Board (Bottom)

Heat Sink

Hinge Cap

Base Enclosure

Display Bezel

Display Panel


LCD Bracket

Webcam Board

Display Panel Hinges

Display Panel Cable

Webcam Cable



[Go to External Views](#)

Battery


- Top Cover with Keyboard
- Touchpad
- Speakers
- Battery**
- Hall Sensor Board
- System Board (Top)
- System Board (Bottom)
- Heat Sink
- Hinge Cap
- Base Enclosure
- Display Bezel
- Display Panel
- LCD Bracket
- Webcam Board
- Display Panel Hinges
- Display Panel Cable
- Webcam Cable



Go to External Views

Hall Sensor Board


- Top Cover with Keyboard
- Touchpad
- Speakers
- Battery
- Hall Sensor Board**
- System Board (Top)
- System Board (Bottom)
- Heat Sink
- Hinge Cap
- Base Enclosure
- Display Bezel
- Display Panel
- LCD Bracket
- Webcam Board
- Display Panel Hinges
- Display Panel Cable
- Webcam Cable



[Go to External Views](#)

System Board (Top)


- Top Cover with Keyboard
- Touchpad
- Speakers
- Battery
- Hall Sensor Board
- System Board (Top)**
- System Board (Bottom)
- Heat Sink
- Hinge Cap
- Base Enclosure
- Display Bezel
- Display Panel
- LCD Bracket
- Webcam Board
- Display Panel Hinges
- Display Panel Cable
- Webcam Cable



[Go to External Views](#)

System Board (Bottom)


- Top Cover with Keyboard
- Touchpad
- Speakers
- Battery
- Hall Sensor Board
- System Board (Top)
- System Board (Bottom)**
- Heat Sink
- Hinge Cap
- Base Enclosure
- Display Bezel
- Display Panel
- LCD Bracket
- Webcam Board
- Display Panel Hinges
- Display Panel Cable
- Webcam Cable



[Go to External Views](#)

Heat Sink

- Top Cover with Keyboard
- Touchpad
- Speakers
- Battery
- Hall Sensor Board
- System Board (Top)
- System Board (Bottom)
- Heat Sink**
- Hinge Cap
- Base Enclosure
- Display Bezel
- Display Panel
- LCD Bracket
- Webcam Board
- Display Panel Hinges
- Display Panel Cable
- Webcam Cable



[Go to External Views](#)

Hinge Cap

- Top Cover with Keyboard
- Touchpad
- Speakers
- Battery
- Hall Sensor Board
- System Board (Top)
- System Board (Bottom)
- Heat Sink
- Hinge Cap**
- Base Enclosure
- Display Bezel
- Display Panel
- LCD Bracket
- Webcam Board
- Display Panel Hinges
- Display Panel Cable
- Webcam Cable



[Go to External Views](#)

Base Enclosure

- Top Cover with Keyboard
- Touchpad
- Speakers
- Battery
- Hall Sensor Board
- System Board (Top)
- System Board (Bottom)
- Heat Sink
- Hinge Cap
- Base Enclosure**
- Display Bezel
- Display Panel
- LCD Bracket
- Webcam Board
- Display Panel Hinges
- Display Panel Cable
- Webcam Cable



[Go to External Views](#)

Display Bezel

- Top Cover with Keyboard
- Touchpad
- Speakers
- Battery
- Hall Sensor Board
- System Board (Top)
- System Board (Bottom)
- Heat Sink
- Hinge Cap
- Base Enclosure
- Display Bezel**
- Display Panel
- LCD Bracket
- Webcam Board
- Display Panel Hinges
- Display Panel Cable
- Webcam Cable



[Go to External Views](#)

Display Panel


- Top Cover with Keyboard
- Touchpad
- Speakers
- Battery
- Hall Sensor Board
- System Board (Top)
- System Board (Bottom)
- Heat Sink
- Hinge Cap
- Base Enclosure
- Display Bezel
- Display Panel**
- LCD Bracket
- Webcam Board
- Display Panel Hinges
- Display Panel Cable
- Webcam Cable



[Go to External Views](#)

LCD Bracket

- Top Cover with Keyboard
- Touchpad
- Speakers
- Battery
- Hall Sensor Board
- System Board (Top)
- System Board (Bottom)
- Heat Sink
- Hinge Cap
- Base Enclosure
- Display Bezel
- Display Panel
- LCD Bracket**
- Webcam Board
- Display Panel Hinges
- Display Panel Cable
- Webcam Cable



[Go to External Views](#)

Webcam Board

- Top Cover with Keyboard
- Touchpad
- Speakers
- Battery
- Hall Sensor Board
- System Board (Top)
- System Board (Bottom)
- Heat Sink
- Hinge Cap
- Base Enclosure
- Display Bezel
- Display Panel
- LCD Bracket
- Webcam Board**
- Display Panel Hinges
- Display Panel Cable
- Webcam Cable



[Go to External Views](#)

Display Panel Hinges


- Top Cover with Keyboard
- Touchpad
- Speakers
- Battery
- Hall Sensor Board
- System Board (Top)
- System Board (Bottom)
- Heat Sink
- Hinge Cap
- Base Enclosure
- Display Bezel
- Display Panel
- LCD Bracket
- Webcam Board
- Display Panel Hinges**
- Display Panel Cable
- Webcam Cable



[Go to External Views](#)

Display Panel Cable


- Top Cover with Keyboard
- Touchpad
- Speakers
- Battery
- Hall Sensor Board
- System Board (Top)
- System Board (Bottom)
- Heat Sink
- Hinge Cap
- Base Enclosure
- Display Bezel
- Display Panel
- LCD Bracket
- Webcam Board
- Display Panel Hinges
- Display Panel Cable**
- Webcam Cable



[Go to External Views](#)

Webcam Cable

- Top Cover with Keyboard
- Touchpad
- Speakers
- Battery
- Hall Sensor Board
- System Board (Top)
- System Board (Bottom)
- Heat Sink
- Hinge Cap
- Base Enclosure
- Display Bezel
- Display Panel
- LCD Bracket
- Webcam Board
- Display Panel Hinges
- Display Panel Cable
- Webcam Cable**



[Go to External Views](#)