

# Interactive Part Locator

## HP Pavilion 14-ec0000 Laptop PC

Welcome to the interactive part locator  
for the HP Pavilion 14-ec0000 Laptop PC

### **Here's how to use it...**

[External Views](#) (Click the link to navigate to the views)

On this page you will find large icons of each of the external views of this product. To view a specific view in greater detail, simply click that view.

[Parts List](#) (Click the link to navigate to the parts)

On this page, you will find a list of all of the replaceable parts for this product. To view a specific part and its location in the product, click the part name in the list.

**That's it! On every page there is a link that brings you back to either the External Views or the Parts List, enabling you to navigate to whatever view or part you wish to review.**

# External Views

[Back to Welcome page](#)



Front View



Left View



Right View



Rear View



Display View



Top View



Bottom View



Internal View

[Go to Parts List](#)

# Front View


[Back to External Views](#)



[Go to Parts List](#)

# Left View


[Back to External Views](#)



[Go to Parts List](#)

# Right View


[Back to External Views](#)



[Go to Parts List](#)

# Rear View

[Back to External Views](#)




HP Pavilion logo

[Go to Parts List](#)

# Display View


[Back to External Views](#)



[Go to Parts List](#)

# Top View

[Back to External Views](#)




[Go to Parts List](#)



# Bottom View

[Back to External Views](#)



[Go to Parts List](#)

# Internal View

[Back to External Views](#)




[Go to Parts List](#)

# Base Enclosure

## Base Enclosure

- Battery
- Memory Modules
- M.2 Solid State Drive
- Wireless LAN Module
- Speakers
- Touchpad
- Touchpad Ribbon Cable
- USB Board
- USB Board Ribbon Cable
- System Fan
- Heat Sink
- System Board (top)
- System Board (bottom)
- Fingerprint Reader
- Fingerprint Reader Ribbon Cable
- Top Cover with Keyboard
- Display Panel Assembly
- DC-in Connector
- Display Bezel
- Display Panel
- Hinges
- Webcam
- Display Panel Cable
- Wireless Antenna



[Go to External Views](#)

# Battery

Base Enclosure

**Battery**

Memory Modules

M.2 Solid State Drive

Wireless LAN Module

Speakers

Touchpad

Touchpad Ribbon Cable

USB Board

USB Board Ribbon Cable

System Fan

Heat Sink

System Board (top)

System Board (bottom)

Fingerprint Reader

Fingerprint Reader Ribbon Cable

Top Cover with Keyboard

Display Panel Assembly

DC-in Connector

Display Bezel

Display Panel

Hinges

Webcam

Display Panel Cable

Wireless Antenna



[Go to External Views](#)

# Memory Modules

Base Enclosure

Battery

**Memory Modules**

M.2 Solid State Drive

Wireless LAN Module

Speakers

Touchpad

Touchpad Ribbon Cable

USB Board

USB Board Ribbon Cable

System Fan

Heat Sink

System Board (top)

System Board (bottom)

Fingerprint Reader

Fingerprint Reader Ribbon Cable

Top Cover with Keyboard

Display Panel Assembly

DC-in Connector

Display Bezel

Display Panel

Hinges

Webcam

Display Panel Cable

Wireless Antenna



[Go to External Views](#)

# M.2 Solid State Drive


- Base Enclosure
- Battery
- Memory Modules
- M.2 Solid State Drive**
- Wireless LAN Module
- Speakers
- Touchpad
- Touchpad Ribbon Cable
- USB Board
- USB Board Ribbon Cable
- System Fan
- Heat Sink
- System Board (top)
- System Board (bottom)
- Fingerprint Reader
- Fingerprint Reader Ribbon Cable
- Top Cover with Keyboard
- Display Panel Assembly
- DC-in Connector
- Display Bezel
- Display Panel
- Hinges
- Webcam
- Display Panel Cable
- Wireless Antenna



[Go to External Views](#)

# Wireless LAN Module


- Base Enclosure
- Battery
- Memory Modules
- M.2 Solid State Drive
- Wireless LAN Module**
- Speakers
- Touchpad
- Touchpad Ribbon Cable
- USB Board
- USB Board Ribbon Cable
- System Fan
- Heat Sink
- System Board (top)
- System Board (bottom)
- Fingerprint Reader
- Fingerprint Reader Ribbon Cable
- Top Cover with Keyboard
- Display Panel Assembly
- DC-in Connector
- Display Bezel
- Display Panel
- Hinges
- Webcam
- Display Panel Cable
- Wireless Antenna



[Go to External Views](#)

# Speakers

- Base Enclosure
- Battery
- Memory Modules
- M.2 Solid State Drive
- Wireless LAN Module
- Speakers**
- Touchpad
- Touchpad Ribbon Cable
- USB Board
- USB Board Ribbon Cable
- System Fan
- Heat Sink
- System Board (top)
- System Board (bottom)
- Fingerprint Reader
- Fingerprint Reader Ribbon Cable
- Top Cover with Keyboard
- Display Panel Assembly
- DC-in Connector
- Display Bezel
- Display Panel
- Hinges
- Webcam
- Display Panel Cable
- Wireless Antenna




[Go to External Views](#)



# Touchpad


- Base Enclosure
- Battery
- Memory Modules
- M.2 Solid State Drive
- Wireless LAN Module
- Speakers
- Touchpad**
- Touchpad Ribbon Cable
- USB Board
- USB Board Ribbon Cable
- System Fan
- Heat Sink
- System Board (top)
- System Board (bottom)
- Fingerprint Reader
- Fingerprint Reader Ribbon Cable
- Top Cover with Keyboard
- Display Panel Assembly
- DC-in Connector
- Display Bezel
- Display Panel
- Hinges
- Webcam
- Display Panel Cable
- Wireless Antenna



[Go to External Views](#)

# Touchpad Ribbon Cable

- Base Enclosure
- Battery
- Memory Modules
- M.2 Solid State Drive
- Wireless LAN Module
- Speakers
- Touchpad
- Touchpad Ribbon Cable**
- USB Board
- USB Board Ribbon Cable
- System Fan
- Heat Sink
- System Board (top)
- System Board (bottom)
- Fingerprint Reader
- Fingerprint Reader Ribbon Cable
- Top Cover with Keyboard
- Display Panel Assembly
- DC-in Connector
- Display Bezel
- Display Panel
- Hinges
- Webcam
- Display Panel Cable
- Wireless Antenna



[Go to External Views](#)

# USB Board


- Base Enclosure
- Battery
- Memory Modules
- M.2 Solid State Drive
- Wireless LAN Module
- Speakers
- Touchpad
- Touchpad Ribbon Cable
- USB Board**
- USB Board Ribbon Cable
- System Fan
- Heat Sink
- System Board (top)
- System Board (bottom)
- Fingerprint Reader
- Fingerprint Reader Ribbon Cable
- Top Cover with Keyboard
- Display Panel Assembly
- DC-in Connector
- Display Bezel
- Display Panel
- Hinges
- Webcam
- Display Panel Cable
- Wireless Antenna



[Go to External Views](#)

# USB Board Ribbon Cable


- Base Enclosure
- Battery
- Memory Modules
- M.2 Solid State Drive
- Wireless LAN Module
- Speakers
- Touchpad
- Touchpad Ribbon Cable
- USB Board
- USB Board Ribbon Cable**
- System Fan
- Heat Sink
- System Board (top)
- System Board (bottom)
- Fingerprint Reader
- Fingerprint Reader Ribbon Cable
- Top Cover with Keyboard
- Display Panel Assembly
- DC-in Connector
- Display Bezel
- Display Panel
- Hinges
- Webcam
- Display Panel Cable
- Wireless Antenna



[Go to External Views](#)

# System Fan


- Base Enclosure
- Battery
- Memory Modules
- M.2 Solid State Drive
- Wireless LAN Module
- Speakers
- Touchpad
- Touchpad Ribbon Cable
- USB Board
- USB Board Ribbon Cable
- System Fan**
- Heat Sink
- System Board (top)
- System Board (bottom)
- Fingerprint Reader
- Fingerprint Reader Ribbon Cable
- Top Cover with Keyboard
- Display Panel Assembly
- DC-in Connector
- Display Bezel
- Display Panel
- Hinges
- Webcam
- Display Panel Cable
- Wireless Antenna



[Go to External Views](#)

# Heat Sink


- Base Enclosure
- Battery
- Memory Modules
- M.2 Solid State Drive
- Wireless LAN Module
- Speakers
- Touchpad
- Touchpad Ribbon Cable
- USB Board
- USB Board Ribbon Cable
- System Fan
- Heat Sink**
- System Board (top)
- System Board (bottom)
- Fingerprint Reader
- Fingerprint Reader Ribbon Cable
- Top Cover with Keyboard
- Display Panel Assembly
- DC-in Connector
- Display Bezel
- Display Panel
- Hinges
- Webcam
- Display Panel Cable
- Wireless Antenna



[Go to External Views](#)

# System Board (top)


- Base Enclosure
- Battery
- Memory Modules
- M.2 Solid State Drive
- Wireless LAN Module
- Speakers
- Touchpad
- Touchpad Ribbon Cable
- USB Board
- USB Board Ribbon Cable
- System Fan
- Heat Sink
- System Board (top)**
- System Board (bottom)
- Fingerprint Reader
- Fingerprint Reader Ribbon Cable
- Top Cover with Keyboard
- Display Panel Assembly
- DC-in Connector
- Display Bezel
- Display Panel
- Hinges
- Webcam
- Display Panel Cable
- Wireless Antenna



[Go to External Views](#)

# System Board (bottom)

- Base Enclosure
- Battery
- Memory Modules
- M.2 Solid State Drive
- Wireless LAN Module
- Speakers
- Touchpad
- Touchpad Ribbon Cable
- USB Board
- USB Board Ribbon Cable
- System Fan
- Heat Sink
- System Board (top)
- System Board (bottom)**
- Fingerprint Reader
- Fingerprint Reader Ribbon Cable
- Top Cover with Keyboard
- Display Panel Assembly
- DC-in Connector
- Display Bezel
- Display Panel
- Hinges
- Webcam
- Display Panel Cable
- Wireless Antenna




[Go to External Views](#)



# Fingerprint Reader


- Base Enclosure
- Battery
- Memory Modules
- M.2 Solid State Drive
- Wireless LAN Module
- Speakers
- Touchpad
- Touchpad Ribbon Cable
- USB Board
- USB Board Ribbon Cable
- System Fan
- Heat Sink
- System Board (top)
- System Board (bottom)
- Fingerprint Reader**
- Fingerprint Reader Ribbon Cable
- Top Cover with Keyboard
- Display Panel Assembly
- DC-in Connector
- Display Bezel
- Display Panel
- Hinges
- Webcam
- Display Panel Cable
- Wireless Antenna



[Go to External Views](#)

# Fingerprint Reader Ribbon Cable

- Base Enclosure
- Battery
- Memory Modules
- M.2 Solid State Drive
- Wireless LAN Module
- Speakers
- Touchpad
- Touchpad Ribbon Cable
- USB Board
- USB Board Ribbon Cable
- System Fan
- Heat Sink
- System Board (top)
- System Board (bottom)
- Fingerprint Reader
- Fingerprint Reader Ribbon Cable**
- Top Cover with Keyboard
- Display Panel Assembly
- DC-in Connector
- Display Bezel
- Display Panel
- Hinges
- Webcam
- Display Panel Cable
- Wireless Antenna



[Go to External Views](#)

# Top Cover with Keyboard

- Base Enclosure
- Battery
- Memory Modules
- M.2 Solid State Drive
- Wireless LAN Module
- Speakers
- Touchpad
- Touchpad Ribbon Cable
- USB Board
- USB Board Ribbon Cable
- System Fan
- Heat Sink
- System Board (top)
- System Board (bottom)
- Fingerprint Reader
- Fingerprint Reader Ribbon Cable
- Top Cover with Keyboard**
- Display Panel Assembly
- DC-in Connector
- Display Bezel
- Display Panel
- Hinges
- Webcam
- Display Panel Cable
- Wireless Antenna



[Go to External Views](#)

# Display Panel Assembly


- Base Enclosure
- Battery
- Memory Modules
- M.2 Solid State Drive
- Wireless LAN Module
- Speakers
- Touchpad
- Touchpad Ribbon Cable
- USB Board
- USB Board Ribbon Cable
- System Fan
- Heat Sink
- System Board (top)
- System Board (bottom)
- Fingerprint Reader
- Fingerprint Reader Ribbon Cable
- Top Cover with Keyboard
- Display Panel Assembly**
- DC-in Connector
- Display Bezel
- Display Panel
- Hinges
- Webcam
- Display Panel Cable
- Wireless Antenna



[Go to External Views](#)

# DC-in Connector

- Base Enclosure
- Battery
- Memory Modules
- M.2 Solid State Drive
- Wireless LAN Module
- Speakers
- Touchpad
- Touchpad Ribbon Cable
- USB Board
- USB Board Ribbon Cable
- System Fan
- Heat Sink
- System Board (top)
- System Board (bottom)
- Fingerprint Reader
- Fingerprint Reader Ribbon Cable
- Top Cover with Keyboard
- Display Panel Assembly
- DC-in Connector**
- Display Bezel
- Display Panel
- Hinges
- Webcam
- Display Panel Cable
- Wireless Antenna



[Go to External Views](#)

# Display Bezel

- Base Enclosure
- Battery
- Memory Modules
- M.2 Solid State Drive
- Wireless LAN Module
- Speakers
- Touchpad
- Touchpad Ribbon Cable
- USB Board
- USB Board Ribbon Cable
- System Fan
- Heat Sink
- System Board (top)
- System Board (bottom)
- Fingerprint Reader
- Fingerprint Reader Ribbon Cable
- Top Cover with Keyboard
- Display Panel Assembly
- DC-in Connector
- Display Bezel**
- Display Panel
- Hinges
- Webcam
- Display Panel Cable
- Wireless Antenna



[Go to External Views](#)

# Display Panel

- Base Enclosure
- Battery
- Memory Modules
- M.2 Solid State Drive
- Wireless LAN Module
- Speakers
- Touchpad
- Touchpad Ribbon Cable
- USB Board
- USB Board Ribbon Cable
- System Fan
- Heat Sink
- System Board (top)
- System Board (bottom)
- Fingerprint Reader
- Fingerprint Reader Ribbon Cable
- Top Cover with Keyboard
- Display Panel Assembly
- DC-in Connector
- Display Bezel
- Display Panel**
- Hinges
- Webcam
- Display Panel Cable
- Wireless Antenna



[Go to External Views](#)

# Hinges

- Base Enclosure
- Battery
- Memory Modules
- M.2 Solid State Drive
- Wireless LAN Module
- Speakers
- Touchpad
- Touchpad Ribbon Cable
- USB Board
- USB Board Ribbon Cable
- System Fan
- Heat Sink
- System Board (top)
- System Board (bottom)
- Fingerprint Reader
- Fingerprint Reader Ribbon Cable
- Top Cover with Keyboard
- Display Panel Assembly
- DC-in Connector
- Display Bezel
- Display Panel
- Hinges**
- Webcam
- Display Panel Cable
- Wireless Antenna



[Go to External Views](#)



# Webcam

- Base Enclosure
- Battery
- Memory Modules
- M.2 Solid State Drive
- Wireless LAN Module
- Speakers
- Touchpad
- Touchpad Ribbon Cable
- USB Board
- USB Board Ribbon Cable
- System Fan
- Heat Sink
- System Board (top)
- System Board (bottom)
- Fingerprint Reader
- Fingerprint Reader Ribbon Cable
- Top Cover with Keyboard
- Display Panel Assembly
- DC-in Connector
- Display Bezel
- Display Panel
- Hinges
- Webcam**
- Display Panel Cable
- Wireless Antenna



[Go to External Views](#)

# Display Panel Cable



- Base Enclosure
- Battery
- Memory Modules
- M.2 Solid State Drive
- Wireless LAN Module
- Speakers
- Touchpad
- Touchpad Ribbon Cable
- USB Board
- USB Board Ribbon Cable
- System Fan
- Heat Sink
- System Board (top)
- System Board (bottom)
- Fingerprint Reader
- Fingerprint Reader Ribbon Cable
- Top Cover with Keyboard
- Display Panel Assembly
- DC-in Connector
- Display Bezel
- Display Panel
- Hinges
- Webcam
- Display Panel Cable**
- Wireless Antenna



[Go to External Views](#)

# Wireless Antenna

- Base Enclosure
- Battery
- Memory Modules
- M.2 Solid State Drive
- Wireless LAN Module
- Speakers
- Touchpad
- Touchpad Ribbon Cable
- USB Board
- USB Board Ribbon Cable
- System Fan
- Heat Sink
- System Board (top)
- System Board (bottom)
- Fingerprint Reader
- Fingerprint Reader Ribbon Cable
- Top Cover with Keyboard
- Display Panel Assembly
- DC-in Connector
- Display Bezel
- Display Panel
- Hinges
- Webcam
- Display Panel Cable
- Wireless Antenna**



[Go to External Views](#)