

Interactive Part Locator

HP ENVY 17-ch0xxx Laptop PC

Welcome to the interactive part locator for the
HP ENVY 17-ch0xxx Laptop PC

Here's how to use it...

[External Views](#) (Click the link to navigate to the views)

On this page you will find large icons of each of the external views of this product. To view a specific view in greater detail, simply click that view.

[Parts List](#) (Click the link to navigate to the parts)

On this page, you will find a list of all of the replaceable parts for this product. To view a specific part and its location in the product, click the part name in the list.

That's it! On every page there is a link that brings you back to either the External Views or the Parts List, enabling you to navigate to whatever view or part you wish to review.

External Views

Front

Left

Right

Rear


Internal

Parts List


Front View



Left View




Right View




Rear View



Internal View 1




Internal View 2




Base Enclosure


Base Enclosure




Battery





Memory Module(s)




Wireless LAN Module





Fan CPU





Fan GPU





Touchpad Board




M.2 Solid State Drive





Speakers




DC-in Connector




IR Board



Heatsink



Motherboard



Top Cover

Top Cover



Display Panel Assembly

Display Panel Assembly



Display Panel

Display Panel



Display Panel Hinges



Webcam

