

Interactive Part Locator

HP Chromebook x360 11 G4 EE

Welcome to the interactive part locator for the
HP Chromebook x360 11 G4 EE

Here's how to use it...

[External Views](#) (Click the link to navigate to the views)

On this page you will find large icons of each of the external views of this product. To view a specific view in greater detail, simply click that view.

[Parts List](#) (Click the link to navigate to the parts)

On this page, you will find a list of all of the replaceable parts for this product. To view a specific part and its location in the product, click the part name in the list.

That's it! On every page there is a link that brings you back to either the External Views or the Parts List, enabling you to navigate to whatever view or part you wish to review.

External Views

Front

Left

Right

Rear


Internal

Parts List


Front View



Left View



Right View



Rear View



Internal View 1




Battery

POGO Connector

Wireless LAN Module

Internal View 2

DC-in Connector



Motherboard

USB Board

Heatsink

Speakers


Touchpad Board

Base Enclosure


Base Enclosure




Battery





Wireless LAN Module





POGO Connector






Touchpad Board





Top Cover Webcam





Speakers





USB Board



Heatsink



Motherboard



Top Cover

Top Cover



Display Panel Assembly

Display Panel Assembly





Display Panel




Display Panel




Sensor Board




Display Panel Hinges



Hinge Covers



Hinge Brackets



Webcam

