Interactive Part Locator

HP Chromebook x360 14b-cb0000

Welcome to the interactive part locator for the HP Chromebook x360 14b-cb0000

Here's how to use it...

External Views (Click the link to navigate to the views)

On this page you will find large icons of each of the external views of this product. To view a specific view in greater detail, simply click that view.


Parts List (Click the link to navigate to the parts)

On this page, you will find a list of all of the replaceable parts for this product. To view a specific part and its location in the product, click the part name in the list.

That's it! On every page there is a link that brings you back to either the External Views or the Parts List, enabling you to navigate to whatever view or part you wish to review.

External Views

Back to Welcome page




Front View

Back to External Views




Display View

Back to External Views




Rear View

Back to External Views




Left View




Right View

Back to External Views



Top View




Bottom View



Internal View

Back to External Views



Base Enclosure

Battery

Speaker Assembly

Wireless LAN Module

Heat Sink

Touchpad

USB Board

System Board (Top)

System Board (Bottom)

Top Cover

Display Panel Assembly

Display Panel

Webcam

Webcam Cable

Display Panel Cable


Touch Control Board Cable

Hinges

Hinge Caps

Wireless LAN Antennas

Display Enclosure





Battery

Speaker Assembly
Wireless LAN Module

Heat Sink

Touchpad

USB Board

System Board (Top)

System Board (Bottom)

Top Cover

Display Panel Assembly

Display Panel

Webcam

Webcam Cable

Display Panel Cable

Touch Control Board Cable

Hinges


Hinge Caps

Wireless LAN Antennas

Display Enclosure

Battery





Battery

Speaker Assembly

Wireless LAN Module

Heat Sink

Touchpad

USB Board

System Board (Top)

System Board (Bottom)

Top Cover

Display Panel Assembly

Display Panel

Webcam

Webcam Cable

Display Panel Cable

Touch Control Board Cable


Hinges

Hinge Caps

Wireless LAN Antennas

Display Enclosure

Speaker Assembly



Battery

Speaker Assembly

Wireless LAN Module

Heat Sink

Touchpad

USB Board

System Board (Top)

System Board (Bottom)

Top Cover

Display Panel Assembly

Display Panel

Webcam

Webcam Cable

Display Panel Cable

Touch Control Board Cable

Hinges


Hinge Caps

Wireless LAN Antennas

Display Enclosure

Wireless LAN Module





Battery
Speaker Assembly
Wireless LAN Module

Heat Sink

Touchpad

USB Board

System Board (Top)

System Board (Bottom)

Top Cover

Display Panel Assembly

Display Panel

Webcam

Webcam Cable

Display Panel Cable

Touch Control Board Cable

Hinges


Hinge Caps

Wireless LAN Antennas

Display Enclosure

Heat Sink





Battery
Speaker Assembly
Wireless LAN Module

Heat Sink

Touchpad

USB Board

System Board (Top)

System Board (Bottom)

Top Cover

Display Panel Assembly

Display Panel

Webcam

Webcam Cable

Display Panel Cable

Touch Control Board Cable

Hinges


Hinge Caps

Wireless LAN Antennas

Display Enclosure

Touchpad





Battery **Speaker Assembly** Wireless LAN Module **Heat Sink**

Touchpad

USB Board

System Board (Top) System Board (Bottom) Top Cover Display Panel Assembly


Display Panel Webcam

Webcam Cable

Display Panel Cable **Touch Control Board Cable** Hinges Hinge Caps Wireless LAN Antennas

USB Board





Go to External Views

Display Enclosure

Battery

Speaker Assembly

Wireless LAN Module

Heat Sink

Touchpad

USB Board

System Board (Top)

System Board (Bottom)

Top Cover

Display Panel Assembly

Display Panel

Webcam

Webcam Cable

Display Panel Cable

Touch Control Board Cable

Hinges


Hinge Caps

Wireless LAN Antennas

Display Enclosure

Go to External Views

System Board (Top)



Battery

Speaker Assembly

Wireless LAN Module

Heat Sink

Touchpad

USB Board

System Board (Top)

System Board (Bottom)

Top Cover

Display Panel Assembly

Display Panel

Webcam

Webcam Cable

Display Panel Cable

Touch Control Board Cable


Hinges

Hinge Caps

Wireless LAN Antennas

Display Enclosure

System Board (Bottom)



Battery

Speaker Assembly

Wireless LAN Module

Heat Sink

Touchpad

USB Board

System Board (Top)

System Board (Bottom)

Top Cover

Display Panel Assembly

Display Panel

Webcam

Webcam Cable

Display Panel Cable

Touch Control Board Cable


Hinges

Hinge Caps

Wireless LAN Antennas

Display Enclosure

Top Cover





Battery

Speaker Assembly

Wireless LAN Module

Heat Sink

Touchpad

USB Board

System Board (Top)

System Board (Bottom)

Top Cover

Display Panel Assembly

Display Panel

Webcam

Webcam Cable

Display Panel Cable

Touch Control Board Cable


Hinges

Hinge Caps

Wireless LAN Antennas

Display Enclosure

Display Panel Assembly



Battery

Speaker Assembly

Wireless LAN Module

Heat Sink

Touchpad

USB Board

System Board (Top)

System Board (Bottom)

Top Cover

Display Panel Assembly

Display Panel

Webcam

Webcam Cable

Display Panel Cable

Touch Control Board Cable


Hinges

Hinge Caps

Wireless LAN Antennas

Display Enclosure

Display Panel



Webcam

Base Enclosure

Battery

Speaker Assembly

Wireless LAN Module

Heat Sink

Touchpad

USB Board

System Board (Top)

System Board (Bottom)

Top Cover

Display Panel Assembly

Display Panel

Webcam

Webcam Cable

Display Panel Cable


Touch Control Board Cable

Hinges

Hinge Caps

Wireless LAN Antennas

Display Enclosure





Battery

Speaker Assembly

Wireless LAN Module

Heat Sink

Touchpad

USB Board

System Board (Top)

System Board (Bottom)

Top Cover

Display Panel Assembly

Display Panel

Webcam

Webcam Cable

Display Panel Cable Touch Control Board Cable


Hinges

Hinge Caps

Wireless LAN Antennas

Display Enclosure

Webcam Cable



Battery

Speaker Assembly

Wireless LAN Module

Heat Sink

Touchpad

USB Board

System Board (Top)

System Board (Bottom)

Top Cover

Display Panel Assembly

Display Panel

Webcam

Webcam Cable

Display Panel Cable

Touch Control Board Cable


Hinges

Hinge Caps

Wireless LAN Antennas

Display Enclosure

Display Panel Cable



Battery

Speaker Assembly

Wireless LAN Module

Heat Sink

Touchpad

USB Board

System Board (Top)

System Board (Bottom)

Top Cover

Display Panel Assembly

Display Panel

Webcam

Webcam Cable

Display Panel Cable

Touch Control Board Cable


Hinges

Hinge Caps

Wireless LAN Antennas

Display Enclosure

Touch Control Board Cable



Battery

Speaker Assembly

Wireless LAN Module

Heat Sink

Touchpad

USB Board

System Board (Top)

System Board (Bottom)

Top Cover

Display Panel Assembly

Display Panel

Webcam

Webcam Cable


Display Panel Cable

Touch Control Board Cable

Hinges

Hinge Caps Wireless LAN Antennas Display Enclosure

Hinges



Battery

Speaker Assembly

Wireless LAN Module

Heat Sink

Touchpad

USB Board

System Board (Top)

System Board (Bottom)

Top Cover

Display Panel Assembly

Display Panel

Webcam

Webcam Cable

Display Panel Cable


Touch Control Board Cable

Hinges

Hinge Caps

Wireless LAN Antennas Display Enclosure

Hinge Caps



Battery

Speaker Assembly

Wireless LAN Module

Heat Sink

Touchpad

USB Board

System Board (Top)

System Board (Bottom)

Top Cover

Display Panel Assembly

Display Panel

Webcam

Webcam Cable

Display Panel Cable

Touch Control Board Cable


Hinges

Hinge Caps

Wireless LAN Antennas

Display Enclosure

Wireless LAN Antennas



Battery

Speaker Assembly

Wireless LAN Module

Heat Sink

Touchpad

USB Board

System Board (Top)

System Board (Bottom)

Top Cover

Display Panel Assembly

Display Panel

Webcam

Webcam Cable

Display Panel Cable

Touch Control Board Cable

Hinges

Hinge Caps

Wireless LAN Antennas

Display Enclosure

Display Enclosure

