

Interactive BIOS simulator

HP EliteBook 830 G8 Notebook PC

Welcome to the interactive BIOS simulator for the
HP EliteBook 830 G8 Notebook PC

Here's how to use it...

[BIOS Utility Menus](#): (Click the link to navigate to the individual menus)

On this page you will find thumbnail images of each of the product's BIOS utility menus. To view a specific menu in greater detail, simply click that thumbnail. Just as in the live BIOS, on each menu, you can select the tab of each of the other utility menus to navigate directly to that menu.

Menu options:


While the menu options cannot be toggled, many of them offer item specific information about that option. To view this information, use the cursor to rollover the option and the information will present in a pane on the right of the BIOS screen.

That's it!


On every page there is a link that brings you back to either this Welcome page or the BIOS Utility Menus page enabling you to navigate to whatever BIOS option you wish to review.

BIOS Utility Menus


Back to Welcome Page



Main



Security



Advanced



UEFI Drivers

Main Menu


Back to BIOS Utility Menus

Main

Security

Advanced

UEFI Drivers



HP computer setup

Item Specific Help

Help

Back to Welcome Page

Security Menu

Back to BIOS Utility Menus

Main | Security | Advanced | UEFI Drivers



HP computer setup

Administrator Tools

Security Configuration

☐ Trusted Execution Technology (TXT)

Utilities

Activation Status: Inactive
Absolute[®] Persistence Module Permanent Disable: No

Item Specific Help

Help

Back to Welcome Page

Advanced Menu

Back to BIOS Utility Menus

Main | Security | **Advanced** | UEFI Drivers



HP computer setup

Item Specific Help

Remote HP PC Hardware Diagnostics

Help

Back to Welcome Page

UEFI Drivers

[Back to BIOS Utility Menus](#)



HP computer setup

This will restart the system into the 3rd Party Option ROM Management application.
You can get to this application directly by pressing F3 during startup.

Item Specific Help


Help

[Back to Welcome Page](#)

System Information

Back to BIOS Utility Menus

Main | Security | Advanced | UEFI Drivers



HP computer setup

BASIC SYSTEM INFORMATION

Product Name

Processor 1

Memory Size

System BIOS

HP EliteBook 830 G8 Notebook PC

11th Gen Intel(R) Core(TM) i7-1185G7 @ 3.00GHz

16384 MB

T76 Ver. 80.30.02 09/12/2020

SERVICE -----

Born On Date

Serial Number

SKU Number

Universally Unique Identifier (UUID)

UUID (standard format)

Asset Tracking Number

03/17/2021

000076036X

1234567#ABA

370C6B5CAD14764E86CC00C2340895E8

5C6B0C37-14AD-4E76-86CC-00C2340895E8

000076036X

Press Escape to Return

Item Specific Help

Help

Back to Welcome Page

System Information

Back to BIOS Utility Menus

HP

HP computer setup

Main | Security | Advanced | UEFI Drivers

ADVANCED SYSTEM INFORMATION

Product Name

Memory Size

Storage Devices

HP EliteBook 830 G8 Notebook PC

16384 MB

KXG60ZNV256G KIOXIA-506A73JQKGUL (256 GB)

PROCESSOR1 -----

Processor Type

Cache Size (L1/L2/L3)

Processor Speed

Processor Cores

MicroCode Revision

Processor Stepping

Memory Speed

Bottom-Slot 1(left)

Bottom-Slot 2(right)

11th Gen Intel(R) Core(TM) i7-1185G7 @ 3.00GHz

320 KB / 5 MB / 12 MB

3000 MHz

4

58

1

3200 MHz

8 GB Hynix/Hyundai

8 GB Samsung

Item Specific Help

Help

Back to Welcome Page

System Information

Back to BIOS Utility Menus

Main

Security

Advanced

UEFI Drivers

HP

computer setup

FIRMWARE

System BIOS

T76 Ver. 80.30.02 09/12/2020

ME Firmware Version

15.0.1.1345

ME Firmware Mode

Enable

Audio Controller

Realtek ALC3292

Video BIOS Version

Intel(R) GOP Driver [17.0.1044]

Reference Code Revision

A.0.2A.30

Embedded Controller Firmware

Version

30.1F.00

USB Type-C Controller(s) Firmware

Version:

CCG6 : 1.3.0

Camera Controller Firmware

Camera : 0009

Item Specific Help

Help

Back to Welcome Page

System Information

Back to BIOS Utility Menus

HP

HP computer setup

Main | Security | Advanced | UEFI Drivers

SERVICE-----

Born On Date03/17/2021

Serial Number000076036X

SKU Number1234567#ABA

Universally Unique Identifier (UUID)370C6B5CAD14764E86CC00C2340895E8

UUID (standard format)5C6B0C37-14AD-4E76-86CC-00C2340895E8

Asset Tracking Byte000076036X

Feature Byte3X476J656b7B7H7M7RW7m7saBapaqauawb8bUbhcAdUdpudqfPguhKhWhkjhk8mEmwng.4M

Build ID21WWCVAT6bk#SABA#DABA

Product Family103C_5336AN HP EliteBook

System Board ID880D

System Board CT NumberPC3822E2DF113A

Primary Battery Serial Number

Press Escape to Return


Item Specific Help

Help

Back to Welcome Page

System Diagnostics

Back to BIOS Utility Menus



HP PC Hardware UEFI

Version 7.7.1.0


For more information, please visit: www.hp.com/go/techcenter/PCDiags

System Information

System Tests

Component Tests

Test Logs

 Language


Item Specific Help

Back to Welcome Page

BIOS Event Log

[Back to BIOS Utility Menus](#)

Main | Security | Advanced | UEFI Drivers



HP computer setup

BIOS EVENT LOG

Item Specific Help


Help

[Back to Welcome Page](#)

Update System BIOS

Back to BIOS Utility Menus

Main | Security | Advanced | UEFI Drivers



HP computer setup

Update System BIOS

Current System BIOS Version: T76 Ver. 80.30.02

Current BIOS Release Date: 09/12/2020

Installation Date of Current BIOS: 09/17/2020

Most Recent Update Check: Never Checked

→ Minimum BIOS version

Item Specific Help


Help

Back to Welcome Page

Change Date And Time

[Back to BIOS Utility Menus](#)

Main | Security | Advanced | UEFI Drivers



HP computer setup

Change Date And Time

Set Date (MM/DD/YYYY):03 / 17 /2021

Set Time (HH:MM):06 : 46

Item Specific Help


Help

[Back to Welcome Page](#)

System IDs

Back to BIOS Utility Menus

Main | Security | Advanced | UEFI Drivers



HP computer setup

System IDs

Item Specific Help


Help

Back to Welcome Page

Replicated Setup

Back to BIOS Utility Menus

Main | Security | Advanced | UEFI Drivers



HP computer setup

Replicated Setup

Item Specific Help


Help

Back to Welcome Page

Save Custom Defaults

Back to BIOS Utility Menus

Main | Security | Advanced | UEFI Drivers



HP computer setup

Are you sure you want to save your current settings as custom defaults?

Item Specific Help


Help

Back to Welcome Page

Apply Custom Defaults and Exit

Back to BIOS Utility Menus

Main | Security | Advanced | UEFI Drivers



HP computer setup

Are you sure you want to restore defaults and exit?


Item Specific Help

Help

Back to Welcome Page

Apply Factory Defaults and Exit

Back to BIOS Utility Menus




Back to Welcome Page

Ignore Changes and Exit

Back to BIOS Utility Menus

Main | Security | Advanced | UEFI Drivers



HP computer setup

Are you sure you want to ignore Changes and Exit?

Item Specific Help


Help

Back to Welcome Page

Save Changes and Exit

Back to BIOS Utility Menus

Save Changes ?




Item Specific Help

Back to Welcome Page

Create BIOS Administrator Password

[Back to BIOS Utility Menus](#)

BIOS Administrator Password



Enter BIOS Administrator Password

Item Specific Help

[Back to Welcome Page](#)

Create POST Power-On Password

[Back to BIOS Utility Menus](#)

POST Power-On Password

Enter POST Power-On Password


Item Specific Help

[Back to Welcome Page](#)

TPM Embedded Security

[Back to BIOS Utility Menus](#)

Main | Security | Advanced | UEFI Drivers



HP computer setup

TPM Embedded Security

TPM Specific Version

2.0

Item Specific Help

Help

[Back to Welcome Page](#)

BIOS Sure Start

[Back to BIOS Utility Menus](#)

Main

Security

Advanced

UEFI Drivers

HP

HP computer setup

BIOS Sure Start

☐ Sure Start BIOS Settings Protection

Requires BIOS Administrator credentials to be set

Sure Start Security Event Policy

Item Specific Help


Help

[Back to Welcome Page](#)

Secure Boot Configuration

Back to BIOS Utility Menus

Main | Security | Advanced | UEFI Drivers



HP computer setup

Secure Boot Configuration

Secure Boot Key Management

Access to the above settings requires Sure Start Secure Boot Keys Protection to be disabled

Requires BIOS Administrator credentials to be configured and Secure Boot to be enabled

Item Specific Help

Help

Back to Welcome Page

Secure Platform Management (SPM)


[Back to BIOS Utility Menus](#)

Main

Security

Advanced

UEFI Drivers



HP computer setup

Secure Platform Management (SPM)

SPM

SPM Current State: Not provisioned

HP Sure Run

HP Sure Run Current State: Inactive

HP Sure Admin

Enhanced BIOS Authentication Mode (EBAM)

EBAM Current State: Disabled

Local Access Key: Not Present

Item Specific Help


Help

[Back to Welcome Page](#)

Smart Cover

[Back to BIOS Utility Menus](#)

Main | Security | Advanced | UEFI Drivers



HP computer setup

Smart Cover

Access to the above settings requires Cover Removal Sensor to be enabled.

Item Specific Help

Help

[Back to Welcome Page](#)

Hard Drive Utilities

[Back to BIOS Utility Menus](#)

Main

Security

Advanced

UEFI Drivers

HP

computer setup

Hard Drive Utilities

Disable DriveLock on NVMe drives before using applications for hardware-based encryption.

Item Specific Help


Help

[Back to Welcome Page](#)

Restore Security Settings

Back to BIOS Utility Menus

Main | Security | Advanced | UEFI Drivers



HP computer setup

Are you sure you want to restore security settings to default?

Item Specific Help


Help

Back to Welcome Page

Display Language

Back to BIOS Utility Menus

Main | Security | **Advanced** | UEFI Drivers



Display Language

Item Specific Help


Help

Back to Welcome Page

Scheduled Power-On

[Back to BIOS Utility Menus](#)

Main | Security | **Advanced** | UEFI Drivers



Scheduled Power-On

Item Specific Help

HP computer setup


Help

[Back to Welcome Page](#)

Boot Options

Back to BIOS Utility Menus

Main | Security | **Advanced** | UEFI Drivers



HP computer setup

Boot Options

Item Specific Help

UEFI Boot Order

M.2 SSD: Windows Boot Manager

USB:

Network Boot: IPV4

Network Boot: IPV6


Help

Back to Welcome Page

HP Sure Recover

Back to BIOS Utility Menus

Main | Security | **Advanced** | UEFI Drivers



HP Sure Recover

Recovery Agent

URL: http://ftp.hp.com/pub/pcbios/CPR

Username:

Provisioning Version: 0

OS Recovery Agent Version: 0

Recovery Image

URL:

Username:

Provisioning Version: 0

OS Recovery Image Version:

OS Recovery Driver Version:

Embedded Storage for Recovery 32 GB

Item Specific Help

HP computer setup


Help

Back to Welcome Page

System Options

Back to BIOS Utility Menus

Main | Security | **Advanced** | UEFI Drivers



System Options

Item Specific Help


Help

Back to Welcome Page

Built-In Device Options

Back to BIOS Utility Menus

Main | Security | **Advanced** | UEFI Drivers



HP computer setup

Built-In Device Options

HP LAN-Wireless Protection

Item Specific Help


Help

Back to Welcome Page

Port Options

[Back to BIOS Utility Menus](#)

Main | Security | **Advanced** | UEFI Drivers

**HP** computer setup

Port Options

Disable Charging Port
in sleep/off if battery below (%)

10

Item Specific Help


Help

[Back to Welcome Page](#)

Power Management Options

[Back to BIOS Utility Menus](#)

Main | Security | **Advanced** | UEFI Drivers



HP computer setup

Power Management Options

HP will balance your battery health and battery duration [Enable]

Item Specific Help


Help

[Back to Welcome Page](#)

Remote Management Options

Back to BIOS Utility Menus

Main | Security | **Advanced** | UEFI Drivers



HP computer setup

Remote Management Options

Item Specific Help

Press Escape to Return


Help

Back to Welcome Page

MAC Address Pass Through

[Back to BIOS Utility Menus](#)

Main | Security | **Advanced** | UEFI Drivers



MAC Address Pass Through

Item Specific Help

Help

[Back to Welcome Page](#)

Thunderbolt Options

Back to BIOS Utility Menus

The screenshot shows the HP UEFI BIOS interface. At the top, there is a navigation bar with four tabs: 'Main', 'Security', 'Advanced', and 'UEFI Drivers'. The 'Advanced' tab is currently selected. In the top right corner, the HP logo is displayed. Below the navigation bar, the text 'HP computer setup' is visible. The main content area is titled 'Thunderbolt Options'. On the right side of this area, there is a large, light blue rectangular box with a black border. The top of this box contains the text 'Item Specific Help'. At the bottom right of the screen, there is a small, light blue button with the text 'Help'.

Back to Welcome Page

Remote HP PC Hardware Diagnostics

[Back to BIOS Utility Menus](#)

Main | Security | **Advanced** | UEFI Drivers

Remote HP PC Hardware Diagnostics

Diagnostics Logs Upload URL

HP computer setup

Item Specific Help


Help

[Back to Welcome Page](#)

Remote HP PC Hardware Diagnostics Execution

[Back to BIOS Utility Menus](#)

Remote HP PC Hardware Diagnostics Execution



Status of last attempt to execute: Could not detect network link or network cable is unplugged.


Item Specific Help

[Back to Welcome Page](#)

3rd Party Option ROM Management

Back to BIOS Utility Menus

Exiting...



HP computer setup

Save Changes?

Item Specific Help

Back to Welcome Page