Interactive Part Locator

HP Chromebook x360 14c-cc0000

Welcome to the interactive part locator for the HP Chromebook x360 14c-cc0000

Here's how to use it...

External Views (Click the link to navigate to the views)

On this page you will find large icons of each of the external views of this product. To view a specific view in greater detail, simply click that view.

Parts List (Click the link to navigate to the parts)

On this page, you will find a list of all of the replaceable parts for this product. To view a specific part and its location in the product, click the part name in the list.

That's it! On every page there is a link that brings you back to either the External Views or the Parts List, enabling you to navigate to whatever view or part you wish to review.

External Views

Back to Welcome page



Go to Parts List


Front View

Back to External Views




Go to Parts List


Left View




Right View




Rear View



Display View




Top View




Go to Parts List

Bottom View



Internal View



Go to Parts List

Base Enclosure

Base Enclosure

Battery

Touchpad

M.2 Solid State Drive

Fingerprint Reader

Speakers

USB Board

System Fan

Heat Sink

System Board (top)

System Board (bottom)

Camera Privacy Switch

Display Panel Assembly

Top Cover with Keyboard

Display Panel


Display Panel Cable

Sensor Board

Hinges

Webcam

Webcam Cable



Battery

Base Enclosure

Battery

Touchpad

M.2 Solid State Drive

Fingerprint Reader

Speakers

USB Board

System Fan

Heat Sink

System Board (top)

System Board (bottom)

Camera Privacy Switch

Display Panel Assembly

Top Cover with Keyboard

Display Panel

Display Panel Cable

Sensor Board

Hinges

Webcam

Webcam Cable





Touchpad

Base Enclosure

Battery

Touchpad

M.2 Solid State Drive

Fingerprint Reader

Speakers

USB Board

System Fan

Heat Sink

System Board (top)

System Board (bottom)

Camera Privacy Switch

Display Panel Assembly

Top Cover with Keyboard

Display Panel


Display Panel Cable


Sensor Board

Hinges

Webcam

Webcam Cable





M.2 Solid State Drive

Base Enclosure

Battery

Touchpad

M.2 Solid State Drive

Fingerprint Reader

Speakers

USB Board

System Fan

Heat Sink

System Board (top)

System Board (bottom)

Camera Privacy Switch

Display Panel Assembly

Top Cover with Keyboard

Display Panel

Display Panel Cable

Sensor Board

Hinges

Webcam

Webcam Cable





Fingerprint Reader

Base Enclosure

Battery

Touchpad

M.2 Solid State Drive

Fingerprint Reader

Speakers

USB Board

System Fan

Heat Sink

System Board (top)

System Board (bottom)

Camera Privacy Switch

Display Panel Assembly

Top Cover with Keyboard

Display Panel

Display Panel Cable

Sensor Board

Hinges

Webcam

Webcam Cable





Speakers

Base Enclosure

Battery

Touchpad

M.2 Solid State Drive

Fingerprint Reader

Speakers

USB Board

System Fan

Heat Sink

System Board (top)

System Board (bottom)

Camera Privacy Switch

Display Panel Assembly

Top Cover with Keyboard

Display Panel


Display Panel Cable

Sensor Board

Hinges

Webcam

Webcam Cable





USB Board

Base Enclosure

Battery

Touchpad

M.2 Solid State Drive

Fingerprint Reader

Speakers

USB Board

System Fan

Heat Sink

System Board (top)

System Board (bottom)

Camera Privacy Switch

Display Panel Assembly

Top Cover with Keyboard

Display Panel

Display Panel Cable


Sensor Board

Hinges

Webcam

Webcam Cable





System Fan

Base Enclosure

Battery

Touchpad

M.2 Solid State Drive

Fingerprint Reader

Speakers

USB Board

System Fan

Heat Sink

System Board (top)

System Board (bottom)

Camera Privacy Switch

Display Panel Assembly

Top Cover with Keyboard

Display Panel

Display Panel Cable


Sensor Board

Hinges

Webcam

Webcam Cable





Heat Sink

Base Enclosure

Battery

Touchpad

M.2 Solid State Drive

Fingerprint Reader

Speakers

USB Board

System Fan

Heat Sink

System Board (top)

System Board (bottom)

Camera Privacy Switch

Display Panel Assembly

Top Cover with Keyboard

Display Panel


Display Panel Cable

Sensor Board

Hinges

Webcam

Webcam Cable





System Board (top)

Base Enclosure

Battery

Touchpad

M.2 Solid State Drive

Fingerprint Reader

Speakers

USB Board

System Fan

Heat Sink

System Board (top)

System Board (bottom)

Camera Privacy Switch

Display Panel Assembly

Top Cover with Keyboard

Display Panel

Display Panel Cable


Sensor Board

Hinges

Webcam

Webcam Cable

Wireless LAN Antennas



System Board (bottom)

Base Enclosure

Battery

Touchpad

M.2 Solid State Drive

Fingerprint Reader

Speakers

USB Board

System Fan

Heat Sink

System Board (top)

System Board (bottom)

Camera Privacy Switch

Display Panel Assembly

Top Cover with Keyboard

Display Panel

Display Panel Cable


Sensor Board

Hinges

Webcam

Webcam Cable

Wireless LAN Antennas





Camera Privacy Switch

Base Enclosure

Battery

Touchpad

M.2 Solid State Drive

Fingerprint Reader

Speakers

USB Board

System Fan

Heat Sink

System Board (top)

System Board (bottom)

Camera Privacy Switch

Display Panel Assembly

Top Cover with Keyboard

Display Panel

Display Panel Cable


Sensor Board

Hinges

Webcam

Webcam Cable





Display Panel Assembly

Base Enclosure

Battery

Touchpad

M.2 Solid State Drive

Fingerprint Reader

Speakers

USB Board

System Fan

Heat Sink

System Board (top)

System Board (bottom)

Camera Privacy Switch

Display Panel Assembly

Top Cover with Keyboard

Display Panel

Display Panel Cable

Sensor Board

Hinges

Webcam

Webcam Cable



Top Cover with Keyboard

Base Enclosure

Battery

Touchpad

M.2 Solid State Drive

Fingerprint Reader

Speakers

USB Board

System Fan

Heat Sink

System Board (top)

System Board (bottom)

Camera Privacy Switch

Display Panel Assembly

Top Cover with Keyboard

Display Panel

Display Panel Cable

Sensor Board

Hinges

Webcam

Webcam Cable



Display Panel

Base Enclosure

Battery

Touchpad

M.2 Solid State Drive

Fingerprint Reader

Speakers

USB Board

System Fan

Heat Sink

System Board (top)

System Board (bottom)

Camera Privacy Switch

Display Panel Assembly

Top Cover with Keyboard

Display Panel

Display Panel Cable


Sensor Board

Hinges

Webcam

Webcam Cable

Wireless LAN Antennas



Display Panel Cable

Base Enclosure

Battery

Touchpad

M.2 Solid State Drive

Fingerprint Reader

Speakers

USB Board

System Fan

Heat Sink

System Board (top)

System Board (bottom)

Camera Privacy Switch

Display Panel Assembly

Top Cover with Keyboard

Display Panel

Display Panel Cable

Sensor Board

Hinges

Webcam

Webcam Cable

Wireless LAN Antennas



Sensor Board

Base Enclosure

Battery

Touchpad

M.2 Solid State Drive

Fingerprint Reader

Speakers

USB Board

System Fan

Heat Sink

System Board (top)

System Board (bottom)

Camera Privacy Switch

Display Panel Assembly

Top Cover with Keyboard

Display Panel

Display Panel Cable

Sensor Board

Hinges

Webcam

Webcam Cable

Wireless LAN Antennas



Hinges

Base Enclosure

Battery

Touchpad

M.2 Solid State Drive

Fingerprint Reader

Speakers

USB Board

System Fan

Heat Sink

System Board (top)

System Board (bottom)

Camera Privacy Switch

Display Panel Assembly

Top Cover with Keyboard

Display Panel

Display Panel Cable


Sensor Board

Hinges

Webcam

Webcam Cable

Wireless LAN Antennas



Webcam

Base Enclosure

Battery

Touchpad

M.2 Solid State Drive

Fingerprint Reader

Speakers

USB Board

System Fan

Heat Sink

System Board (top)

System Board (bottom)

Camera Privacy Switch

Display Panel Assembly

Top Cover with Keyboard

Display Panel

Display Panel Cable


Sensor Board

Hinges

Webcam

Webcam Cable

Wireless LAN Antennas



Webcam Cable

Base Enclosure

Battery

Touchpad

M.2 Solid State Drive

Fingerprint Reader

Speakers

USB Board

System Fan

Heat Sink

System Board (top)

System Board (bottom)

Camera Privacy Switch

Display Panel Assembly

Top Cover with Keyboard

Display Panel


Display Panel Cable

Sensor Board

Hinges

Webcam

Webcam Cable



Wireless LAN Antennas

Base Enclosure

Battery

Touchpad

M.2 Solid State Drive

Fingerprint Reader

Speakers

USB Board

System Fan

Heat Sink

System Board (top)

System Board (bottom)

Camera Privacy Switch

Display Panel Assembly

Top Cover with Keyboard

Display Panel

Display Panel Cable

Sensor Board

Hinges

Webcam

Webcam Cable

