

# Interactive Part Locator

## HP 17-cp0xxx Laptop PC

Welcome to the interactive part locator for the  
HP 17-cp0xxx Laptop PC

### **Here's how to use it...**

[External Views](#) (Click the link to navigate to the views)

On this page you will find large icons of each of the external views of this product. To view a specific view in greater detail, simply click that view.

[Parts List](#) (Click the link to navigate to the parts)

On this page, you will find a list of all of the replaceable parts for this product. To view a specific part and its location in the product, click the part name in the list.

**That's it! On every page there is a link that brings you back to either the External Views or the Parts List, enabling you to navigate to whatever view or part you wish to review.**

# External Views

Front

Left

Right

Rear

Internal

# Parts List


# Front View



# Left View




## Right View



## Rear View



# Internal View 1




Wireless LAN Module

Battery



# Internal View 2




# Base Enclosure


Base Enclosure





# Battery




# Hard Disk Drive




# Memory Module(s)





# Wireless LAN Module



# M.2 Solid State Drive




# Touchpad Board







# Fingerprint Reader Board




# DC-in Connector





# Fan




# USB Board




# Heatsink



# Motherboard



# Speakers



# Top Cover

Top Cover





# Display Panel Assembly

Display Panel Assembly



# Hinge Cover

Hinge Cover



# Display Bezel

Display Bezel




# Display Panel

Display Panel



# Display Panel Hinges



# Webcam

