

# Interactive Part Locator

## HP Elite x2 G8 Tablet

Welcome to the interactive part locator for the  
HP Elite x2 G8 Tablet

### Here's how to use it...

[External Views](#) (Click the link to navigate to the views)

On this page you will find large icons of each of the external views of this product. To view a specific view in greater detail, simply click that view.

[Parts List](#) (Click the link to navigate to the parts)

On this page, you will find a list of all of the replaceable parts for this product. To view a specific part and its location in the product, click the part name in the list.

**That's it! On every page there is a link that brings you back to either the External Views or the Parts List, enabling you to navigate to whatever view or part you wish to review.**

# External Views

Front

Left

Right

Rear

Internal

# Parts List

# Front View



# Left View




## Right View



# Rear View



# Internal View 1






CPU Heatsink

# Internal View 2

- Power Button/  
Audio Jack Assembly
- Fingerprint Board Reader
- Volume Button Board



- Webcam Assembly
- Heatsink/ Fan Assembly
- Motherboard
- Hinges
- POGO Cable
- SIM Board

# Keyboard



Keyboard


# Display Panel Assembly

Display Panel Assembly





# Kickstand



Kickstand




# Battery





# Speakers



# M.2 Solid State Drive




# SIM Board








# POGO Cable





# Hinges





# Webcam Assembly




# Fingerprint Reader Board





# Power Button/Audio Jack Assembly



# Volume Button Board



# Heatsink/Fan Assembly



# Motherboard

