

# Interactive Part Locator

## HP Spectre 16 x360 Convertible PC

Welcome to the interactive part locator for the  
HP Spectre 16 x360 Convertible PC

### **Here's how to use it...**

[External Views](#) (Click the link to navigate to the views)

On this page you will find large icons of each of the external views of this product. To view a specific view in greater detail, simply click that view.

[Parts List](#) (Click the link to navigate to the parts)

On this page, you will find a list of all of the replaceable parts for this product. To view a specific part and its location in the product, click the part name in the list.

**That's it! On every page there is a link that brings you back to either the External Views or the Parts List, enabling you to navigate to whatever view or part you wish to review.**

# External Views

Front

Left

Right

Rear

Internal

# Parts List

# Front View



Optical  
Disk Drive

# Left View



## Right View



## Rear View




# Internal View 1





# Internal View 2

IR Board



Touchpad Board

# Base Enclosure

Base Enclosure



# Battery



# M.2 Solid State Drive






# Audio Board



# DC-in Connector




# Fans








# Heatsink





# Motherboard




# Speakers



# IR Board




# Touchpad Board




# Keyboard Backlight

Keyboard Backlight




# Keyboard

Keyboard



# Fingerprint Reader





# Display Panel


Display Panel




# Display Panel Hinges



# Hinge Covers



# Webcam



# Top Cover

Top Cover

