

# Using a single receiver to connect the HP 975 Dual-Mode Wireless Keyboard and supported mice to a computer

Use the following procedure to pair the HP 93x Creator Wireless Mouse, HP 635 Multi-Device Wireless Mouse, or other supported mice and the HP 975 wireless keyboard to your computer, using the keyboard receiver. Be sure to use the correct receiver.

1. If an HP 93x Creator Wireless Mouse, HP 635 Multi-Device Wireless Mouse, or other supported mouse is already connected, disconnect the receiver for the mouse from your computer.
2. Remove the cover of the mouse (1), and place the mouse receiver inside of the mouse (2). Replace the cover on the mouse (3).

After this step, the cursor does not show on-screen when you move the mouse.




3. If the HP 975 wireless keyboard currently is connected or paired, remove the keyboard receiver from your computer. The keyboard no longer functions after this step. If the HP 975 wireless keyboard is not connected or paired currently, locate the keyboard receiver but do not connect or pair it. A keyboard and mouse icon can be seen on the keyboard receiver.


4. If the keyboard has not been charged previously, connect the HP 975 Dual-Mode wireless keyboard to your computer using the USB cable that came with the keyboard, and charge it for 3 hours.



5. Move the keyboard switch to the **on** position.



6. Press the mouse pairing button on the bottom or on the side until the light appears. Press and hold the button for 3 to 10 seconds until the receiver light blinks.



7. Connect the HP 975 Dual-Mode wireless keyboard receiver into your device. A keyboard and a mouse icon displays on this receiver.



Both the HP 975 Dual-Mode wireless keyboard and supported mouse connect to your computer using the keyboard receiver.