





1 Turn on your device.

2 Insert the AAAA pen battery.



3 Turn on the pen by tapping the tip to any surface.



By default, press **A** to select an item or perform a right-click function, and press **B** to erase. Depending on the application, these button functions might vary.

To view or edit the configuration of these buttons, use the pen app, such as HP Pen Control, on your device (select products only).

ESPAÑOL

- 1 Encienda su dispositivo.
- 2 Inserte la batería AAAA en el lápiz.
- 3 Encienda el lápiz dando un golpecito con la punta sobre cualquier superficie.

De forma predeterminada, presione **A** para seleccionar un elemento o realizar una función con el botón derecho del mouse y presione **B** para borrar. Según la aplicación, las funciones de este botón pueden variar.

Para ver o editar la configuración de estos botones, utilice la aplicación del lápiz, como HP Pen Control, en su dispositivo (solo en productos seleccionados).

FRANÇAIS

- 1 Mettez votre appareil sous tension.
- 2 Insérez la pile AAAA du stylet.
- 3 Mettez le stylet sous tension en tapotant la pointe sur n'importe quelle surface.

Par défaut, appuyez sur **A** pour sélectionner un élément ou effectuer une fonction de clic droit et appuyez sur **B** pour effacer. Selon l'application, les fonctions de ces boutons peuvent varier.

Pour afficher ou modifier la configuration de ces boutons, utilisez l'application stylet, par exemple HP Pen Control, de votre appareil (certains produits uniquement).

PORTUGUÊS (BRASIL)

- 1 Ligue o dispositivo.
- 2 Insira a pilha AAAA na caneta.
- 3 Ligue a caneta pressionando a ponta de leve em qualquer superfície.

Por padrão, pressione **A** para selecionar um item ou executar uma função de clique com o botão direito, e pressione **B** para apagar. Dependendo do aplicativo, as funções desses botões podem variar.

Para exibir ou editar a configuração desses botões, use o aplicativo da caneta, como o HP Pen Control, em seu dispositivo (apenas em determinados produtos).



ENGLISH

For regulatory information, scan the QR code or go to www.hp.com/go/regulatory.

ESPAÑOL

Para obtener información normativa, escanee el código QR o vaya a www.hp.com/go/regulatory.

FRANÇAIS

Pour des informations sur les réglementations, scannez le code QR ou rendez-vous sur www.hp.com/go/regulatory.

PORTUGUÊS (BRASIL)

Para informações regulamentares, faça a leitura do código QR ou acesse www.hp.com/go/regulatory.

Operating temperature/操作温度/操作温度: 0° – 40° C

RMN/型號/型号: HSA-M001S

© Copyright 2021 HP Development Company, L.P.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

First Edition: May 2021

M75847-001