





1



Remove all packaging and tape. Plug in and power on the printer.

2




Adjust guides, load paper and slide the tray cover into place. Open the output tray extender.

3



For wireless setup, do not connect an Ethernet cable.

4



Install the **required** HP Smart software from **123.hp.com** or your app store on a computer or mobile device.


5

Follow instructions in HP Smart to connect the printer to a network and finish setup.



See Reference Guide for additional Wi-Fi troubleshooting and tips.

If connecting the printer to Wi-Fi, your computer or mobile device must be near the printer during setup.



Get help with setup

Find setup information and videos online.

hp.com/support/printer-setup





The Apple logo is a trademark of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc. Android, Google Play, and the Google Play logo are trademarks of Google Inc.
© Copyright 2021 HP Development Company, L.P.



381V6-90011

Printed in Vietnam