

Computer Setup

User Guide

© Copyright 2008 Hewlett-Packard
Development Company, L.P.

Windows is a U.S. registered trademark of
Microsoft Corporation.

The information contained herein is subject
to change without notice. The only
warranties for HP products and services are
set forth in the express warranty statements
accompanying such products and services.
Nothing herein should be construed as
constituting an additional warranty. HP shall
not be liable for technical or editorial errors
or omissions contained herein.

Second Edition: May 2008

First Edition: April 2008

Document Part Number: 468554-002

Product notice

This user guide describes features that are common to most models. Some features may not be available on your computer.

Table of contents

1 Starting Computer Setup

2 Using Computer Setup

Navigating and selecting in Computer Setup	2
Restoring factory settings in Computer Setup	3

3 Computer Setup menus

File menu	4
Security menu	5
System Configuration menu	6

Index	7
-------------	---

1 Starting Computer Setup

Computer Setup is a preinstalled, ROM-based utility that can be used even when the operating system is not working or will not load.



NOTE: Some of the Computer Setup menu items listed in this guide may not be supported by your computer.

NOTE: Pointing devices are not supported in Computer Setup. You must use the keyboard to navigate and make selections.

NOTE: An external keyboard connected by USB can be used with Computer Setup only if USB legacy support is enabled.

To start Computer Setup, follow these steps:

1. Turn on or restart the computer.
2. Before Windows® opens and while the “F10=ROM Based Setup” message is displayed in the lower-left corner of the screen, press **F10**.

2 Using Computer Setup

Navigating and selecting in Computer Setup

The information and settings in Computer Setup are accessed from the File, Security, Diagnostics, and System Configuration menus.

1. Open Computer Setup by turning on or restarting the computer, and then pressing **f10** while the "F10 = ROM Based Setup" message is displayed in the lower-left corner of the screen.

Because Computer Setup is not Windows-based, it does not support the TouchPad. Navigation and selection are by keystroke:

- To choose a menu or a menu item, use the arrow keys.
 - To select an item, press **enter**.
 - To close open dialog boxes and return to the main Computer Setup screen, press **esc**.
 - To view navigation information, press **f1**.
 - To change the language, press **f2**.
2. Select the **File**, **Security**, or **System Configuration** menu.
 3. To exit Computer Setup, choose one of the following methods:
 - To exit Computer Setup without saving your preferences, use the arrow keys to select **File > Ignore changes and exit**. Then follow the instructions on the screen.
 - To save your preferences and exit Computer Setup, use the arrow keys to select **File > Save changes and exit**. Then follow the instructions on the screen.

Your preferences go into effect when the computer restarts.

Restoring factory settings in Computer Setup

To return all settings in Computer Setup to the values that were set at the factory, follow these steps:

1. Open Computer Setup by turning on or restarting the computer, and then pressing **f10** while the "F10 = ROM Based Setup" message is displayed in the lower-left corner of the screen.
2. Use the arrow keys to select **File > Restore defaults**, and then press **enter**.
3. When the confirmation dialog box opens, press **f10**.
4. To save your preferences and exit Computer Setup, use the arrow keys to select **File > Save changes and exit**. Then follow the instructions on the screen.

Your preferences go into effect when the computer restarts.



NOTE: Your password settings and security settings are not changed when you restore the factory settings.

3 Computer Setup menus

The menu tables in this section provide an overview of Computer Setup options.

 **NOTE:** Some of the Computer Setup menu items listed in this chapter may not be supported by your computer.

File menu

Select	To do this
System information	• View identification information for the computer and the batteries in the system. • View specification information for the processor, cache and memory size, system ROM, video revision, and keyboard controller version.
Restore defaults	Replace the configuration settings in Computer Setup with the original factory settings. (Password settings and security settings are not changed when you restore the factory settings.)
Ignore changes and exit	Cancel any changes entered during the current session. Then exit and restart the computer.
Save changes and exit	Save any changes entered during the current session. Then exit and restart the computer. Your changes go into effect when the computer restarts.

Security menu



NOTE: Some of the menu items listed in this section may not be supported by your computer.

Select	To do this
Administrator Password	Enter, change, or delete a setup password.
Change Administrator Password	Enter, change, or delete an Administrator password.
Password Check	• Enable/disable Always to always check for a password. • Enable Setup to set the password.
Password Options	• Enable/disable stringent security. • Enable/disable the password requirement on computer restart.
DriveLock Passwords	• Enable/disable DriveLock on any computer hard drive. • Change a DriveLock user password or master password. NOTE: DriveLock settings are accessible only when you enter Computer Setup by turning on (not restarting) the computer.
Notebook hard drive password status	Enable/disable hard drive password status visibility.

System Configuration menu



NOTE: Some of the listed System Configuration options may not be supported by your computer.

Select	To do this
Boot Options	• Set an f9 and f10 delay when starting up. • Set the Express Boot Popup delay in seconds. • Enable/disable internal network adapter boot and set the boot mode (PXE). • Enable/disable MultiBoot, which sets a boot order that can include most boot devices in the system. • Set the boot order. ◦ 1st Boot device: USB devices ◦ 2nd Boot device: Notebook hard drive ◦ 3rd Boot device: Notebook Ethernet
Device Configurations	• Swap the functions of the fn key and left ctrl key. • Enable/disable USB legacy support. When enabled, USB legacy support allows the following: ◦ Use of a USB keyboard in Computer Setup even when a Windows operating system is not running. ◦ Startup from bootable USB devices, including a hard drive, diskette drive, or optical drive connected by a USB port to the computer. • Enable/disable fan always on while connected to an AC outlet. • Enable/disable SATA Native Mode.
Built-In Device Options	• Enable/disable embedded WLAN Device Radio. • Enable/disable Bluetooth. • Enable/disable integrated camera. • Enable/disable Wake on LAN. • Enable/disable the ExpressCard slot.

Index

B

boot options 6
boot order 6

C

Computer Setup
 accessing 1
 File menu 4
 navigating and selecting 2
 restoring factory settings 3
 Security menu 5
 System Configuration menu 6
 using 2

D

DriveLock password 5
drives, boot order 6

F

File menu 4

L

legacy support, USB 1, 6

P

passwords 5

S

Security menu 5
setup utility
 accessing 1
 File menu 4
 Security menu 5
 System Configuration menu 6
stringent security 5
System Configuration menu 6
system fan 6
system information 4

U

USB legacy support 1, 6

