

Computer Setup

User Guide

© Copyright 2009 Hewlett-Packard
Development Company, L.P.

Bluetooth is a trademark owned by its
proprietor and used by Hewlett-Packard
Company under license. Windows is a U.S.
registered trademark of Microsoft
Corporation.

The information contained herein is subject
to change without notice. The only
warranties for HP products and services are
set forth in the express warranty statements
accompanying such products and services.
Nothing herein should be construed as
constituting an additional warranty. HP shall
not be liable for technical or editorial errors
or omissions contained herein.

First Edition: June 2009

Document Part Number: 535141-001

Product notice

This user guide describes features that are
common to most models. Some features
may not be available on your computer.

Table of contents

1 Starting Computer Setup

2 Using Computer Setup

Navigating and selecting in Computer Setup	3
Restoring factory settings in Computer Setup	4

3 Computer Setup menus

File menu	6
Security menu	7
Diagnostics menu	8
System Configuration menu	9

Index	11
-------------	----

1 Starting Computer Setup

Computer Setup is a preinstalled, ROM-based utility that can be used even when the operating system is not working or will not load.



NOTE: Some of the Computer Setup menu items listed in this guide may not be supported by your computer.

NOTE: An external keyboard or mouse connected to a USB port can be used with Computer Setup only if USB legacy support is enabled.

To start Computer Setup, follow these steps:

1. Turn on or restart the computer, and then press **esc** while the “Press the ESC key for Startup Menu” message is displayed at the bottom of the screen.
2. Press **f10** to enter BIOS Setup.

2 Using Computer Setup

Navigating and selecting in Computer Setup

The information and settings in Computer Setup are accessed from the File, Security, Diagnostics, and System Configuration menus.

To navigate and select in Computer Setup, follow these steps:

1. Turn on or restart the computer, and then press **esc** while the “Press the ESC key for Startup Menu” message is displayed at the bottom of the screen.
 - To select a menu or a menu item, use the tab key and the keyboard arrow keys and then press **enter**, or use a pointing device to click the item.
 - To scroll up and down, click the up arrow or the down arrow in the upper-right corner of the screen, or use the up arrow key or the down arrow key.
 - To close open dialog boxes and return to the main Computer Setup screen, press **esc**, and then follow the on-screen instructions.

 **NOTE:** You can use either a pointing device (TouchPad or USB mouse) or the keyboard to navigate and make selections in Computer Setup.

2. Press **f10** to enter BIOS Setup.
3. Select the **File**, **Security**, **Diagnostics**, or **System Configuration** menu.

To exit Computer Setup, choose one of the following methods:

- To exit Computer Setup without saving your changes, click the **Exit** icon in the lower-left corner of the screen, and then follow the on-screen instructions.

– or –

Use the tab key and the arrow keys to select **File > Ignore changes and exit**, and then press **enter**.

– or –
- To save your changes and exit Computer Setup, click the **Save** icon in the lower-left corner of the screen, and then follow the on-screen instructions.

– or –

Use the tab key and the arrow keys to select **File > Save changes and exit**, and then press **enter**.

Your changes go into effect when the computer restarts.

Restoring factory settings in Computer Setup

To return all settings in Computer Setup to the values that were set at the factory, follow these steps:

1. Turn on or restart the computer, and then press **esc** while the “Press the ESC key for Startup Menu” message is displayed at the bottom of the screen.
2. Press **f10** to enter BIOS Setup.
3. Use a pointing device or the arrow keys to select **File > Restore defaults**.
4. Follow the on-screen instructions.
5. To save your changes and exit Computer Setup, click the **Save** icon in the lower-left corner of the screen, and then follow the on-screen instructions.

– or –

Use the arrow keys to select **File > Save changes and exit**, and then press **enter**.

Your changes go into effect when the computer restarts.



NOTE: Your password settings, language settings, security settings, and hard drive mode are not changed when you restore the factory settings.

3 Computer Setup menus

The menu tables in this section provide an overview of Computer Setup options.



NOTE: Some of the Computer Setup menu items listed in this chapter may not be supported by your computer.

File menu

Select	To do this
System Information	• View identification information for the computer and the batteries in the system. • View specification information for the processor, cache and memory size, system ROM, video revision, and keyboard controller version.
Set System Date and Time	Set or change the date and time on the computer.
Restore defaults	Replace the configuration settings in Computer Setup with the original factory settings. (Hard drive mode, password settings, and security settings are not changed when you restore the factory settings.)
BIOS security to factory default	Reset the BIOS security policies and clear the ProtectTools user information.
Ignore changes and exit	Cancel any changes entered during the current session. Then exit and restart the computer.
Save changes and exit	Save any changes entered during the current session. Then exit and restart the computer. Your changes go into effect when the computer restarts.

Security menu



NOTE: Some of the menu items listed in this section may not be supported by your computer.

Select	To do this
Setup BIOS Administrator Password	Set up a BIOS administrator password.
User Management (requires a BIOS administrator password)	• Create a new BIOS user account. • View a list of ProtectTools users.
Password Policy (requires a BIOS administrator password)	Revise password policy criteria.
HP SpareKey	Enable/disable HP SpareKey (enabled by default).
Always Prompt for HP SpareKey Enrollment	Enable/disable HP SpareKey enrollment (enabled by default).
Fingerprint Reset on Reboot (If Present)	Reset/clear the fingerprint reader ownership (select models only; disabled by default).
Allow Reset of HP ProtectTools security keys	Enable/disable reset of HP ProtectTools security keys (disabled by default).
Change Password	Enter, change, or delete a BIOS administrator password.
HP SpareKey Enrollment	Enroll or reset HP SpareKey, which is a set of security questions and answers used if you forget your password.
DriveLock Passwords	• Enable/disable DriveLock on any computer hard drive (enabled by default). • Change a DriveLock user password or master password. NOTE: DriveLock settings are accessible only when you enter Computer Setup by turning on (not restarting) the computer.
Automatic DriveLock	Enable/disable Automatic DriveLock support.
Disk Sanitizer	Run Disk Sanitizer to destroy all existing data on the primary hard drive or the drive in the upgrade bay. CAUTION: If you run Disk Sanitizer, the data on the selected drive is destroyed permanently.
System IDs	Enter a user-defined computer asset tracking number and ownership tag.

Diagnostics menu

Select	To do this
System Diagnostics menu	• System Information—Displays the following information: ◦ Identification information for the computer and the batteries in the system. ◦ Specification information for the processor, cache and memory size, system ROM, video revision, and keyboard controller version. • Start-up Test—Verifies the system components needed for starting the computer. • Run-In Test—Runs a comprehensive check on system memory. • Hard Disk Test—Runs a comprehensive self-test on any hard drive in the system.

System Configuration menu



NOTE: Some of the listed System Configuration options may not be supported by your computer.

Select	To do this
Language	Change the Computer Setup language.
Boot Options	• Set a Startup Menu delay (in seconds). • Enable/disable Custom Logo (disabled by default). • Enable/disable CD-ROM boot (enabled by default). • Enable/disable SD Card boot (enabled by default). • Enable/disable floppy boot (enabled by default). • Enable/disable PXE Internal NIC boot (enabled by default). • Set the Express Boot Popup Delay in seconds. • Set the boot order.
Device Configurations	• Enable/disable USB legacy support (enabled by default). When enabled, USB legacy support allows the following: ◦ Use of a USB mouse or keyboard in Computer Setup even when a Windows® operating system is not running. ◦ Startup from bootable USB devices, including a hard drive, diskette drive, or optical drive connected by a USB port to the computer. • Enable/disable fan always on while connected to an AC outlet (enabled by default). • Enable/disable Data Execution Prevention. When enabled, the processor can disable some virus code execution, which helps to improve computer security (enabled by default). • SATA (Serial Advanced Technology Attachment) device mode. The following options are available: ◦ AHCI (Advanced Host Controller Interface) ◦ IDE (Integrated Drive Electronics) ◦ RAID (select models only) NOTE: Availability of the options above varies by computer model. • Enable/disable HP QuickLook 2 (enabled by default). • Enable/disable Virtualization Technology (disabled by default).

Select	To do this
	• Enable/disable Dual Core CPU (select models only; enabled by default). • Enable/Disable Unified Extensible Firmware Interface (UEFI) boot mode (disabled by default).
Built-In Device Options	• Enable/disable the wireless button state (enabled by default). • Enable/disable the embedded WLAN device (enabled by default). • Enable/disable embedded Bluetooth® device radio (enabled by default). • Enable/disable the Network Interface Controller (LAN) (enabled by default). • Enable/disable LAN/WLAN switching (disabled by default). • Set the wake on LAN state. Options include the following: ◦ Disabled ◦ Boot to Network (set by default) ◦ Follow Boot Order • Enable/disable the optical disc drive (select models only; enabled by default). • Enable/disable the fingerprint device (select models only; enabled by default). • Enable/disable the integrated camera (enabled by default). • Enable/disable a modem device (select models only; enabled by default). • Enable/disable the microphone (enabled by default).
Port Options (all are enabled by default)	NOTE: All port options are enabled by default. • Enable/disable the flash media reader. • Enable/disable the USB port. CAUTION: Disabling the USB port also disables MultiBay devices and ExpressCard devices on the advanced port replicator. • Enable/disable the ExpressCard slot.
Set Security Level	Change, view, or hide security levels for all BIOS menu items.
Restore Security Defaults	Restore the default security settings.

Index

B

- BIOS administrator password 7
- boot options 9
- boot order 9
- built-in device
 - Bluetooth device radio 10
 - embedded WLAN 10
 - fingerprint reader 10
 - integrated camera 10
 - LAN/WLAN switching 10
 - microphone 10
 - modem 10
 - Network Interface Controller (LAN) 10
 - optical disc drive 10
 - Wake on LAN 10
 - wireless button 10
- built-in device options 10

C

- Computer Setup
 - accessing 1
 - Diagnostics menu 8
 - File menu 6
 - navigating and selecting 3
 - restoring factory settings 4
 - Security menu 7
 - System Configuration menu 9
 - using 2

D

- device configurations 9
- Diagnostics menu 8
- Disk Sanitizer 7
- DriveLock password 7
- DriveLock, automatic 7
- drives, boot order 9
- Dual Core CPU 10

E

- Execution Disable 9

F

- File menu 6

H

- hard disk test 8
- HP QuickLook 2 9
- HP SpareKey enrollment 7

L

- language, changing in Computer Setup 9
- legacy support, USB 1, 9

P

- passwords 7
- port options
 - ExpressCard slot 10
 - flash media reader 10
 - USB port 10

R

- RAID (Redundant Array of Independent Disks) devices 9
- restore security defaults 10
- restore the factory settings 6
- run-in test 8

S

- SATA (Serial Advanced Technology Attachment) devices
 - AHCI (Advanced Host Controller Interface) 9
 - IDE (Integrated Drive Electronics) 9
- Security menu
 - allow reset of HP ProtectTools security keys 7

- always prompt for HP SpareKey enrollment 7
- Automatic DriveLock 7
- change password 7
- Disk Sanitizer 7
- DriveLock 7
- fingerprint reader reset 7
- HP Sparekey 7
- HP Sparekey enrollment 7
- password policy 7
- set up BIOS administrator password 7
- System IDs 7
- user management 7
- set security level 10
- setup utility
 - accessing 1
 - Diagnostics menu 8
 - File menu 6
 - navigating and selecting 3
 - restoring factory settings 4
 - Security menu 7
 - System Configuration menu 9
 - using 2
- start-up test 8
- System Configuration menu 9
- system date and time 6
- System Diagnostics menu 8
- system fan 9
- system IDs 7
- system information 6

U

- Unified Extensible Firmware Interface (UEFI) mode 10
- USB legacy support 1, 9

V

- Virtualization Technology 9

