



LaserJet Pro M501 Getting Started Guide



English..... 1

עברית 4

! IMPORTANT:

Follow **Steps 1 - 2** on the printer hardware setup poster, and then continue with **Step 3**.



www.hp.com/support/ljM501



www.register.hp.com

3. Set up the control panel

After turning on the printer, wait for it to initialize. To navigate the control panel, use the arrow buttons and the **OK** button. Follow the prompts on the control panel to configure these settings:

- Language
- Location
- Default Settings

Under **Default Settings** select one of these options:

- **Self-managed:** Optimized default settings for most users that include guided setup and configuration steps and automatic updates.
- **IT-managed:** Optimized default settings for fleet manageability.

Settings are fully customizable after initial setup.

NOTE: Select **Print Information Sheet** to print a page that instructs how to change the default settings.

4. Select the connection method



USB connection directly between the printer and the computer

Use an A-to-B type USB cable (not included with all models).

Windows

1. Do not connect the USB cable before installing the software. If the cable is already connected, disconnect it before continuing. The installation process prompts to connect the cable at the appropriate time.

2. Continue with [“5. Locate or download the software installation files”](#)

NOTE: During software installation, select the option to **Directly connect this computer using a USB cable**. (Windows only)

Mac

1. For Mac, connect the USB cable between the computer and the printer before installing the software.
2. Continue with [“5. Locate or download the software installation files”](#)



Wired (Ethernet) network connection

Use a standard network cable. (Cable not included.)

1. Connect the network cable to the printer and to the network. Wait a few minutes for the printer to acquire a network address.
2. On the control panel, view the display while it is in the Ready state. If an IP address is listed, the network connection has been established. If not, wait a few more minutes and try again. Note the IP address for use during software installation. **Example IP address:** 192.168.0.1

To manually configure the IP address, see [“Manually configure the IP address.”](#)

3. Continue with [“5. Locate or download the software installation files”](#)
- NOTE:** During software installation, select the option to **Connect through a network**. (Windows only).

Manually configure the IP address

See the printer user guide for information on how to manually configure the IP address. See the [“Troubleshooting”](#) section of this guide.



J8H60-90994

5. Locate or download the software installation files



Download from the Web

HP Easy Start

1. Go to 123.hp.com.
2. Select **HP LaserJet Printers**, and then click **Begin**.
3. Follow the on-screen instructions. Follow the prompts to save the file to the computer.
4. Launch the software file from the folder where the file was saved, and continue with “6. Install the software.”

Product support Web site

1. Go to www.hp.com/support/ljm501.
2. Under **Download options**, click **drivers, software, & firmware**, and then select the appropriate operating system.
3. From **Driver - Product Installation Software**, determine which software option to use, and then click the **Download** button next to it. Follow the prompts to save the file to the computer.
4. Launch the software file from the folder where the file was saved, and continue with “6. Install the software.”



Install from the printer CD

For Windows, the software installation files are provided on the CD that came with the printer.

For OS X, the file on the CD includes a link to download the files from the Web.

1. Insert the printer CD into the computer.
2. Continue with “6. Install the software.”

Install notes

For more details about the software for the printer, see the install notes file on the printer CD.

6. Install the software

Windows solution

1. The software installer detects the language of the operating system, and then it displays the main menu of the installation program in the same language. When installing from the CD, if the installer program does not start after 30 seconds, browse the CD drive on the computer and launch the file named SETUP.EXE.
2. The **Software Selection** screen details the software to be installed.
 - The recommended software installation includes the print driver and software for all available printer features.
 - To customize the software installed, click the **Customize software selections** link. When finished, click the **Next** button.
3. Follow the on-screen instructions to install the software.
4. When prompted to select a connection type, select the appropriate option for the type of connection:
 - **Directly connect this computer using a USB cable**
 - **Connect through a network**



NOTE: When connecting through a network, the easiest way to detect the printer is to select **Automatically find my printer on the network**.



NOTE: For wireless installation, select the option to **Help me set up a first-time wireless connection**, and then select **Yes, retrieve the wireless settings on my computer**.

OS X solution

1. The software installer detects the language of the operating system, and then it displays the main menu of the installation program in the same language.
2. Follow the on-screen instructions to install the software. When prompted, connect the printer using the appropriate cable for the connection.
3. At the end of the software installation process, use the **HP Utility Setup Assistant** to configure printer options.

Install notes

Not all software components are available for all operating systems. For more information, see the install notes file on the printer CD.



7. Set up mobile printing (optional)

To print from a phone or tablet, connect the device to the same network as the printer.

Apple iOS devices (AirPrint): Open the item to print, and select the **Action** icon. Select **Print**, select the printer, and then select **Print**.

Newer Android devices (4.4 or newer): Open the item to print, and select the **Menu** button. Select **Print**, select the printer, and select **Print**.

Some devices require downloading the HP Print Service plugin app from the Google Play store.

Older Android devices (4.3 or older): Download the HP ePrint app from the Google Play store.

Windows Phone: Download the HP AiO Remote app from the Windows Store.



NOTE: Printing from a wireless device requires a wireless network connection.

Learn more about mobile printing

To learn more about other mobile printing options, including additional ePrint solutions, scan the QR code, or see the “Mobile printing” section of the user guide.





8. Set up HP ePrint via email (optional)

Use HP ePrint via email to print documents by sending them as an email attachment to the printer's email address from any email-enabled device, even from devices that are not on the same network.

To use HP ePrint via email, the printer must meet these requirements:

- The printer must be connected to a wired network and have Internet access.
- HP Web Services must be enabled on the printer, and the printer must be registered with HP Connected.

Enable HP Web Services

 **NOTE:** Before enabling HP Web Services, verify that the printer is connected to a network. Also, verify that HP Web Services was not enabled during the initial printer setup.

1. Press the **OK** button.
2. Open the **HP Web Services** menu.
3. Select **Print Information Sheet**. The printer will print the page.

4. Open the HP Embedded Web Server. Go to a network-connected computer, open a browser window, and type the IP address shown on the information sheet in the address box, and then press **ENTER**.

 **NOTE:** The HP EWS provides access to many other advanced printer settings as well.

5. In the HP Embedded Web Server, click the **HP Web Services** tab.
6. Click the **Enable** button.
The printer enables Web Services. The information page contains a printer code necessary to register the HP printer at HP Connected.
7. Go to www.hpconnected.com to create an HP ePrint account and complete the setup process.

Troubleshooting

User guide

The user guide includes printer usage and troubleshooting information. It is available on the printer CD and on the Web:

1. Go to www.hp.com/support/ljM501.
2. Click **Manuals**.

For Windows, the user guide is copied to the computer during the recommended software installation.

Windows® XP, Windows Vista®, Windows® 7, and Windows® 10: Click **Start**, select **Programs, All Programs**, or **All Apps**, select **HP**, select the folder for the HP printer, and then select **Help**.

Windows® 8:

On the **Start** screen, right-click an empty area on the screen, click **All Apps** on the app bar, click the icon with the printer's name, and then select **Help**.

Check for firmware updates

1. On the printer control panel, press the **OK** button.
2. Open the **Service** menu.
3. Select **LaserJet Update**.
4. Select **Check for Updates Now**.

Additional support resources

For HP's all-inclusive help for the printer, go to www.hp.com/support/ljM501:

- Solve problems
- Find advanced configuration instructions
- Download software updates
- Join support forums
- Find warranty and regulatory information
- Access mobile printing resources



Wired (Ethernet) network connection

- Verify that the printer is attached to the correct network port using a cable of the correct length.
- Verify that the lights next to the network port are lit.
- Verify that the print driver is installed on the computer.
- Test the network connection by pinging the printer:
 - Windows:** Click **Start > Run**. Type **cmd**, and press **ENTER**. Type **ping**, type a space, type the printer IP address, and then press **ENTER**. **Example IP address:** 192.168.0.1
 - OS X:** Open the Network Utility, and type the IP address in the **ping** pane. Press **ENTER**. **Example IP address:** 192.168.0.1
- If the window displays round-trip times, the network is working.
- If the ping does not work, try restarting the printer and recheck all of the connection steps.

מדריך תחילת העבודה של LaserJet Pro M501


www.hp.com/support/ljM501

www.register.hp.com
חשוב:

בצע את שלבים 1 - 2

בפוסטר הגדרת החומרה של המדפסת, ולאחר מכן המשך לשלב 3.

3. הגדר את לוח הבקרה.

לאחר הפעלת המדפסת, המתן לאתחול המדפסת. כדי לנווט בלוח הבקרה, השתמש בלחצני החצים ובלחצן **OK**. מלא אחר ההנחיות בלוח הבקרה כדי לקבוע את התצורה של ההגדרות הבאות:

- Language (שפה)
- Location (מיקום)
- Default Settings (הגדרות ברירת מחדל) בחר אחת מהאפשרויות הבאות:
- **Self-managed (ניהול עצמי):** הגדרות ברירת מחדל ממוטבות עבור רוב המשתמשים, הכוללות שלבים מונחים להגדרה ועדכוני אוטומטיים.
- **IT-managed (ניהול IT):** הגדרות ברירת מחדל ממוטבות ליכולת ניהול של צי כלים. ההגדרות ניתנות להתאמה אישית מלאה לאחר ההגדרה הראשונית.
- **הערה:** בחר באפשרות **Print Information Sheet** (הדפס גיליון מידע) כדי להדפיס את הדף המנחה אותך כיצד לשנות את הגדרות ברירת המחדל.



4. בחר את שיטת החיבור

חיבור רשת קווית (Ethernet)

השתמש בכבל רשת רגיל. (הכבל אינו כלול).

1. חבר את כבל הרשת למדפסת ולרשת. המתן כמה דקות עד שהמדפסת תקבל כתובת רשת.
2. בלוח הבקרה, בדוק את התצוגה כאשר היא במצב 'מוכן'. אם מופיעה כתובת IP, נוצר חיבור רשת. אם לא, המתן עוד כמה דקות ונסה שוב. שים לב לכתובת ה-IP שבה יש להשתמש במהלך התקנת התוכנה.
כתובת IP לדוגמה: 192.168.0.1
כדי לקבוע באופן ידני את התצורה של כתובת ה-IP, ראה "קביעת תצורה ידנית של כתובת ה-IP".
3. המשך לשלב "5. אתר או הורד את קובצי התקנת התוכנה"
הערה: במהלך התקנת התוכנה, בחר את האפשרות **חיבור באמצעות רשת**. (Windows בלבד).

חיבור USB ישיר בין המדפסת למחשב

השתמש בכבל USB מסוג A ל-B (לא כלול עם כל הדגמים).

Windows

1. אל תחבר את כבל ה-USB לפני התקנת התוכנה. אם הכבל מחובר כבר, נתק אותו לפני שתמשיך. תהליך ההתקנה מנחה את המשתמש לחבר את הכבל ברגע המתאים.
2. המשך לשלב "5. אתר או הורד את קובצי התקנת התוכנה"

הערה: במהלך התקנת התוכנה, בחר את האפשרות **התחברות ישירות למחשב זה באמצעות כבל USB**. (Windows בלבד)

Mac

1. עבור Mac, חבר את כבל ה-USB בין המחשב למדפסת לפני התקנת התוכנה.
2. המשך לשלב "5. אתר או הורד את קובצי התקנת התוכנה".

קביעת תצורה ידנית של כתובת ה-IP

עיין במדריך למשתמש של המדפסת לקבלת מידע על קביעת תצורה ידנית של כתובת ה-IP. עיין בסעיף "פתרון בעיות" במדריך זה.

5. אתר או הורד את קובצי התקנת התוכנה

הורדה מהאינטרנט

HP Easy Start

1. עבור לכתובת 123.hp.com.
2. בחר **HP LaserJet Printers**, ולאחר מכן לחץ על **התחל**.
3. פעל בהתאם להוראות שעל-גבי המסך. פעל בהתאם להוראות המופיעות כדי לשמור את הקובץ במחשב.
4. הפעל את קובץ התוכנה מהתיקייה שבה הקובץ נשמר והמשך לשלב "6. התקנת התוכנה".

אתר תמיכה במוצר

1. עבור לכתובת www.hp.com/support/ljM501.
2. תחת **Download options** (אפשרויות הורדה), לחץ על **drivers, software, & firmware** (מנהלי התקן, תוכנה וחומרה), ולאחר מכן בחר את מערכת ההפעלה המתאימה.
3. בקטע **Driver - Product Installation Software** (מנהל התקן - תוכנת ההתקנה של המוצר), החלט באיזו אפשרות תוכנה ברצונך להשתמש, ולאחר מכן לחץ על הלחצן **Download** (הורד) (הסמך). פעל בהתאם להוראות המופיעות כדי לשמור את הקובץ במחשב.
4. הפעל את קובץ התוכנה מהתיקייה שבה הקובץ נשמר והמשך לשלב "6. התקנת התוכנה".

התקנה מתקליטור המדפסת

- עבור Windows, קובצי התקנת התוכנה כלולים בתקליטור המצורף למדפסת. עבור OS X, הקובץ שבתקליטור כולל קישור להורדת הקבצים מהאינטרנט.
1. הכנס את תקליטור המדפסת למחשב.
 2. המשך לשלב "6. התקנת התוכנה".

הערות התקנה

לקבלת פרטים נוספים אודות התוכנה עבור המדפסת, עיין בקובץ הערות ההתקנה בתקליטור המדפסת.

6. התקנת התוכנה

פתרון ב-Windows

1. תוכנית ההתקנה של התוכנה מזהה את שפת מערכת ההפעלה, ולאחר מכן מציגה את התפריט הראשי של תוכנית ההתקנה באותה השפה. בזמן ההתקנה מהתקליטור, אם תוכנית ההתקנה אינה מתחילה לפעול לאחר 30 שניות, בוטל אל כונן התקליטור במחשב והפעל את הקובץ ששמו **SETUP.EXE**.
2. המסך **Software Selection** (בחירת תוכנה) מפרט את התוכנה שיש להתקין.
 - התקנת התוכנה המומלצת כוללת את מנהל ההדפסה ואת התוכנה לכל מאפייני המדפסת הזמינים.
 - כדי להתאים אישית את התוכנה המותקנת, לחץ על הקישור **Customize software selections** (התאמה אישית של בחירות תוכנה). עם סיום ההתקנה, לחץ על לחצן **Next** (הבא).
3. התקן את התוכנה בהתאם להוראות המופיעות על המסך.
4. כאשר תתבקש לבחור סוג חיבור, בחר את האפשרות המתאימה עבור סוג החיבור:

- **Directly connect this computer using a USB cable** (התחברות ישירות למחשב זה באמצעות כבל USB)
- **Connect through a network** (חיבור באמצעות רשת)

הערה: בזמן החיבור לרשת, הדרך הקלה ביותר לזהות את המדפסת היא לבחור באפשרות **Automatically find my printer on the network** (חפש באופן אוטומטי את המדפסת שלי ברשת).

הערה: להתקנה אלחוטית, בחר את האפשרות **Help me set up a first-time wireless connection** (עזור לי להגדיר חיבור אלחוטי בפעם הראשונה), ולאחר מכן בחר באפשרות **Yes, retrieve the wireless settings on my computer** (כן, אחזר את הגדרות האלחוט במחשב שלי).

פתרון ב-OS X

1. תוכנית ההתקנה של התוכנה מזהה את שפת מערכת ההפעלה, ולאחר מכן מציגה את התפריט הראשי של תוכנית ההתקנה באותה השפה.
2. התקן את התוכנה בהתאם להוראות המופיעות על המסך. כאשר תתבקש לעשות זאת, חבר את המדפסת באמצעות הכבל המתאים לחיבור.
3. עם סיום תהליך התקנת התוכנה, השתמש ב-**HP Utility Setup Assistant** (מסייע התקנת HP Utility) כדי להגדיר אפשרויות מדפסת.

הערות התקנה

לא כל רכיבי התוכנה זמינים עבור כל מערכות ההפעלה. לקבלת מידע נוסף, עיין בקובץ הערות ההתקנה שבתקליטור המדפסת.

7. הגדרת הדפסה ממכשירים ניידים (אופציונלי)

- להדפסה מטלפון או מטאבלט, חבר את ההתקן לאותה רשת שאליה מחוברת המדפסת.
- הערה:**  הדפסה מהתקן אלחוטי מחייבת חיבור רשת אלחוטית.
- התקני Apple iOS (AirPrint):** פתח את הפריט להדפסה ובחר בסמל **Action** (פעולה). בחר באפשרות **Print** (הדפסה), בחר את המדפסת ולאחר מכן בחר באפשרות **Print** (הדפס).
- התקני Android חדשים יותר (4.4 ואילך):** פתח את הפריט להדפסה ובחר בלחצן **Menu** (תפריט). בחר באפשרות **Print** (הדפסה), בחר את המדפסת ובחר באפשרות **Print** (הדפסה).
- התקנים מסוימים דורשים התקנה של יישום ה-Plugin של HP Print Service מחנות האפליקציות Google Play.
- התקני Android ישנים יותר (4.3 ומטה):** הורד את האפליקציה HP ePrint מחנות האפליקציות Google Play.
- Windows Phone:** הורד את האפליקציה HP AiO Remote מחנות Windows.

מידע נוסף על הדפסה ניידת

כדי ללמוד עוד על אפשרויות אחרות להדפסה ניידת, לרבות פתרונות ePrint נוספים, סרוק את קוד QR או עיין בסעיף "הדפסה ניידת" במדריך למשתמש.



8. הגדרת HP ePrint דרך דוא"ל (אופציונלי)

השתמש ב-HP ePrint דרך דוא"ל כדי להדפיס מסמכים על-ידי שליחתם כקובץ מצורף לדוא"ל אל כתובת הדוא"ל של המדפסת, מכל התקן התומך בדוא"ל, אפילו מהתקנים שאינם מחוברים לאותה רשת.

- כדי להשתמש ב-HP ePrint דרך דוא"ל, על המדפסת לעמוד בדרישות הבאות:
- המדפסת צריכה להיות מחוברת לרשת קווית ודרושה לה גישה לאינטרנט.
 - יש לוודא כי HP Web Services זמין במדפסת, ויש לרשום את המדפסת באמצעות HP Connected.

הפעלת HP Web Services

הערה: לפני שתפעיל את HP Web Services, ודא שהמדפסת מחוברת לרשת. כמו כן, ודא ש-HP Web Services לא הופעלו במהלך ההגדרה הראשונית של המדפסת.

1. לחץ על הלחצן **OK**.
2. פתח את התפריט **HP Web Services**.
3. בחר **Print Information Sheet** (הדפס דף מידע). המדפסת תדפיס את הדף.

4. פתח את שרת האינטרנט המשובץ של HP. עבור למחשב המחובר לרשת, פתח חלון דפדפן והקלד בתיבת הכתובת את כתובת ה-IP המופיעה בגיליון המידע. לאחר מכן, הקש **ENTER**.
- הערה:**  שרת האינטרנט המשובץ של HP מספק גישה גם להגדרות מדפסת מתקדמות רבות אחרות.
5. בשרת האינטרנט המשובץ של HP, לחץ על הכרטיסייה **HP Web Services**.
6. לחץ על הלחצן **Enable** (הפעל). המדפסת מפעילה את Web Services. דף המידע מכיל קוד מדפסת שהנו נחוץ כדי לרשום את המדפסת של HP שברשותך ב-HP Connected.
7. עבור לכתובת www.hpconnected.com כדי ליצור חשבון HP ePrint ולהשלים את תהליך ההתקנה.

מדריך למשתמש

המדריך למשתמש כולל פרטים אודות השימוש במדפסת ופתרון בעיות. הוא זמין בתקליטור המדפסת ובאינטרנט:

1. עבור לכתובת www.hp.com/support/ljM501.

2. לחץ על **Manuals** (מדריכים למשתמש).

עבור Windows, המדריך למשתמש מועתק אל המחשב במהלך התקנת התוכנה המומלצת.

Windows® XP, Windows Vista®, Windows 7, Windows® 10:

לחץ על **התחל**, בחר **תוכניות**, **כל התוכניות** או **כל האפליקציות**, בחר **HP**, בחר את התיקיה עבור מדפסת HP, ולאחר מכן בחר **עזרה**.

Windows® 8:

במסך **התחל**, לחץ לחיצה ימנית על אזור ריק במסך, לחץ על **כל**

האפליקציות, בסרגל האפליקציות, לחץ על הסמל עם שם המדפסת, ולאחר מכן בחר באפשרות **עזרה**.

בדיקה של עדכוני קושחה

1. בלוח הבקרה של המדפסת, לחץ על הלחצן **OK**.

2. פתח את התפריט **Service** (שירותים).

3. בחר באפשרות **LaserJet Update** (עדכון LaserJet).

4. בחר באפשרות **Check for Updates Now** (בדוק עדכונים כעת).

משאבי תמיכה נוספים

לקבלת עזרה כוללת של HP עבור המדפסת, עבור לכתובת www.hp.com/support/ljM501

- פתור בעיות
- חפש הוראות לתצורה מתקדמת
- הורד עדכוני תוכנה
- הצטרף לפורומי תמיכה
- חפש מידע על אחריות ותקינה
- גישה למשאבי הדפסה ביידת

חיבור רשת קווית (Ethernet)



• ודא שהמוצא מחובר ליציאת הרשת הנכונה באמצעות כבל באורך הנכון.

• ודא שהנורות שליד יציאת הרשת דולקות.

• ודא שמנהל ההדפסה מותקן במחשב.

• בדוק את החיבור לרשת על-ידי שליחת Ping (איתות) למדפסת:

Windows: לחץ על **התחל** < **הפעל**. הקלד **cmd**, והקש **ENTER**. הקלד **ping**,

הקלד רווח, הקלד את כתובת ה-IP של המדפסת, ולאחר מכן הקש **ENTER**.

כתובת IP לדוגמה: 192.168.0.1

OS X: פתח את כלי השירות של הרשת, והקלד את כתובת ה-IP בחלונת

ping. הקש **ENTER**. **כתובת IP לדוגמה:** 192.168.0.1

- אם החלון מציג זמני מעבר הלון ושוב, הרשת פועלת.
- אם פעולת ה-ping אינה פועלת, נסה להפעיל מחדש את המדפסת ולבדוק מחדש את כל שלבי החיבור.

© Copyright 2016 HP Development Company, L.P.

Reproduction, adaptation or translation without prior written permission is prohibited, except as allowed under the copyright laws.

The information contained herein is subject to change without notice.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Trademark Credits

Windows® is a U.S. registered trademark of Microsoft Corporation.

OS X is a trademark of Apple Inc., registered in the U.S. and other countries.

AirPrint is a trademark of Apple Inc., registered in the U.S. and other countries.

FCC Regulations

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio-frequency energy. If this equipment is not installed and used in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase separation between equipment and receiver.
- Connect equipment to an outlet on a circuit different from that to which the receiver is located.
- Consult your dealer or an experienced radio/TV technician.

Any changes or modifications to the product that are not expressly approved by HP could void the user's authority to operate this equipment. Use of a shielded interface cable is required to comply with the Class A limits of Part 15 of FCC rules. For more regulatory information, see the electronic user guide. HP shall not be liable for any direct, indirect, incidental, consequential, or other damage alleged in connection with the furnishing or use of this information.

www.hp.com



www.hp.com/support

