

Interactive Part Locator

HP ENVY x360 15-eu0xxx Convertible PC

Welcome to the interactive part locator for the
HP ENVY x360 15-eu0xxx Convertible PC

Here's how to use it...

[External Views](#) (Click the link to navigate to the views)

On this page you will find large icons of each of the external views of this product. To view a specific view in greater detail, simply click that view.

[Parts List](#) (Click the link to navigate to the parts)

On this page, you will find a list of all of the replaceable parts for this product. To view a specific part and its location in the product, click the part name in the list.

That's it! On every page there is a link that brings you back to either the External Views or the Parts List, enabling you to navigate to whatever view or part you wish to review.

External Views

Front

Left

Right

Rear


Internal

Parts List


Front View



Left View



Right View



Rear View




Internal View 1



Internal View 2

DC-in Connector



IR Sensor Board


Motherboard

Memory Modules



Touchpad Board

Base Enclosure


Base Enclosure




Battery




Memory Module(s)




Wireless LAN Module





M.2 Solid State Drive




Speakers




CPU Fan




GPU Fan




Heatsink




Touchpad Board




DC-in Connector



IR Sensor Board



Motherboard



Top Cover



Top Cover

Display Panel Assembly

Display Panel Assembly




Display Panel

Display Panel



Display Panel Hinges



Hinge Caps



Webcam

