HP CM8060/CM8050 Color MFP with Edgeline Technology – Security

How do I	Steps to perform
1 Set the device administrator password	a. Open the embedded Web server (EWS). b. Select the **Settings** tab, and then select **General Security** from the menu on the left side of the screen. c. In the **Set Password** area, type the new password in the boxes labeled **New Password** and **Verify Password**. If you have already set up a password, type the old password in the **Old Password** box. d. Click **Apply**.
2 Lock the administrator tools section of the startup menu	a. Press the **on/off** button on the device control panel to turn the device off, and then press it again to turn the device on. b. While the device is initializing, watch the control-panel display. When the white HP logo appears on the black background, press the **Stop** button. c. Press **8** to move the highlight to **Administrator Tools**. Press **5** to select it. d. Press **8** to move the highlight to **Change Administrator Password**. Press **5** to select it. e. A prompt to enter a new password appears. Use the numeric keypad to type the password. A second prompt appears so you can confirm the password. Type the password again. f. Press **Start** to save the password.
3 Access the administrator tools section of the startup menu	a. After opening the startup menu, press **8** to move the highlight to **Sign In**. Press **5** to select it. b. A prompt to enter the password appears. Use the numeric keypad to type the password. c. Press **Start** to enter the password. The **Administrator Tools** option should now be available. d. Press **8** to move the highlight to **Administrator Tools**. Press **5** to select it.



©2007 Copyright Hewlett-Packard Development Company, L.P.

HP CM8060/CM8050 Color MFP with Edgeline Technology – Security

How do I	Steps to perform
4 Disable printing through a direct connection	a. Open the embedded Web server (EWS). b. Select the **Settings** tab, and then select **General Security** from the menu on the left side of the screen. c. In the area for **Direct Ports**, select **Disable Direct Ports**. d. Click **Apply**. The device automatically turns off and then on.
5 Disable printing from the embedded Web server (EWS)	a. Open the embedded Web server (EWS). b. Select the **Settings** tab, and then select **General Security** from the menu on the left side of the screen. c. In the area for **Set Options**, clear the check box next to **Display Print Page on Information Tab**.
6 Restrict users from sending e-mail to accounts other than their own	a. Open the embedded Web server (EWS). b. Select the **Digital Sending** tab, and then select **E-mail Setup** from the menu on the left side of the screen. c. In the area for **Default Message Settings**, select **Restrict users from editing all address fields**. Configure the E-mail feature so that users must sign in to use it. d. Click **Apply**.
7 Control access to the device	a. Open the embedded Web server (EWS). b. Select the **Settings** tab. c. Select **Device Sign In** from the menu on the left side of the screen. d. On the **Device Access** tab, specify the level of control you want.



©2007 Copyright Hewlett-Packard Development Company, L.P.