Interactive Part Locator

HP ENVY x360 15-ed0000 Convertible PC/HP ENVY x360 15-ee0000 Convertible PC

Welcome to this interactive part locator

Here's how to use it...

External Views (Click the link to navigate to the views)
On this page you will find large icons of each of the external views of this product. To view a specific view in greater detail, simply click that view.

Parts List (Click the link to navigate to the parts)
On this page, you will find a list of all of the replaceable parts for this product. To view a specific part and its location in the product, click the part name in the list.

That's it! On every page there is a link that brings you back to either the External Views or the Parts List, enabling you to navigate to whatever view or part you wish to review.

External Views

Back to Welcome page

Front

Left

Right

Rear

Display

Top

Bottom

Internal

Go to Parts List

Front View

Back to External Views

Go to Parts List

Left View

Back to External Views



Go to Parts List

Right View

Back to External Views



Go to Parts List

Rear View

Back to External Views



Go to Parts List

Display View

Back to External Views



Go to Parts List

Top View

Back to External Views



Go to Parts List

Bottom View

Back to External Views



Go to Parts List

Internal View

Back to External Views



Go to Parts List

Base Enclosure

Base Enclosure
Battery
Speaker Assembly
M.2 Solid State Drive
Wireless LAN Module
Touchpad Board
Memory Module(s)
Fans
Heat Sink (Discrete)
Heat Sink (UMA)
Rear Speaker
IR Board
DC-in Connector
System Board (Discrete Top)
System Board (Discrete Bottom)
System Board (UMA Top)
System Board (UMA Bottom)
Top Cover with Keyboard
Display Panel Assembly
Display Panel
Display Panel Cable
Touch Control Board
Touch Control Board Cable
Webcam
Hinges
Hinge Caps
Wireless LAN Antennas
Display Enclosure

Go to External Views

Battery

Base Enclosure
Battery
Speaker Assembly
M.2 Solid State Drive
Wireless LAN Module
Touchpad Board
Memory Module(s)
Fans
Heat Sink (Discrete)
Heat Sink (UMA)
Rear Speaker
IR Board
DC-in Connector
System Board (Discrete Top)
System Board (Discrete Bottom)
System Board (UMA Top)
System Board (UMA Bottom)
Top Cover with Keyboard
Display Panel Assembly
Display Panel
Display Panel Cable
Touch Control Board
Touch Control Board Cable
Webcam
Hinges
Hinge Caps
Wireless LAN Antennas
Display Enclosure

Go to External Views

Speaker Assembly

Base Enclosure
Battery
Speaker Assembly
M.2 Solid State Drive
Wireless LAN Module
Touchpad Board
Memory Module(s)
Fans
Heat Sink (Discrete)
Heat Sink (UMA)
Rear Speaker
IR Board
DC-in Connector
System Board (Discrete Top)
System Board (Discrete Bottom)
System Board (UMA Top)
System Board (UMA Bottom)
Top Cover with Keyboard
Display Panel Assembly
Display Panel
Display Panel Cable
Touch Control Board
Touch Control Board Cable
Webcam
Hinges
Hinge Caps
Wireless LAN Antennas
Display Enclosure



Go to External Views

M.2 Solid State Drive

Base Enclosure
Battery
Speaker Assembly
M.2 Solid State Drive
Wireless LAN Module
Touchpad Board
Memory Module(s)
Fans
Heat Sink (Discrete)
Heat Sink (UMA)
Rear Speaker
IR Board
DC-in Connector
System Board (Discrete Top)
System Board (Discrete Bottom)
System Board (UMA Top)
System Board (UMA Bottom)
Top Cover with Keyboard
Display Panel Assembly
Display Panel
Display Panel Cable
Touch Control Board
Touch Control Board Cable
Webcam
Hinges
Hinge Caps
Wireless LAN Antennas
Display Enclosure

Go to External Views

Wireless LAN Module

Base Enclosure
Battery
Speaker Assembly
M.2 Solid State Drive
Wireless LAN Module
Touchpad Board
Memory Module(s)
Fans
Heat Sink (Discrete)
Heat Sink (UMA)
Rear Speaker
IR Board
DC-in Connector
System Board (Discrete Top)
System Board (Discrete Bottom)
System Board (UMA Top)
System Board (UMA Bottom)
Top Cover with Keyboard
Display Panel Assembly
Display Panel
Display Panel Cable
Touch Control Board
Touch Control Board Cable
Webcam
Hinges
Hinge Caps
Wireless LAN Antennas
Display Enclosure

Go to External Views

Touchpad Board

Base Enclosure
Battery
Speaker Assembly
M.2 Solid State Drive
Wireless LAN Module
Touchpad Board
Memory Module(s)
Fans
Heat Sink (Discrete)
Heat Sink (UMA)
Rear Speaker
IR Board
DC-in Connector
System Board (Discrete Top)
System Board (Discrete Bottom)
System Board (UMA Top)
System Board (UMA Bottom)
Top Cover with Keyboard
Display Panel Assembly
Display Panel
Display Panel Cable
Touch Control Board
Touch Control Board Cable
Webcam
Hinges
Hinge Caps
Wireless LAN Antennas
Display Enclosure



Go to External Views

Memory Module(s)

Base Enclosure
Battery
Speaker Assembly
M.2 Solid State Drive
Wireless LAN Module
Touchpad Board
Memory Module(s)
Fans
Heat Sink (Discrete)
Heat Sink (UMA)
Rear Speaker
IR Board
DC-in Connector
System Board (Discrete Top)
System Board (Discrete Bottom)
System Board (UMA Top)
System Board (UMA Bottom)
Top Cover with Keyboard
Display Panel Assembly
Display Panel
Display Panel Cable
Touch Control Board
Touch Control Board Cable
Webcam
Hinges
Hinge Caps
Wireless LAN Antennas
Display Enclosure

Go to External Views

Base Enclosure
Battery
Speaker Assembly
M.2 Solid State Drive
Wireless LAN Module
Touchpad Board
Memory Module(s)
Fans
Heat Sink (Discrete)
Heat Sink (UMA)
Rear Speaker
IR Board
DC-in Connector
System Board (Discrete Top)
System Board (Discrete Bottom)
System Board (UMA Top)
System Board (UMA Bottom)
Top Cover with Keyboard
Display Panel Assembly
Display Panel
Display Panel Cable
Touch Control Board
Touch Control Board Cable
Webcam
Hinges
Hinge Caps
Wireless LAN Antennas
Display Enclosure

Go to External Views

Fans

* Note: The HP ENVY x360 15-ed0000 Convertible PC with UMA graphics will only have one fan.

Heat Sink (Discrete)

Base Enclosure
Battery
Speaker Assembly
M.2 Solid State Drive
Wireless LAN Module
Touchpad Board
Memory Module(s)
Fans
Heat Sink (Discrete)
Heat Sink (UMA)
Rear Speaker
IR Board
DC-in Connector
System Board (Discrete Top)
System Board (Discrete Bottom)
System Board (UMA Top)
System Board (UMA Bottom)
Top Cover with Keyboard
Display Panel Assembly
Display Panel
Display Panel Cable
Touch Control Board
Touch Control Board Cable
Webcam
Hinges
Hinge Caps
Wireless LAN Antennas
Display Enclosure

Go to External Views

Heat Sink (UMA)

Base Enclosure
Battery
Speaker Assembly
M.2 Solid State Drive
Wireless LAN Module
Touchpad Board
Memory Module(s)
Fans
Heat Sink (Discrete)
Heat Sink (UMA)
Rear Speaker
IR Board
DC-in Connector
System Board (Discrete Top)
System Board (Discrete Bottom)
System Board (UMA Top)
System Board (UMA Bottom)
Top Cover with Keyboard
Display Panel Assembly
Display Panel
Display Panel Cable
Touch Control Board
Touch Control Board Cable
Webcam
Hinges
Hinge Caps
Wireless LAN Antennas
Display Enclosure



HP ENVY x360 15-ed0000



HP ENVY x360 15-ee0000

Go to External Views

Rear Speaker

Base Enclosure
Battery
Speaker Assembly
M.2 Solid State Drive
Wireless LAN Module
Touchpad Board
Memory Module(s)
Fans
Heat Sink (Discrete)
Heat Sink (UMA)
Rear Speaker
IR Board
DC-in Connector
System Board (Discrete Top)
System Board (Discrete Bottom)
System Board (UMA Top)
System Board (UMA Bottom)
Top Cover with Keyboard
Display Panel Assembly
Display Panel
Display Panel Cable
Touch Control Board
Touch Control Board Cable
Webcam
Hinges
Hinge Caps
Wireless LAN Antennas
Display Enclosure



Go to External Views

IR Board

Base Enclosure
Battery
Speaker Assembly
M.2 Solid State Drive
Wireless LAN Module
Touchpad Board
Memory Module(s)
Fans
Heat Sink (Discrete)
Heat Sink (UMA)
Rear Speaker
IR Board
DC-in Connector
System Board (Discrete Top)
System Board (Discrete Bottom)
System Board (UMA Top)
System Board (UMA Bottom)
Top Cover with Keyboard
Display Panel Assembly
Display Panel
Display Panel Cable
Touch Control Board
Touch Control Board Cable
Webcam
Hinges
Hinge Caps
Wireless LAN Antennas
Display Enclosure



Go to External Views

DC-in Connector

Base Enclosure
Battery
Speaker Assembly
M.2 Solid State Drive
Wireless LAN Module
Touchpad Board
Memory Module(s)
Fans
Heat Sink (Discrete)
Heat Sink (UMA)
Rear Speaker
IR Board
DC-in Connector
System Board (Discrete Top)
System Board (Discrete Bottom)
System Board (UMA Top)
System Board (UMA Bottom)
Top Cover with Keyboard
Display Panel Assembly
Display Panel
Display Panel Cable
Touch Control Board
Touch Control Board Cable
Webcam
Hinges
Hinge Caps
Wireless LAN Antennas
Display Enclosure



Go to External Views

System Board (Discrete Top)

Base Enclosure
Battery
Speaker Assembly
M.2 Solid State Drive
Wireless LAN Module
Touchpad Board
Memory Module(s)
Fans
Heat Sink (Discrete)
Heat Sink (UMA)
Rear Speaker
IR Board
DC-in Connector
System Board (Discrete Top)
System Board (Discrete Bottom)
System Board (UMA Top)
System Board (UMA Bottom)
Top Cover with Keyboard
Display Panel Assembly
Display Panel
Display Panel Cable
Touch Control Board
Touch Control Board Cable
Webcam
Hinges
Hinge Caps
Wireless LAN Antennas
Display Enclosure

Go to External Views



System Board (Discrete Bottom)

Base Enclosure
Battery
Speaker Assembly
M.2 Solid State Drive
Wireless LAN Module
Touchpad Board
Memory Module(s)
Fans
Heat Sink (Discrete)
Heat Sink (UMA)
Rear Speaker
IR Board
DC-in Connector
System Board (Discrete Top)
System Board (Discrete Bottom)
System Board (UMA Top)
System Board (UMA Bottom)
Top Cover with Keyboard
Display Panel Assembly
Display Panel
Display Panel Cable
Touch Control Board
Touch Control Board Cable
Webcam
Hinges
Hinge Caps
Wireless LAN Antennas
Display Enclosure

Go to External Views



System Board (UMA Top)

Base Enclosure
Battery
Speaker Assembly
M.2 Solid State Drive
Wireless LAN Module
Touchpad Board
Memory Module(s)
Fans
Heat Sink (Discrete)
Heat Sink (UMA)
Rear Speaker
IR Board
DC-in Connector
System Board (Discrete Top)
System Board (Discrete Bottom)
System Board (UMA Top)
System Board (UMA Bottom)
Top Cover with Keyboard
Display Panel Assembly
Display Panel
Display Panel Cable
Touch Control Board
Touch Control Board Cable
Webcam
Hinges
Hinge Caps
Wireless LAN Antennas
Display Enclosure

Go to External Views



System Board (UMA Bottom)

Base Enclosure
Battery
Speaker Assembly
M.2 Solid State Drive
Wireless LAN Module
Touchpad Board
Memory Module(s)
Fans
Heat Sink (Discrete)
Heat Sink (UMA)
Rear Speaker
IR Board
DC-in Connector
System Board (Discrete Top)
System Board (Discrete Bottom)
System Board (UMA Top)
System Board (UMA Bottom)
Top Cover with Keyboard
Display Panel Assembly
Display Panel
Display Panel Cable
Touch Control Board
Touch Control Board Cable
Webcam
Hinges
Hinge Caps
Wireless LAN Antennas
Display Enclosure

Go to External Views



Top Cover with Keyboard

Base Enclosure
Battery
Speaker Assembly
M.2 Solid State Drive
Wireless LAN Module
Touchpad Board
Memory Module(s)
Fans
Heat Sink (Discrete)
Heat Sink (UMA)
Rear Speaker
IR Board
DC-in Connector
System Board (Discrete Top)
System Board (Discrete Bottom)
System Board (UMA Top)
System Board (UMA Bottom)
Top Cover with Keyboard
Display Panel Assembly
Display Panel
Display Panel Cable
Touch Control Board
Touch Control Board Cable
Webcam
Hinges
Hinge Caps
Wireless LAN Antennas
Display Enclosure

Go to External Views

Display Panel Assembly

- Base Enclosure
- Battery
- Speaker Assembly
- M.2 Solid State Drive
- Wireless LAN Module
- Touchpad Board
- Memory Module(s)
- Fans
- Heat Sink (Discrete)
- Heat Sink (UMA)
- Rear Speaker
- IR Board
- DC-in Connector
- System Board (Discrete Top)
- System Board (Discrete Bottom)
- System Board (UMA Top)
- System Board (UMA Bottom)
- Top Cover with Keyboard
- **Display Panel Assembly**
- Display Panel
- Display Panel Cable
- Touch Control Board
- Touch Control Board Cable
- Webcam
- Hinges
- Hinge Caps
- Wireless LAN Antennas
- Display Enclosure

Go to External Views

Display Panel

- Base Enclosure
- Battery
- Speaker Assembly
- M.2 Solid State Drive
- Wireless LAN Module
- Touchpad Board
- Memory Module(s)
- Fans
- Heat Sink (Discrete)
- Heat Sink (UMA)
- Rear Speaker
- IR Board
- DC-in Connector
- System Board (Discrete Top)
- System Board (Discrete Bottom)
- System Board (UMA Top)
- System Board (UMA Bottom)
- Top Cover with Keyboard
- Display Panel Assembly
- **Display Panel**
- Display Panel Cable
- Touch Control Board
- Touch Control Board Cable
- Webcam
- Hinges
- Hinge Caps
- Wireless LAN Antennas
- Display Enclosure

Go to External Views

Display Panel Cable

- Base Enclosure
- Battery
- Speaker Assembly
- M.2 Solid State Drive
- Wireless LAN Module
- Touchpad Board
- Memory Module(s)
- Fans
- Heat Sink (Discrete)
- Heat Sink (UMA)
- Rear Speaker
- IR Board
- DC-in Connector
- System Board (Discrete Top)
- System Board (Discrete Bottom)
- System Board (UMA Top)
- System Board (UMA Bottom)
- Top Cover with Keyboard
- Display Panel Assembly
- Display Panel
- **Display Panel Cable**
- Touch Control Board
- Touch Control Board Cable
- Webcam
- Hinges
- Hinge Caps
- Wireless LAN Antennas
- Display Enclosure

Go to External Views

Touch Control Board

- Base Enclosure
- Battery
- Speaker Assembly
- M.2 Solid State Drive
- Wireless LAN Module
- Touchpad Board
- Memory Module(s)
- Fans
- Heat Sink (Discrete)
- Heat Sink (UMA)
- Rear Speaker
- IR Board
- DC-in Connector
- System Board (Discrete Top)
- System Board (Discrete Bottom)
- System Board (UMA Top)
- System Board (UMA Bottom)
- Top Cover with Keyboard
- Display Panel Assembly
- Display Panel
- Display Panel Cable
- **Touch Control Board**
- Touch Control Board Cable
- Webcam
- Hinges
- Hinge Caps
- Wireless LAN Antennas
- Display Enclosure

Go to External Views

Touch Control Board Cable

Base Enclosure
Battery
Speaker Assembly
M.2 Solid State Drive
Wireless LAN Module
Touchpad Board
Memory Module(s)
Fans
Heat Sink (Discrete)
Heat Sink (UMA)
Rear Speaker
IR Board
DC-in Connector
System Board (Discrete Top)
System Board (Discrete Bottom)
System Board (UMA Top)
System Board (UMA Bottom)
Top Cover with Keyboard
Display Panel Assembly
Display Panel
Display Panel Cable
Touch Control Board
Touch Control Board Cable
Webcam
Hinges
Hinge Caps
Wireless LAN Antennas
Display Enclosure

Go to External Views

Webcam

Base Enclosure
Battery
Speaker Assembly
M.2 Solid State Drive
Wireless LAN Module
Touchpad Board
Memory Module(s)
Fans
Heat Sink (Discrete)
Heat Sink (UMA)
Rear Speaker
IR Board
DC-in Connector
System Board (Discrete Top)
System Board (Discrete Bottom)
System Board (UMA Top)
System Board (UMA Bottom)
Top Cover with Keyboard
Display Panel Assembly
Display Panel
Display Panel Cable
Touch Control Board
Touch Control Board Cable
Webcam
Hinges
Hinge Caps
Wireless LAN Antennas
Display Enclosure

Go to External Views

Hinges

Base Enclosure
Battery
Speaker Assembly
M.2 Solid State Drive
Wireless LAN Module
Touchpad Board
Memory Module(s)
Fans
Heat Sink (Discrete)
Heat Sink (UMA)
Rear Speaker
IR Board
DC-in Connector
System Board (Discrete Top)
System Board (Discrete Bottom)
System Board (UMA Top)
System Board (UMA Bottom)
Top Cover with Keyboard
Display Panel Assembly
Display Panel
Display Panel Cable
Touch Control Board
Touch Control Board Cable
Webcam
Hinges
Hinge Caps
Wireless LAN Antennas
Display Enclosure



Go to External Views

Hinge Caps

Base Enclosure
Battery
Speaker Assembly
M.2 Solid State Drive
Wireless LAN Module
Touchpad Board
Memory Module(s)
Fans
Heat Sink (Discrete)
Heat Sink (UMA)
Rear Speaker
IR Board
DC-in Connector
System Board (Discrete Top)
System Board (Discrete Bottom)
System Board (UMA Top)
System Board (UMA Bottom)
Top Cover with Keyboard
Display Panel Assembly
Display Panel
Display Panel Cable
Touch Control Board
Touch Control Board Cable
Webcam
Hinges
Hinge Caps
Wireless LAN Antennas
Display Enclosure



Go to External Views

Wireless LAN Antennas

Base Enclosure
Battery
Speaker Assembly
M.2 Solid State Drive
Wireless LAN Module
Touchpad Board
Memory Module(s)
Fans
Heat Sink (Discrete)
Heat Sink (UMA)
Rear Speaker
IR Board
DC-in Connector
System Board (Discrete Top)
System Board (Discrete Bottom)
System Board (UMA Top)
System Board (UMA Bottom)
Top Cover with Keyboard
Display Panel Assembly
Display Panel
Display Panel Cable
Touch Control Board
Touch Control Board Cable
Webcam
Hinges
Hinge Caps
Wireless LAN Antennas
Display Enclosure



Go to External Views

Display Enclosure

Base Enclosure
Battery
Speaker Assembly
M.2 Solid State Drive
Wireless LAN Module
Touchpad Board
Memory Module(s)
Fans
Heat Sink (Discrete)
Heat Sink (UMA)
Rear Speaker
IR Board
DC-in Connector
System Board (Discrete Top)
System Board (Discrete Bottom)
System Board (UMA Top)
System Board (UMA Bottom)
Top Cover with Keyboard
Display Panel Assembly
Display Panel
Display Panel Cable
Touch Control Board
Touch Control Board Cable
Webcam
Hinges
Hinge Caps
Wireless LAN Antennas
Display Enclosure

Go to External Views