Interactive Part Locator

HP ZBook Create G7 Notebook PC

Welcome to the interactive part locator
for the HP ZBook Create G7 Notebook PC

Here's how to use it...

External Views (Click the link to navigate to the views)
On this page you will find large icons of each of the external views of this product. To view a specific view in greater detail, simply click that view.

Parts List (Click the link to navigate to the parts)
On this page, you will find a list of all of the replaceable parts for this product. To view a specific part and its location in the product, click the part name in the list.

That's it! On every page there is a link that brings you back to either the External Views or the Parts List, enabling you to navigate to whatever view or part you wish to review.

External Views

Front

Left

Right

Rear

Display

Top

Internal

Bottom

Front View

Left View

USB–A 3.0
charging port

Nano security
locking slot

Thermal
vent

Headphone/microphone
combo jack

Right View

SD card
reader slot

USB-C 3.2 Gen1
(Thunderbolt) ports

AC adapter LED

Mini DisplayPort

AC adapter
port

Rear View

Hinges

Display View

Microphones

Webcam

Webcam LED

IR Sensor

IR Sensor

Top View

Volume
control keys

Brightness control keys

Microphone mute/LED

Display switching

Power button/LED

Audio mute/LED

HP Command Center

Caps Lock key/LED

FN key/LED

Fingerprint reader

Windows application key

Clickpad

Internal View

IO Board

Heat Sink with Fans

System Board

M.2 Solid State Drive

Fingerprint Reader

RTC Battery

Keyboard Controller Board

Touchpad

Left and Right Speakers

Bottom View

Thermal vent

Rubber feet

Service tag

Base Enclosure

Go to External Views

Battery

Go to External Views

M.2 Solid State Drive

Heat Sink with Fans

RTC Battery

Touchpad

Go to External Views

Keyboard Controller Board

Go to External Views

Fingerprint Reader

IO Board

Base Enclosure

Battery

M.2 Solid State Drive

Heat Sink with Fans

RTC Battery

Touchpad

Keyboard Controller Board

Fingerprint Reader

IO Board

System Board (Top)

System Board (Bottom)

Left and Right Speakers

Top Speaker

Top Cover with Keyboard

Display Panel Assembly

Go to External Views

System Board (Top)

Go to External Views

System Board (Bottom)

Go to External Views

Left and Right Speakers

Base Enclosure

Battery

M.2 Solid State Drive

Heat Sink with Fans

RTC Battery

Touchpad

Keyboard Controller Board

Fingerprint Reader

IO Board

System Board (Top)

System Board (Bottom)

Left and Right Speakers

Top Speaker

Top Cover with Keyboard

Display Panel Assembly

Go to External Views

Top Speaker

Top Cover with Keyboard

Base Enclosure

Battery

M.2 Solid State Drive

Heat Sink with Fans

RTC Battery

Touchpad

Keyboard Controller Board

Fingerprint Reader

IO Board

System Board (Top)

System Board (Bottom)

Left and Right Speakers

Top Speaker

Top Cover with Keyboard

Display Panel Assembly

Go to External Views

Display Panel Assembly

Base Enclosure

Battery

M.2 Solid State Drive

Heat Sink with Fans

RTC Battery

Touchpad

Keyboard Controller Board

Fingerprint Reader

IO Board

System Board (Top)

System Board (Bottom)

Left and Right Speakers

Top Speaker

Top Cover with Keyboard

Display Panel Assembly