Interactive Part Locator

HP ENVY 14-eb0000 Laptop PC

Welcome to the interactive part locator for the
HP ENVY 14-eb0000 Laptop PC

Here's how to use it...

External Views (Click the link to navigate to the views)
On this page you will find large icons of each of the external views of this product. To view a specific view in greater detail, simply click that view.

Parts List (Click the link to navigate to the parts)
On this page, you will find a list of all of the replaceable parts for this product. To view a specific part and its location in the product, click the part name in the list.

That's it! On every page there is a link that brings you back to either the External Views or the Parts List, enabling you to navigate to whatever view or part you wish to review.

External Views

Front

Left

Right

Rear

Display

Top

Internal

Bottom

Front View

Left View

HDMI 2.0
port

Headphone/
microphone
combo port

USB-A 3.2
Gen 1 port

USB4 Type-C
Gen 3 port

Right View

USB-A 3.2
Gen 1 port

AC adapter
port

SD card
reader slot

AC adapter
LED

Rear View

HP ENVY logo

Display View

Webcam

Microphone

Webcam LED

Microphone

Top View

Audio mute/LED

Microphone mute/LED

Camera privacy shutter/LED

Caps lock/LED

Clickpad

Fingerprint sensor

Power button/LED

Internal View

DC-in connector

Fans

Heat sink

M.2 solid state drive

System board

Speaker

Battery

Speaker

Bottom View

Vent

Service tag

Back rubber foot

Speaker

Speaker

Back rubber foot

Base Enclosure

Battery

Base Enclosure

Battery

M.2 Solid State Drive

DC-in Connector

Heat Sink

Fans

Speakers

Top Cover with Keyboard

Display Panel Assembly

System Board (Top)

System Board (Bottom)

IR Sensor Board

Touchpad

Go to External Views

M.2 Solid State Drive

Go to External Views

DC-in Connector

Base Enclosure

Battery

M.2 Solid State Drive

DC-in Connector

Heat Sink

Fans

Speakers

Top Cover with Keyboard

Display Panel Assembly

System Board (Top)

System Board (Bottom)

IR Sensor Board

Touchpad

Go to External Views

Heat Sink

Fans

Base Enclosure

Battery

M.2 Solid State Drive

DC-in Connector

Heat Sink

Fans

Speakers

Top Cover with Keyboard

Display Panel Assembly

System Board (Top)

System Board (Bottom)

IR Sensor Board

Touchpad

Speakers

Base Enclosure

Battery

M.2 Solid State Drive

DC-in Connector

Heat Sink

Fans

Speakers

Top Cover with Keyboard

Display Panel Assembly

System Board (Top)

System Board (Bottom)

IR Sensor Board

Touchpad

Go to External Views

Top Cover with Keyboard

Go to External Views

Display Panel Assembly

Go to External Views

System Board (Top)

Base Enclosure

Battery

M.2 Solid State Drive

DC-in Connector

Heat Sink

Fans

Speakers

Top Cover with Keyboard

Display Panel Assembly

System Board (Top)

System Board (Bottom)

IR Sensor Board

Touchpad

Go to External Views

System Board (Bottom)

Go to External Views

IR Sensor Board

Base Enclosure

Battery

M.2 Solid State Drive

DC-in Connector

Heat Sink

Fans

Speakers

Top Cover with Keyboard

Display Panel Assembly

System Board (Top)

System Board (Bottom)

IR Sensor Board

Touchpad

Go to External Views

Touchpad

Base Enclosure

Battery

M.2 Solid State Drive

DC-in Connector

Heat Sink

Fans

Speakers

Top Cover with Keyboard

Display Panel Assembly

System Board (Top)

System Board (Bottom)

IR Sensor Board

Touchpad

Go to External Views