Maintenance schedule



When:	Task:	See job aid:
On opening	Wake minilab from Sleep mode	page 2 of Maintenance Schedule
	Resolve errors or warnings on touchscreen	Troubleshooting
	Empty finisher trim bag	Emptying finisher trim bag
	Check supplies and long-life consumables status	Checking supplies and long-life consumables status
	Check pen health and verify image quality	Verifying image quality
Daily, at closing	Empty finisher trim bag	Emptying finisher trim bag
	Clean drum screen	Cleaning drum screen
	Inspect paper path	Inspecting paper path
	Clean minilab exterior	Cleaning minilab exterior
Weekly, on opening	Check DFT PM list	page 4 of Maintenance Schedule
Weekly, at closing	Clean paper path	Cleaning paper path
	Ensure Sleep mode is enabled	page 4 of Maintenance schedule
As indicated by touchscreen	Add paper and configure trays	Loading paper
TOUCHSCreen	Replace ink cartridge	Replacing ink cartridges
	Replace pen wipe cartridge	Replacing pen wipe cartridge
	Replace ink droplet collector	Replacing ink droplet collector
	Empty finisher trim bag	Emptying finisher trim bag
When backside print fades	Replace backside printer ribbon	Replacing backside printer ribbon

Rev. 08.07.09

© 2009 Hewlett-Packard Development Company, L.P.

Before you begin: general maintenance guidelines

Adjust electrostatic discharge (ESD) strap

To ensure proper fitting of ESD strap:

- 1. Slide strap onto wrist. Make sure free end does not pull out of lock.
- 2. Pull strap until snug and snap lock closed.
- 3. Slide strap off of wrist.
- 4. Stretch free end of strap. Cut off excess close to lock (free end retracts under lock).
- 5. Remove alligator clip from ground cord.
- 6. Connect ground cord to wrist strap.
- Remove jams in direction of paper travel

When removing jams, pull only in direction of paper path (shown below) for jam area, or damage can result.



Avoid moving minilab

Do not move print engine during any maintenance procedure, or you will reduce image quality and may damage print engine. If print engine must be moved, contact HP support at http://www.hp.com/support.

Avoid excess moisture

When cleaning, wipes should be damp only. Excess moisture can damage minilab.

Special tools

Some tasks require special cleaning tools, including dust remover kit and pick roller cleaning cartridge. See *Cleaning paper path* job aid for details.

Cleaning guidelines

When wipes get dirty, replace with clean wipes before resuming cleaning. Clean surfaces until wipes come out clean.

Opening tasks:

When:	Task:	See job aid:
On opening	Wake minilab from Sleep mode	below
	Resolve errors or warnings on touchscreen	Troubleshooting
	Empty finisher trim bag	Emptying finisher trim bag
	Check supplies and long-life consumables status	Checking supplies and long-life consumables status
	Check pen health and verify image quality	Verifying image quality

1 Wake minilab from Sleep mode.

Touch screen or press Sleep button. Home screen will appear on touchscreen.

2 Resolve errors or warnings on touchscreen.

Follow procedure in Troubleshooting job aid.

3 Empty finisher trim bag.

Follow procedure in *Emptying finisher trim bag* job aid.

4 Check supplies and long-life consumables status.

Follow procedure in Checking supplies and long-life consumables status job aid.

5 Check pen health and verify image quality.

Follow procedure in Verifying image quality job aid.

120

Closing tasks:

When:	Task:	See job aid:
At closing	Empty finisher trim bag	Emptying finisher trim bag
	Clean drum screen	Cleaning drum screen
	Inspect paper path	Inspecting paper path
	Clean minilab exterior	Cleaning minilab exterior

- 1 Empty finisher trim bag.
 - Follow procedure in *Emptying finisher trim bag* job aid.
- 2 Clean drum screen.
 Follow procedure in *Cleaning drum screen* job aid.
- 3 Inspect paper path.
 Follow procedure in *Inspecting paper path* job aid.
- 4 Clean minilab exterior.


Follow procedure in Cleaning minilab exterior job aid.

Weekly tasks:

When:	Task:	See job aid:
Weekly, on opening	Check DFT PM list	page 4 of Maintenance Schedule
Weekly, at closing	Clean paper path	Cleaning paper path
	Ensure Sleep mode is enabled	below

Check DFT PM list.

- 1. Touch **Service** on Home screen.
- 2. Enter 00 from virtual keyboard.
- 3. Touch Yes.
- 4. Touch View PM Items.
- 5. Scroll through the list.
- 6. Perform any operator PM tasks in red.
- 7. If any non-operator tasks are red, contact HP Support.





Clean paper path.

Follow procedure in Cleaning paper path job aid.

Ensure Sleep mode is enabled.

- 1. Touch Administration.
- 2. Touch Management.
- 3. Touch Sleep Mode.
- 4. Make sure **Custom Energy Savings** is selected.
- 5. Touch Save.
- 6. Touch **Home** button in upper-left corner of screen.





mode to allow automatic maintenance and calibration.



As needed tasks:

When:	Task:	See job aid:
As indicated by touchscreen	Add paper and configure trays	Loading paper
	Replace ink cartridge	Replacing ink cartridges
	Replace pen wipe cartridge	Replacing pen wipe cartridge
	Replace ink droplet collector	Replacing ink droplet collector
	Empty finisher trim bag	Emptying finsher trim bag
When backside print fades	Replace backside printer ribbon	Replacing backside printer ribbon



Note: HP recommends training in each maintenance task for all retail operators. See ML1000 Training Checklist on documentation DVD for complete list of training tasks.



Note: For details about these procedures, see ML1000 Reference Guide on documentation DVD.