

HP LaserJet 1022, 1022n, 1022nw Software Technical Reference



HP LaserJet 1022 Series printer

Software Technical Reference



Copyright

© 2005 Copyright Hewlett-Packard Development Company, L.P.

Reproduction, adaptation or translation without prior written permission is prohibited, except as allowed under the copyright laws.

The information contained herein is subject to change without notice.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Edition 1, 4/2005

Trademarks

Adobe® and Acrobat® are trademarks of Adobe Systems Incorporated.

EnergyStar® and the Energy Star logo® are US registered marks of the United States Environmental Protection Agency.



Linux is a U.S. registered trademark of Linus Torvalds.

Microsoft®, Windows®, and Windows NT® are U.S. registered trademarks of Microsoft Corporation.

Pentium® is a registered trademark of Intel Corporation or its subsidiaries in the United States and other countries.

UNIX® is a registered trademark of The Open Group.

Table of contents

1 Introduction

Purpose and scope.....	2
HP LaserJet 1022 Series model comparison.....	3
Software availability and fulfillment.....	5
In-box file layout.....	5
HP LaserJet 1022 software CD, Windows partition.....	5
CD language groupings and part number.....	5
Ordering software.....	7
Documentation availability and localization.....	8

2 Windows software overview

Windows operating systems.....	12
Supported Windows operating systems.....	12
Supported operating systems.....	12
Driver-only supported operating systems.....	12
Windows system requirements.....	12
Windows supported operating system requirements.....	13
Printing from other operating systems.....	13
Software component information.....	14
Printing-system software features.....	14
Software component availability.....	14
Software component localization.....	15
HP Software Update utility.....	17
HP Print Screen utility.....	19
Installation.....	19
Activating the utility.....	19
Features.....	19
HP Order Reminder utility.....	21
Available printer configurations.....	23
Software features by connection type.....	23
Direct connection.....	23
Network connection options (HP LaserJet 1022n and HP LaserJet 1022nw printers only).....	23
Local connection that uses Microsoft peer-to-peer networking (Windows only)	23
Networked by using the internal HP network port (HP LaserJet 1022n and HP LaserJet 1022nw printers only).....	24
Networked by using the external HP network port.....	24
Port communication.....	25

Overview.....	25
USB port connections.....	25
Device conflicts in Windows.....	25
Opening the Windows Device Manager.....	25
Check for device conflicts.....	26
Guidelines for troubleshooting and resolving device conflicts.....	26

3 Macintosh software overview and installation

Supported Macintosh operating systems.....	28
Macintosh printing-system software for the HP LaserJet 1022 printer.....	29
Macintosh component descriptions.....	29
PDEs.....	29
In-box file layout.....	29
HP LaserJet 1022 software CD, Macintosh partition.....	29
Software components for Macintosh.....	29
Software component availability for Macintosh.....	30
Software component localization.....	30
Ordering software for Macintosh.....	32
System requirements (Macintosh).....	33
Installation overview.....	34
Installation options.....	35
Macintosh installation instructions for direct connections.....	35
Direct-connection installation instructions for Mac OS X, V10.2 and later.....	35
Macintosh installation instructions for networked computers.....	35
Network installation instructions for Mac OS X, V10.2 and later.....	36
Installation dialog-box options for Macintosh.....	37

4 Windows driver features

Host-based features.....	46
Access to drivers.....	46
Help system.....	46
What's this? Help.....	47
Context-sensitive Help.....	47
Constraint messages.....	47
Driver tab features.....	47
Printing Preferences tab set.....	48
Paper/Quality tab features.....	48
Quick Sets.....	49
Default Print Settings.....	49
Type new Quick Set name here.....	49
Paper Options group box.....	50
Size is:.....	50
Custom.....	51
Name.....	52
Save, Delete, or Rename.....	53
Paper Size (width and height controls).....	54
Custom width and height control limits.....	54
Units.....	54

OK.....	54
Use different paper check box.....	55
Source Is: drop-down menu.....	55
Type is: drop-down menu.....	55
Use different paper options.....	56
Back Cover options.....	57
First Page and Other Pages options.....	58
Document preview image.....	59
Effects tab features.....	59
Quick Sets.....	60
Fit to Page options group box.....	60
Print Document On setting.....	60
Scale to Fit option.....	60
% of Normal Size option.....	61
Document preview image.....	61
Watermarks group box.....	62
Current Watermarks.....	63
Watermark Message.....	64
Message Angle.....	64
Font Attribute.....	64
Name.....	64
Color.....	64
Shading.....	65
Size.....	65
Style.....	65
Default settings.....	65
Finishing tab features.....	65
Quick Sets.....	66
Document Options.....	66
Print on Both Sides (Manually) option.....	67
Manually printing on both sides.....	67
Flip Pages Up.....	67
Booklet layout.....	68
Book and Booklet printing.....	68
Printing a Booklet.....	69
Printing a Book.....	69
Pages per Sheet.....	69
Print Page Borders.....	69
Page Order.....	69
Document preview image.....	70
Print Quality.....	70
Print Quality drop-down menu.....	71
Print All Text as Black.....	71
Economode.....	71
Basics tab features.....	71
Quick Sets.....	72
Copies group box.....	72
Orientation.....	73
Portrait option button.....	73

Landscape option button.....	73
Rotated check box.....	73
Document preview image.....	73
About button.....	74
Printer Properties tab set.....	74
Configure tab features.....	74
Quick Sets.....	75
Jam Recovery.....	76
Status Messages.....	76
Cleaning Page.....	76
Print Density.....	76
Courier Font Type.....	76
Properties tab features - Windows 98 SE and Windows Me.....	76

5 HP Embedded Web Server (HP LaserJet 1022n and HP LaserJet 1022nw printers only)

Using HP Embedded Web Server (EWS).....	80
To open the HP Embedded Web Server.....	80
HP EWS tabs.....	81
Information tab.....	81
Device Status page.....	81
Device Configuration page.....	81
Settings tab.....	82
Print Settings page.....	82
Networking tab.....	84
IP Configuration page.....	84
Advanced page.....	84
mDNS page.....	85
Password page.....	86
Other links.....	86
HP Instant Support.....	86
Product Registration.....	86
Order Supplies page.....	86
Product Support page.....	86

6 Windows software installation

Installation overview	88
Installation options.....	89
Windows installation for direct connections.....	89
Setting up Windows sharing (peer-to-peer networking).....	89
Setting up the host computer running Windows 98 SE, Windows Me, or Windows 2000.....	90
Setting up the host computer running Windows XP.....	90
Setting up client computers running Windows 98 SE, Windows Me, or Windows 2000.....	91
Setting up client computers running Windows XP.....	91
Installation instructions for networked computers.....	92
Installing the software on networked computers (HP LaserJet 1022n and HP LaserJet 1022nw printers only).....	92
Installing the printer driver only.....	92
Printer-driver installation for Windows 98 SE.....	92

Printer-driver installation for Windows 2000 or XP.....	93
Plug-n-Play.....	93
Add Printer Wizard.....	93
Installation dialog-box options for Windows.....	94
Installing the software before the printer is connected to the computer.....	94
Installing the software when the printer is already connected to a computer.....	109
Uninstall.....	119
Uninstall instructions for Windows.....	119
Uninstalling using the HP program group (recommended).....	119
Uninstalling using Windows Add/Remove programs feature.....	121
Removing the HP Software Update utility.....	125
Index.....	127

List of tables

Table 1-1	Features of the HP LaserJet 1022 Series models.....	3
Table 1-2	CD language groupings for Windows installation.....	6
Table 1-3	User documentation availability and localization.....	8
Table 2-1	Software component availability for the HP LaserJet 1022 Series printer.....	14
Table 2-2	Language key A-I.....	15
Table 2-3	Software component localization by language, A-I.....	15
Table 2-4	Languagekey, L-Z.....	16
Table 2-5	Software component localization by language, K-Z	16
Table 3-1	Software components for Macintosh.....	30
Table 3-2	Software component availability for Macintosh.....	30
Table 3-3	CD language groupings for Macintosh.....	30
Table 4-1	Name drop-down menu text strings.....	53
Table 4-2	Host-based custom media sizes.....	54
Table 4-3	OK dialog box text strings.....	55
Table 4-4	Standard media types.....	56
Table 4-5	Page orientation.....	68

List of figures

Figure 2-1	Welcome screen - HP Software Update.....	17
Figure 2-2	New software is available screen - HP Software Update.....	18
Figure 2-3	HP Print Screen - system tray icon.....	19
Figure 2-4	HP Print Screen - configuration dialog box.....	20
Figure 2-5	HP Cartridge Order Reminder screen.....	22
Figure 3-1	Step 1 - Insert the HP LaserJet 1022 printing-system software CD.....	37
Figure 3-2	Step 2 - Run the HP LaserJet 1022 printing-system software CD.....	37
Figure 3-3	Step 3 - Main CD screen.....	38
Figure 3-4	Step 4 - License agreement, screen 1.....	39
Figure 3-5	Software License Agreement, screen 2.....	39
Figure 3-6	Step 5 - Select a destination.....	40
Figure 3-7	Step 6 - Easy Install process.....	41
Figure 3-8	Step 7 - Authenticate.....	41
Figure 3-9	Step 8 - Install files.....	42
Figure 3-10	Step 9 - Installation completed.....	43
Figure 4-1	A typical constraint message.....	47
Figure 4-2	Paper/Quality tab.....	48
Figure 4-3	Paper Options group box.....	50
Figure 4-4	Custom Paper Size dialog box.....	51
Figure 4-5	Back Cover setting.....	57
Figure 4-6	First Page and Other Page options.....	58
Figure 4-7	Effects tab.....	59
Figure 4-8	Preview images - Legal on Letter; Scale to Fit off (left) and on (right).....	61
Figure 4-9	Watermark Details.....	63
Figure 4-10	Finishing tab.....	66
Figure 4-11	Print on Both Sides Instructions.....	67
Figure 4-12	Page-order preview images.....	70
Figure 4-13	Basics tab.....	72
Figure 4-14	About This Driver dialog box.....	74
Figure 4-15	Configure tab.....	75
Figure 4-16	Properties tabs - Windows 98 SE.....	77
Figure 5-1	Device Status page.....	81
Figure 5-2	Device Configuration page.....	82
Figure 5-3	Print Settings page.....	83
Figure 5-4	IP Configuration page.....	84
Figure 5-5	Advanced page.....	85
Figure 5-6	mDNS page.....	85
Figure 5-7	Password page.....	86
Figure 6-1	Step 1 - CD Browser screen.....	94
Figure 6-2	Step 2 - HP Software License Agreement screen.....	95

Figure 6-3	Step 3 - Model Selection screen.....	96
Figure 6-4	Step 4 - Printer Connection screen.....	97
Figure 6-5	Step 5 - Identify Printer screen.....	98
Figure 6-6	Step 6 - Firewalls screen.....	99
Figure 6-7	Step 7 - Printer Found screen.....	100
Figure 6-8	Step 8 - Confirm Settings screen.....	101
Figure 6-9	Step 9 - Confirm Changing Setting screen.....	102
Figure 6-10	Step 10 - Set Network Protocol screen.....	103
Figure 6-11	Step 11 - Check Cable Connection screen.....	104
Figure 6-12	Step 12 - Specify Printer screen.....	105
Figure 6-13	Step 13 - Start Copying Files screen.....	106
Figure 6-14	Step 14 - Installation Status screen.....	106
Figure 6-15	Step 15 - USB Cable Connect screen.....	107
Figure 6-16	Step 16 - Finish screen.....	107
Figure 6-17	Step 17 - Registration screen.....	108
Figure 6-18	Step 18 - Exit Setup screen.....	108
Figure 6-19	Step 1 - Add Printer Wizard Welcome Screen.....	109
Figure 6-20	Step 2 - Local or Network Printer screen.....	110
Figure 6-21	Step 3 - Select the Printer Port screen.....	111
Figure 6-22	Step 4 - Manufacturer and model screen.....	112
Figure 6-23	Step 5 - Install from Disk.....	112
Figure 6-24	Step 6 - Select the correct language.....	113
Figure 6-25	Step 7 - Select the .INF file.....	113
Figure 6-26	Step 8 - Install from Disk, screen 2.....	114
Figure 6-27	Step 9 - Manufacturer and model screen 2.....	114
Figure 6-28	Step 10 - Name Your Printer screen.....	115
Figure 6-29	Step 11 - Printer Sharing screen.....	116
Figure 6-30	Step 12 - Print Test Page screen.....	117
Figure 6-31	Step 13 - Completing the Add Printer Wizard screen.....	118
Figure 6-32	Welcome to the LaserJet 1020 series uninstall Wizard dialog box.....	119
Figure 6-33	Remove the Program dialog box.....	120
Figure 6-34	Uninstalling the HP LaserJet 1020 series dialog box.....	120
Figure 6-35	Restart dialog box.....	121
Figure 6-36	Windows Control Panel.....	122
Figure 6-37	Windows Change or Remove programs.....	123
Figure 6-38	Remove the Program dialog box.....	124
Figure 6-39	Uninstalling the HP LaserJet 1020 series dialog box.....	124
Figure 6-40	Restart dialog box.....	125

1 Introduction

This chapter provides information about the following topics:

- [Purpose and scope](#)
- [HP LaserJet 1022 Series model comparison](#)
- [Software availability and fulfillment](#)
- [Documentation availability and localization](#)

Purpose and scope

This software technical reference (STR) provides information about and troubleshooting tips for the printing-system software for the HP LaserJet 1022 Series printer, which includes the following models:

- HP LaserJet 1022 printer
- HP LaserJet 1022n printer
- HP LaserJet 1022nw printer

This document is prepared in an electronic format to serve as a quick-reference tool for Customer Care Center (CCC) agents, support engineers, system administrators, management information systems (MIS) personnel, and end users, as appropriate.



NOTE This STR describes drivers that are shipped on the printing-system software CD that comes with the product. This STR does *not* cover drivers that will become available on the Web.

The following information is included in this STR:

- Overview of drivers and operating systems
- Procedures for installing and uninstalling software components



NOTE An addendum to this STR describes system modification information, including file lists and changes to registry keys.

HP LaserJet 1022 Series model comparison

The following table compares features of the product models that are described in this STR.

Table 1-1 Features of the HP LaserJet 1022 Series models

Feature	HP LaserJet 1022	HP LaserJet 1022n	HP LaserJet 1022nw
HP Product number	Q5912A	Q5913A	Q5914A
Memory	<ul style="list-style-type: none"> 8 megabytes (MB) of random access memory (RAM) 	<ul style="list-style-type: none"> 8 MB of RAM 	<ul style="list-style-type: none"> 8 MB of RAM
Speed	<ul style="list-style-type: none"> Prints up to 19 pages per minute (ppm) for letter-size paper Prints up to 18 ppm for A4-size paper First-page-out speed: less than 8 seconds 	<ul style="list-style-type: none"> Prints up to 19 ppm for letter-size paper Prints up to 18 ppm for A4-size paper First-page-out speed: less than 8 seconds 	<ul style="list-style-type: none"> Prints up to 19 ppm for letter-size paper Prints up to 18 ppm for A4-size paper First-page-out speed: less than 8 seconds
Connectivity	<ul style="list-style-type: none"> Universal serial bus (USB) 2.0 compatible 	<ul style="list-style-type: none"> USB 2.0 compatible HP network port 	<ul style="list-style-type: none"> USB 2.0 compatible HP network port Wireless
Paper-handling	<ul style="list-style-type: none"> One 10-sheet priority input slot (tray 1) One 250-sheet tray (tray 2) for standard media sizes 	<ul style="list-style-type: none"> One 10-sheet priority input slot (tray 1) One 250-sheet tray (tray 2) for standard media sizes 	<ul style="list-style-type: none"> One 10-sheet priority input slot (tray 1) One 250-sheet tray (tray 2) for standard media sizes
Print	<ul style="list-style-type: none"> 600 dots per inch (dpi) FastRes 1200: 600x600 dpi ProRes 1200: 1200x1200 dpi Image Resolution Enhancement Technology (ImageREt) Host-based PCL 5e¹ 2000-page capacity black print cartridge EconoMode (saves toner) 	<ul style="list-style-type: none"> 600 dots per inch (dpi) FastRes 1200: 600x600 dpi ProRes 1200: 1200x1200 dpi ImageREt Host-based PCL 5e¹ 2000-page capacity black print cartridge EconoMode (saves toner) 	<ul style="list-style-type: none"> 600 dots per inch (dpi) FastRes 1200: 600x600 dpi ProRes 1200: 1200x1200 dpi ImageREt Host-based PCL 5e¹ 2000-page capacity black print cartridge EconoMode (saves toner)
Internal fonts	26 Intelifont	26 Intelifont	26 Intelifont
Control panel	<ul style="list-style-type: none"> Three light-emitting diodes (LEDs) Two buttons 	<ul style="list-style-type: none"> Three light-emitting diodes (LEDs) Two buttons 	<ul style="list-style-type: none"> Three light-emitting diodes (LEDs) Two buttons

Table 1-1 Features of the HP LaserJet 1022 Series models (continued)

Feature	HP LaserJet 1022	HP LaserJet 1022n	HP LaserJet 1022nw
HP Product number	Q5912A	Q5913A	Q5914A
HP Embedded Web Server (EWS)	No	Yes	Yes

¹ This driver is available at the following Web site: www.hp.com/support/lj1022



NOTE Because the HP LaserJet 1022 Series models do not have a parallel port, they do not support MS-DOS, Windows® 95, Windows 98 (first edition), or Windows NT®. These operating systems require a parallel port and do not support USB connections.

Software availability and fulfillment

The software CD for the HP LaserJet 1022 Series printer contains a variety of files for installing the printing-system software on your computer. This section describes the files that are available on the software CD, as well as additional support and fulfillment information.

In-box file layout

The HP LaserJet 1022 printing-system software consists of two partitions: one for installation on Windows® operating systems and the other for Macintosh operating systems. The files in each partition include both documentation files and files that are required to install and uninstall the systems. For information about the file layout for the Macintosh partition of the HP LaserJet 1022 software CD, see the [HP LaserJet 1022 software CD, Macintosh partition](#) section of this guide.

HP LaserJet 1022 software CD, Windows partition

The HP LaserJet 1022 printing-system software is delivered on a CD that is included with the product. The CD include the following files:

- Installation files
- Uninstall files
- Printer driver
- Online Help
- OrderReminder
- .CHM version of the HP LaserJet 1022 User Guide
- .PDF version of the HP LaserJet 1022 User Guide
- Registration link
- Readme
- Late-breaking readme (English only)
- Status-message files
- Media-output-jam simulator files

To view the directories and support files, insert the HP LaserJet 1022 printing-system software CD into the CD-ROM drive on your computer, right-click **Start**, click **Explore**, and then select the CD-ROM drive.

CD language groupings and part number

The following table presents the Windows installation part number and language groups that are included on the software CD for the product.

Table 1-2 CD language groupings for Windows installation

CD	Part Number	Languages
1	Q5912-60104	<ul style="list-style-type: none">■ Arabic■ Bahasa■ Bulgarian■ Catalan■ Croatian■ Czech■ Danish■ Dutch■ English■ Estonian■ Finnish■ French■ German■ Greek■ Hebrew■ Hungarian■ Italian■ Kazakh■ Korean■ Latvian■ Lithuanian■ Norwegian■ Polish■ Portuguese, Brazilian■ Romanian■ Russian■ Simplified Chinese■ Slovak■ Slovenian■ Spanish■ Swedish

Table 1-2 CD language groupings for Windows installation (continued)

CD	Part Number	Languages
		<ul style="list-style-type: none">■ Thai■ Traditional Chinese■ Ukrainian

Ordering software

If you need a replacement CD or a newer version of the product software, go to the following Web site:

www.hp.com/go/lj1022_software

Click **CD Order Page** to order, or click **Download drivers and software** to get the software update.

To request the software CD by phone, see the following Web site for the correct contact number for your country/region:

www.hp.com/country/us/en/wwcontact.html

Documentation availability and localization

The documentation in the following table is available for the product.

Table 1-3 User documentation availability and localization

Document name	Languages	Location
<i>HP LaserJet 1022 User Guide</i>	<ul style="list-style-type: none"> ■ Arabic ■ Bahasa ■ Bulgarian ■ Catalan ■ Croatian ■ Czech ■ Danish ■ Dutch ■ English ■ Estonian ■ Finnish ■ French ■ German ■ Greek ■ Hebrew ■ Hungarian ■ Italian ■ Kazakh ■ Korean ■ Latvian ■ Lithuanian ■ Norwegian ■ Polish ■ Portuguese, Brazilian ■ Romanian ■ Russian ■ Simplified Chinese ■ Slovak ■ Slovenian 	<p>The <i>HP LaserJet 1022 User Guide</i> is available in electronic format on the HP LaserJet 1022 software CD.</p> <p>This guide is also available by clicking Manuals at the following Web site:</p> <p>www.hp.com/support/lj1022</p>

Table 1-3 User documentation availability and localization (continued)

	<ul style="list-style-type: none"> ■ Spanish ■ Swedish ■ Thai ■ Traditional Chinese ■ Ukrainian 	
<i>HP LaserJet 1022 Series Printer Welcome Mat</i>	<ul style="list-style-type: none"> ■ Arabic ■ Bahasa ■ Bulgarian ■ Catalan ■ Croatian ■ Czech ■ Danish ■ Dutch ■ English ■ Estonian ■ Finnish ■ French ■ German ■ Greek ■ Hebrew ■ Hungarian ■ Italian ■ Kazakh ■ Korean ■ Latvian ■ Lithuanian ■ Norwegian ■ Polish ■ Portuguese, Brazilian ■ Romanian ■ Russian ■ Simplified Chinese ■ Slovak 	<p>The <i>HP LaserJet 1022 Series Printer Welcome Mat</i> is available in electronic format on the HP LaserJet 1022 software CD.</p> <p>This guide is also available by clicking Manuals at the following Web site:</p> <p>www.hp.com/support/lj1022</p>

Table 1-3 User documentation availability and localization (continued)

	<ul style="list-style-type: none">■ Slovenian■ Spanish■ Swedish■ Thai■ Traditional Chinese■ Ukrainian	
<i>HP LaserJet 1022 Series Printing System Install Notes</i>	English	The <i>HP LaserJet 1022 Series Printing System Install Notes</i> are available in electronic format on the HP LaserJet 1022 software CD.

2 Windows software overview

This chapter provides information about the following topics:

- [Windows operating systems](#)
- [Software component information](#)
- [HP Software Update utility](#)
- [HP Print Screen utility](#)
- [Available printer configurations](#)
- [Port communication](#)



NOTE For information about the HP LaserJet 1022 printing-system software for Macintosh systems, see [Macintosh software overview and installation](#).

Windows operating systems

This section contains information about the following topics:

- [Supported Windows operating systems](#)
- [Windows system requirements](#)
- [Printing from other operating systems](#)

Supported Windows operating systems

The HP LaserJet 1022 Series printing-system software supports the following operating systems.

Supported operating systems

The following Windows operating systems are fully supported through the software installer and drivers available on the software CD that comes with the HP LaserJet 1022 Series printer:

- Microsoft ® Windows 98 SE
- Microsoft Windows Millennium Edition (Windows Me)
- Microsoft Windows 2000
- Microsoft Windows XP (32-bit)
- Microsoft Windows Longhorn 32



NOTE Because the HP LaserJet 1022 series product models do not have a parallel port, they do not support MS-DOS, Windows 95, Windows 98 (first edition), or Windows NT. These operating systems require a parallel port and do not support USB connections.

Driver-only supported operating systems

The following Windows operating system has print-driver-only support by the HP LaserJet 1022 printing-system software:

- Microsoft Windows 2003 Server (32-bit) - print driver included on the printing-system CD

Windows system requirements

For print-driver-only support, the HP LaserJet 1022 printing-system software has the following minimum system requirements.

Windows supported operating system requirements

- Processor and RAM requirements:
 - For Windows 98 SE and Windows ME: a computer with at least a Pentium® 166 MHz processor and 32 MB of RAM
 - For Windows 2000: a computer with at least a Pentium 166 MHz processor and 64 MB of RAM
 - For Windows XP: a computer with at least a Pentium 233 MHz processor and 128 MB of RAM
- 150 MB or more of free hard-disk space
- CD-ROM drive (required for installation)
- Works with USB and Hi-Speed USB systems and cables

Printing from other operating systems

You can send print jobs to your product from any operating system that complies with the PCL 5e command language, such as O/S2, UNIX, and Linux systems.

UNIX systems require a Model Script to set up the UNIX environment and then send print jobs to the product. Any generic HP LaserJet printer Model Script should work. These files are written and provided by the individual UNIX vendor. HP-UX® users can check for availability of the Model Script and the support model at the following Web site:

www.hp.com/support/net_printing

Click the **Support & Drivers** link.

Linux users should check for the availability of drivers at the following Web site:

<http://www.hp.com/go/linux>

The Windows inbox LaserJet 6L pcl 5e printer driver has been tested and is supported under Windows Terminal Server and Citrix Metaframe.

Software component information

This section contains information about the following topics:

- [Printing-system software features](#)
- [Software component availability](#)
- [Software component localization](#)

Printing-system software features

The printing-system software for the HP LaserJet 1022 printer includes the following features:

- **New Installer.** The product includes a new installer that improves the software installation process and supports either a hardware-first or a software-first installation.
 - Software-first is the recommended installation method.
 - In a hardware-first installation, the HP LaserJet 1022 printing-system software uses two separate installers, which run together to set up the port and the printing-system software correctly. If you cancel the installation after the hardware-first plug-and-play installer finishes, your installation consists of the print driver only.
- **HP Software Update utility.** The HP Software Update utility is a software program that locates the latest updates that you need for the HP hardware and software installed on your system, and gives you the choice of which updates to install.
- **HP Print Screen utility.** The HP Print Screen utility is a software program that you can use to print the current screen of the PC to the default printer. You can also use the HP Print Screen feature to save the screen to an image file.
- **HP Order Reminder utility.** The HP Order Reminder utility is a software program that you can use to set specific times for reminders to check the current level of toner in the print cartridge. HP Order Reminder also contains a link to a Web page that helps you order supplies online from a reseller of your choice.

Software component availability

The following table lists the availability of the HP LaserJet 1022 printing-system software components by operating system.



NOTE In the following table, "98 SE/Me" refers to Windows 98 SE and Windows Me; "2K/XP" refers to Windows 2000 and Windows XP.

Table 2-1 Software component availability for the HP LaserJet 1022 Series printer

Component	98 SE/Me	2K/XP
Drivers		
Host-based driver	X	X
PCL 5e driver ¹	X	X
Installers		

Table 2-1 Software component availability for the HP LaserJet 1022 Series printer (continued)

Component	98 SE/Me	2K/XP
Common Windows Installer	X	X
CD Browser	X	X
Fonts	X	X
.INF File (Add Printer)	X	X
Bidirectional communication		
Network Bidirectional Communications	X	X
Direct Connect Bidirectional Communications	X	X
Remote management and status		
Embedded Web Server (EWS)	X	X
Online Documentation		
<i>HP LaserJet 1022 User Guide²</i>	X	X
<i>HP LaserJet 1022 Series Printing System Install Notes</i>	X	X
Help systems	X	X
Other		
HP Software Update program	X	X
HP Print Screen program	X	X
HP Order Reminder program	X	X

¹ This driver is available at the following Web site: www.hp.com/support/lj1022

² This document is also available at the following Web site: www.hp.com/support/lj1022

Software component localization

The following tables provide localization information about the printing-system software components.

Table 2-2 Language key A-I

AR = Arabic	ES = Spanish
CS = Czech	FI = Finnish
DA = Danish	FR = French
DE = German	HE = Hebrew
EL = Greek	HU = Hungarian
EN = English	IT = Italian

Table 2-3 Software component localization by language, A-I

Component ¹	Operating system	AR	CS	DA	DE	EL	EN	ES	FI	FR	HE	HU	IT
Host-based driver	98 SE, Me, 2000, XP	X	X	X	X		X	X	X	X	X	X	X

Table 2-3 Software component localization by language, A-I (continued)

Component ¹	Operating system	AR	CS	DA	DE	EL	EN	ES	FI	FR	HE	HU	IT
pcl 5e driver (use Windows inbox 6L printer driver)	98 SE, Me	X	X	X	X	X	X	X	X	X	X	X	X
Common Windows Installer	98 SE, Me, 2000, XP	X	X	X	X	X	X	X	X	X	X	X	X
Online manuals	98 SE, Me, 2000, XP	X	X	X	X		X	X	X	X	X	X	X
Online Help	98 SE, Me, 2000, XP	X	X	X	X	X	X	X	X	X	X	X	X

¹ Components that are not available in a specific language are supported in English.

Table 2-4 Languagekey, L-Z

KO = Korean

SV = Swedish

NL = Dutch

TH = Thai

NO = Norwegian

TR = Turkish

PL = Polish

ZHCN = Simplified Chinese

PT = Portuguese

ZHTW = Traditional Chinese

RU = Russian

Table 2-5 Software component localization by language, K-Z

Component ¹	Operating system	KO	NL	NO	PL	PT	RU	SV	TH	TR	ZHCN	ZHTW
Host-based driver	98 SE, Me, 2000, XP	X	X	X	X	X	X	X	X	X	X	X
pcl 5e driver (use Windows inbox 6L printer driver)	98 SE, Me	X	X	X	X	X	X	X	X	X	X	X
Common Windows Installer	98 SE, Me, 2000, XP	X	X	X	X	X	X	X	X	X	X	X
Online manuals	98 SE, Me, 2000, XP	X	X	X	X	X	X	X	X	X	X	X
Online Help	98 SE, Me, 2000, XP	X	X	X	X	X	X	X	X	X	X	X

¹ Components that are not available in a specific language are supported in English.

HP Software Update utility

The HP Software Update utility is installed with the HP LaserJet 1022 printing-system software. The HP Software Update utility provides an easy and convenient way to keep your HP software programs and HP products up-to-date. The HP Software Update utility locates the latest updates that you need for the HP hardware and software installed on your system, and gives you the choice of which updates to install.

To gain access to the HP Software Update utility, click **Start**, click **Programs**, select **HP**, and then click **HP Software Update**.

From the **Welcome** screen, you can perform the following tasks:

- Configure the HP Software Update utility
- View the data that the HP Software Update utility has collected
- View HP's privacy policy
- View frequently asked questions about the HP Software Update utility
- View the End User License Agreement
- Send feedback to HP

The following illustration shows the **Welcome** screen for the HP Software Update utility.



Figure 2-1 Welcome screen - HP Software Update



NOTE At the time of the writing of this manual the only update available is an update to HP Software Update Version 3.0.1.

When you click **Next**, the following screen appears.




Figure 2-2 New software is available screen - HP Software Update

HP Print Screen utility

HP Print Screen is utility software that you can use to print the current computer screen on the default printer. You can also use the utility to save the screen to an image file.

Installation



NOTE Administrator installations do not install the HP Print Screen program or the HP Web Update utility.

HP Print Screen is a self-contained software program that is installed silently when you install the HP LaserJet 1022 printing-system software.

To open the HP Print Screen utility, click **Start**, click **Programs**, select **HP**, and then click **HP Print Screen**. The configuration dialog box provides the option to run the HP Print Screen utility when Windows is started.

The following path is the installation location for the HP Print Screen utility:

<preferred location>\HP\HP PRINT SCREEN

HP Print Screen is removed from your computer when you uninstall the HP LaserJet 1022 printing-system software.

The HP Print Screen utility supports the same operating systems as the printing-system software. To see a list of supported operating systems, see [Supported Windows operating systems](#).

Activating the utility

The HP Print Screen utility can only be started by clicking **Start**, clicking **Programs**, selecting **HP**, and then clicking **HP Print Screen**. The utility then runs as a system-tray icon, and you can print the current screen when you press the **PrtScn** key or the **Alt + PrtScn** key combination on the keyboard.



NOTE The configuration dialog box also appears when you press the **PrtScn** key or the **Alt + PrtScn** key combination on the keyboard

The configuration dialog box can be opened in any of the following ways:

- Click **Start**, click **Programs**, select **HP**, and then click **HP Print Screen**.
- Press the **PrtScn** key or the **Alt + PrtScn** key combination on the keyboard after the HP Print Screen icon appears in the system tray.
- Mouse over the HP Print screen icon in the system tray, right-click, and then click **Configure** in the context menu.

Features

When the software starts, the HP Print Screen icon appears in the system tray.



Figure 2-3 HP Print Screen - system tray icon

When this icon is visible, a configuration dialog box appears when you press the **PrtScn** key or the **Alt + PrtScn** key combination on the keyboard.




Figure 2-4 HP Print Screen - configuration dialog box

In the configuration dialog box, you can perform the following tasks:

- Print the current screen by clicking **Print Screen**.
- Save the screen to an image file by clicking **Save Screen ...**.
 - The keys that you press on the keyboard determine the current screen. If you use the HP Print Screen interface, the entire desktop is captured. If you press the **Alt + PrtScn** key combination on your keyboard, the active window is captured.
 - After the HP Print Screen utility is started, pressing the **PrtScn** key or the **Alt + PrtScn** key combination does *not* update the HP Print Screen dialog box.
 - The HP Print Screen preview always shows the clipboard content (in bitmap format only) that was there before you opened the HP Print Screen dialog box.
 - Control the orientation of the screen before sending the print job to the default printer or before saving to an image file.
- Enable or disable the option to have the HP Print Screen utility run automatically when you start Windows.
- If you have selected the **Automatically print when the Print Screen button is pressed** option, and then pressed the **PrtScn** key or the **Alt + PrtScn** key combination on your keyboard, the HP Print Screen utility dialog box does *not* appear, but the screen capture is sent automatically to the default printer.

- All of the setting in this dialog box are retained unless they are changed within the configuration or for a specific job. The following are the default values for the settings:
 - Do not start with Windows
 - Orientation is landscape
 - Automatically open the configuration dialog box when you press the **PrtScn** key or the **Alt + PrtScn** key combination on your computer keyboard
- Context-sensitive help opens when you click ? and then click the configuration dialog box control that you want information about.
- The HP Print Screen utility is localized in the following languages:
 - Czech
 - Danish
 - Dutch
 - English
 - Finnish
 - French
 - German
 - Greek
 - Hungarian
 - Italian
 - Korean
 - Norwegian
 - Polish
 - Portuguese (Brazilian)
 - Russian
 - Spanish
 - Swedish
 - Simplified Chinese
 - Traditional Chinese
 - Turkish

HP Order Reminder utility

The HP Order Reminder utility is installed with the HP LaserJet 1022 printing-system software. The HP Order Reminder utility provides an easy and convenient way to set specific times for reminders to

check the current level of toner in the print cartridge. You can also use the utility to disable the reminder.

HP Order Reminder also contains an **Order Now** link to a Web page that helps you order supplies online from a reseller of your choice.

To gain access to the HP Order Reminder utility, click **Start**, select **Programs**, select **Hewlett-Packard**, select **OrderReminder**, and then click **OrderReminder HP LaserJet 1022**.

The following illustration shows the **HP Cartridge Order Reminder** screen .



Figure 2-5 HP Cartridge Order Reminder screen

The **HP Cartridge Order Reminder** screen offers the following options in the **Remind me in** drop-down menu:

- 1 day
- 1 week
- 2 weeks
- 1 month
- 6 months
- 1 year

Available printer configurations

This section contains information about the following topics:

- Software features by connection type
- Supported configurations

Software features by connection type

The HP LaserJet 1022 printing-system software can be used with the product in one of the following configurations:

- Directly connected to a computer. If the product is connected to a computer running Windows 98 SE, Windows Me, Windows 2000, or Windows XP, you can share the product with other network users through Windows sharing.
- Connected to a network through the HP network card.

Direct connection

In the direct (or local) configuration, the product is connected directly to the host computer with a universal serial bus (USB) cable. In this configuration, the product is not shared. A single user has complete control of the product. You can gain access to all of the capabilities of the product in this configuration.

Network connection options (HP LaserJet 1022n and HP LaserJet 1022nw printers only)

The following networking options are available for the product:

- Local connection that uses Microsoft peer-to-peer networking (Windows only)
- Networked by using the internal HP network port (HP LaserJet 1022n and HP LaserJet 1022nw printers only)
- External Jetdirect network port

Local connection that uses Microsoft peer-to-peer networking (Windows only)

You can use Microsoft Windows to share a local printer over the network. The operating system handles all of the networking issues. Because Microsoft peer-to-peer networking is unidirectional, network users do not receive product-status messages when they print.



NOTE HP does not support vending drivers across operating systems that have different printer-driver architectures, such as HP Traditional drivers and HP Unidrivers. To use mixed operating systems, you must install an alternate print driver and download the driver for the specific operating system as described in the HP customer support document *HP Color LaserJet and LaserJet Printers - MS Windows NT 4.0 through MS Windows 2000 and beyond, Print Driver Issues for Operating in a Mixed Operating System Environment*.

Networked by using the internal HP network port (HP LaserJet 1022n and HP LaserJet 1022nw printers only)

In this configuration, your HP LaserJet 1022n or HP LaserJet 1022nw printer is connected to a network through the internal HP network port that comes standard with the product. The product can be under the direct control of a single user or in a common area with other networked resources. All users on operating systems that support the full printer software have access to the full functionality of the product.

Networked by using the external HP network port

In this configuration, your HP LaserJet 1022 printer is connected to a network through the external HP network port that can be added to the product. The product can be under the direct control of a single user or in a common area with other networked resources. All users on operating systems that support the full printer software have access to the full functionality of the product.

Port communication

This section provides information about the following topics:

- [Overview](#)
- [USB port connections](#)
- [Device conflicts in Windows](#)

Overview

The product can be connected through the USB port.



NOTE For the HP LaserJet 1022n or HP LaserJet 1022nw models, use the HP network port to connect multiple computers to a single HP LaserJet 1022 Series printer.

USB port connections

USB 2.0 is an input/output mode that both Windows and Macintosh computers support. A wide variety of consumer devices, such as digital cameras and scanners, also support USB. Note that the HP LaserJet 1022 Series printer is compatible with USB 2.0 specifications.

A distinction exists between a USB Host and a USB Device. The HP LaserJet 1022Series printer is a USB Device. Models can only connect to a USB Host or a USB Hub.

Device conflicts in Windows

When two-way communication cannot be established with the product, the Windows Device Manager might show a conflict. Conflicts should be resolved immediately, and before continuing to troubleshoot two-way communication issues. The following sections contain a few guidelines for identifying and resolving these conflicts.



NOTE This process applies to both USB and parallel port devices. However, USB devices are only supported in Windows 98 SE, Windows Me, Windows 2000, and Windows XP.

Opening the Windows Device Manager

Follow these steps to open the Windows Device Manager.

- 1 For Windows 98 SE, Windows Me, and Windows 2000, click **Start**, click **Settings**, and then click **Control Panel**.
For Windows XP, click **Start**, and then click **Control Panel**.
- 2 Double-click the **System** icon.
- 3 On the **Hardware** tab, click **Device Manager**.



NOTE In Windows 98 SE, click the **Device Manager** tab.

Check for device conflicts

Follow these steps to check for device conflicts.

- 1 Look for devices that appear on the list with a yellow exclamation mark (!) or a red X.
- 2 Identify port conflicts by double-clicking **Port** or by clicking the plus sign (+). Conflicts here usually interfere with two-way communication.
- 3 To check the status of a device, click the device name, and then click **Properties**. The **Device Status** appears in the middle of the dialog box.
- 4 To check the **Conflicting Device** list, click the device name, and then click **Properties**. Click the **Resources** tab, and look at the **Conflicting Device** list at the bottom of the dialog box.
- 5 Click the plus sign (+) to the left of **Open the Other Devices**. Misidentified or noncategorized devices appear here.

Guidelines for troubleshooting and resolving device conflicts

Follow these steps for resolving device conflicts.

- 1 If the conflicting device is no longer present in the list of devices, click the device name, click **Remove**, and then click **Yes**. Click **Yes** to restart Windows.
- 2 If the conflicting device is a duplicate (and one of the duplicate listings does *not* show a conflict), click the name(s) of the device(s) that have a conflict, click **Remove**, and then click **Yes**. Click **Yes** to restart Windows.



NOTE You might not need to restart the computer in Windows 2000 or Windows XP, depending on the type of port conflict that you are resolving.

- 3 If a device has a conflict and you have the driver for that device, remove the device and then reinstall it. After removing the device, restart the computer. When Windows reinstalls devices, it usually finds nonconflicting resources.

3 Macintosh software overview and installation



NOTE This chapter covers information about the HP LaserJet 1022 printing-system software for Macintosh. For information about Windows installations, see [Windows software installation](#).

This chapter provides information about the following topics:

- [Supported Macintosh operating systems](#)
- [Macintosh printing-system software for the HP LaserJet 1022 printer](#)
- [System requirements \(Macintosh\)](#)
- [Installation overview](#)
- [Installation options](#)
- [Installation dialog-box options for Macintosh](#)

Supported Macintosh operating systems

The Macintosh printing-system software for the HP LaserJet 1022 printer supports Mac OS X, V10.2 and later.

Macintosh printing-system software for the HP LaserJet 1022 printer

This section provides information about the following topics:

- [Macintosh component descriptions](#)
- [In-box file layout](#)
- [Software components for Macintosh](#)
- [Software component availability for Macintosh](#)
- [Software component localization](#)
- [Ordering software for Macintosh](#)

Macintosh component descriptions

The HP LaserJet 1022 printing solution for Macintosh uses the Print Center for OS X.2, or the Printer Setup Utility for OS X.3, which are provided with the operating system. It also uses an HP host-based driver to determine the features that the product supports.

PDEs

Printer Dialog Extensions (PDEs) are code plug-ins (for Mac OS X, V10.2 and later) that provide access to product features, such as number of copies, duplexing, and print quality settings.

In-box file layout

The HP LaserJet 1022 printing-system software consists of two partitions: one for installation on Windows operating systems, the other for Macintosh operating systems. The files include both documentation files and files that are required to install and uninstall the systems. For information about the file layout for the Windows partition of the HP LaserJet 1022 printing-system CD, see the [Software availability and fulfillment](#) section of this guide.

HP LaserJet 1022 software CD, Macintosh partition

The files contained in the Macintosh partition of the HP LaserJet 1022 printing-system software CD are grouped by language and reside in the following directories and folders:

- Root directory (contains the README.HTML file)
- HP LaserJet 1022 folder (contains the installers)
- PDF (contains guides and manuals in .PDF format)
- hp Laserjet Screen Fonts folder

Software components for Macintosh

The following table lists the HP LaserJet 1022 software components that are available for computers running the Macintosh operating system.

Table 3-1 Software components for Macintosh

Component	Description
Installer software	Installs the HP LaserJet 1022 host-based driver
Driver software	Is used to print from your HP LaserJet 1022
Online Help	Provides help for the HP LaserJet 1022 printing-system software
	The user documentation for these products is included on the installation CD in Adobe Acrobat .PDF format

Software component availability for Macintosh

The following table lists the availability of the HP LaserJet 1022 printing-system software components for Macintosh.

Table 3-2 Software component availability for Macintosh

Component	Macintosh
Drivers	
HP Host-Based Driver	X
Installers	
HP Host-Based Driver Installer	X
Online Documentation	
<i>HP LaserJet 1022 User Guide</i>	X
<i>HP LaserJet 1022 Series Printing System Install Notes</i>	X
Help systems	X

Software component localization

The following table presents the Macintosh installation part numbers and language groups that are included on the software CDs for the product.

Table 3-3 CD language groupings for Macintosh

CD	Part Number	Languages
1	Q5912-60104	<ul style="list-style-type: none"> ■ Arabic ■ Bahasa ■ Bulgarian ■ Catalan ■ Croatian ■ Czech

Table 3-3 CD language groupings for Macintosh (continued)

CD	Part Number	Languages
		<ul style="list-style-type: none">■ Danish■ Dutch■ English■ Estonian■ Finnish■ French■ German■ Greek■ Hebrew■ Hungarian■ Italian■ Kazakh■ Korean■ Latvian■ Lithuanian■ Norwegian■ Polish■ Portuguese, Brazilian■ Romanian■ Russian■ Simplified Chinese■ Slovak■ Slovenian■ Spanish■ Swedish■ Thai■ Traditional Chinese■ Ukrainian

Ordering software for Macintosh

If you need a replacement CD or a newer version of the printing-system software, go to the following Web site:

- www.hp.com/support/lj1022

On the product Web site, click **CD Order Page** to order a replacement CD. Click **Download drivers and software** to get the software update.

To request the software CD by phone, see the following Web site for the correct contact number for your country/region:

www.hp.com/country/us/en/wwcontact.html

System requirements (Macintosh)

The HP LaserJet 1022 printing-system software has the following minimum system requirements:

- Mac OS X, V10.2 and later
- Macintosh computer (Power PC processor), such as an iMac; a Power Macintosh G3, G4, or G5; an eMac; or an iBook
- RAM: For Mac OS X, V10.2 and later, the minimum system memory is 128 MB. These are minimum system requirements for memory. An additional 32 MB of free memory is optimum for installation.
- 150 MB or more of free hard-disk space
- A CD-ROM drive (required for installation)

Installation overview

The printing-system software for the HP LaserJet 1022 is shipped on one CD. On Mac OS systems, the HP Installer program installs the HP LaserJet 1022 printing-system software from the CD onto the hard disk.

On Mac OS systems, your HP LaserJet 1022 uses the HP Installer. This Installer provides an Easy Install option, which installs only the HP LaserJet 1022 printing-system software on the current system startup drive that contains the active **System** folder.

Installation options

The HP LaserJet 1022 printing-system software can be used in one of the following configurations:

- Directly connected to a computer. This configuration provides the most printer functionality.
- Connected to a network through the HP internal network port.

Macintosh installation instructions for direct connections

This section provides information about the following topic:

- Installation instructions for Mac OS X, V10.2 and later



NOTE Install the software before connecting the product to the computer.

Direct-connection installation instructions for Mac OS X, V10.2 and later

Use the instructions below to install the software on a Macintosh computer running Mac OS X, V10.2 and later.

- 1 Insert the HP LaserJet 1022 printing-system software CD into your CD-ROM drive.
- 2 Run the installer CD.
- 3 Open the **Print Center** or **Printer Setup Utility** (for Mac OS X, V10.3.x) by clicking **HD**, clicking **Applications**, clicking **Utilities**, and then clicking **Print Center** or **Printer Setup Utility**.
- 4 If the HP LaserJet 1022 Series printer appears in the list of printers, go to step 9. If it does not appear in the list of printers, go to step 5.
- 5 Click the **Printers** menu, and then click **Add Printer...**
- 6 Select **USB** in the drop-down list.
- 7 In the **Printer Model** box, click **HP LaserJet 1022**, and then click **Add**.
- 8 Select **HP LaserJet 1022** in the **Printers** menu, and then click **Make Default**.
- 9 Print a page from any program to make sure that the software is correctly installed.



NOTE If the installation fails, see the *HP LaserJet 1022 Series Printing System Install Notes* on the HP LaserJet 1022 printing-system software CD, see the flyer that came in the box with your printer, or go to the following Web site for help or more information:

www.hp.com/support/lj1022

Macintosh installation instructions for networked computers

To install the HP LaserJet 1022 printing-system software on networked Macintosh operating systems, follow the instructions for your operating system.

Network installation instructions for Mac OS X, V10.2 and later

Use the instructions below to install the software on a Macintosh computer that is running Mac OS X, V10.2 and later, and is connected to a network.

- 1 The HP LaserJet 1022n and HP LaserJet 1022nw models have an HP network port for network connection. For a 10/100 Base-T network, connect a twisted-pair network cable between the printer and an active network port.
- 2 At the product control panel, make sure that the Ready light is on. Press the **Go** button for 5 seconds to print a Configuration page, an HP Jetdirect page, and a Supplies Status page.



NOTE If no HP Jetdirect page was printed, wait 30 seconds for the network card to initialize, and then try to print the page again.

- 3 Insert the HP LaserJet 1022 printing-system software CD into your CD-ROM drive.
- 4 Run the installer CD.
- 5 Open the **Print Center** or **Printer Setup Utility** (for Mac OS X, V10.3.x) by clicking **HD**, clicking **Applications**, clicking **Utilities**, and then clicking **Print Center** or **Printer Setup Utility**.
- 6 Open the **Printers** menu, and then click **Add Printer...**
- 7 Select **Rendezvous** in the drop-down list.
- 8 In the **Printer Model** box, click **HP LaserJet 1022**, and then click **Add**.
- 9 Print a page from any program to make sure that the software is correctly installed.



NOTE If the installation fails, see the *HP LaserJet 1022 Series Printing System Install Notes on the HP LaserJet 1022* printing-system software CD, see the flyer that came in the box with your printer, or go the following Web site for help or more information:

www.hp.com/support/lj1022.

Installation dialog-box options for Macintosh

The following sequence describes the dialog box options that appear during the HP LaserJet 1022 printing-system software installation on Macintosh systems.

To begin the installation, insert the HP LaserJet 1022 printing-system software CD into your CD-ROM drive.



Figure 3-1 Step 1 - Insert the HP LaserJet 1022 printing-system software CD

Double-click the **hp LaserJet 1022** icon that appears on the desktop.




Figure 3-2 Step 2 - Run the HP LaserJet 1022 printing-system software CD

Double-click the **hp LaserJet 1022** folder.




Figure 3-3 Step 3 - Main CD screen

Click **Continue**.




Figure 3-4 Step 4 - License agreement, screen 1

In the drop-down menu at the top of the screen, select the language that you want to use for the installation.

Print... opens the **Page Setup** dialog box for your default printer so that you can print a copy of the license agreement.

Save opens the system **Save** dialog box so that you can save the text of the software license agreement to disk.

Continue presents the option to agree or disagree to the terms of the software license agreement.

Go Back returns you to the main CD screen.




Figure 3-5 Software License Agreement, screen 2




Figure 3-6 Step 5 - Select a destination

Select the drive on which you want to install the software.




Figure 3-7 Step 6 – Easy Install process

The **Easy Install** option is the default.

Click **Go Back** to select a different destination.

Click **Install** to begin the installation process.



Figure 3-8 Step 7 - Authenticate

Type your username and the password that provides administrator privileges, and then click **OK** to continue.

Click **Cancel** to close the installer.



Figure 3-9 Step 8 - Install files

The **Installing** dialog box appears, showing the progress of the installation.



Figure 3-10 Step 9 - Installation completed

The **Installation success** dialog box appears, indicating a successful installation.

Click **Close** to close this dialog box.

4 Windows driver features

This chapter provides information about the following topic:

- [Host-based features](#)

Host-based features



NOTE Host-based printing differs from PCL printing by computing the print job on the host computer rather than computing the print job in the product formatter.

This section contains the following information:

- Access to drivers
- Help system
- Driver-tab features

Access to drivers

To gain access to driver settings from within most software programs, click **File**, click **Print**, and then click **Properties**. The appearance and names of the driver tab can vary, depending on the operating system. These settings apply only while the software program is open.

You can also control the drivers directly from the **Printers** folder. These settings change the default settings that are used across all software programs.

- In Windows 2000, click **Start**, click **Settings**, click **Printers**, right-click the product name, and then click **Printing Preferences** to gain access to the same set of driver tabs that the software program controls.
- In Windows XP, click **Start**, click **Printers and Faxes** (Windows XP Professional) or **Printers and Other Hardware Devices** (Windows XP Home), right-click the product name, and then click **Printing Preferences** to gain access to the same set of driver tabs that the software program controls.

If, after right-clicking the product name, you click **Properties**, you gain access to a different set of tabs that control the driver behavior and driver connections. For information about the **Properties** tabs that are described in this chapter, see the [Printer Properties tab set](#) section.

Help system

The Host-based driver includes a full-featured Help system to provide assistance with printing and configuration options. The following Help options are available:

- What's this? Help
- Context-sensitive Help
- Constraint messages

What's this? Help

"What's this?" Help is supported in Windows 2000 and Windows XP. You can gain access to "What's this?" Help messages in any of the following ways:

- Right-click a control or option and then click **What's this?**, and a pop-up Help window appears.
- Click the ? button at the upper-right corner of the frame, next to the X, to change the cursor to an arrow with a question mark. Use this special cursor to select a control or option, and the pop-up Help window for that feature appears.
- Press the F1 key, and the Help window for the currently selected control or option appears.

Context-sensitive Help

Press the **Help** button on a driver tab or in a dialog box, and context-sensitive Help appears.

Constraint messages

Constraint messages are unsolicited messages that appear in response to specific actions that you take. These messages alert you to selections that are illogical or impossible given the capabilities of the product or the current settings of other controls. For example, if you click **Print on Both Sides (Manually)** and then change the media type to **Transparency**, a message appears asking you to resolve this conflict.




Figure 4-1 A typical constraint message

Whenever a constraint message appears with **Restore my previous settings** and **Keep this setting, and I will change it later** buttons, the interpretation of the buttons is as follows:

- Clicking **OK** accepts the change that was just made, and the driver then resets the conflicting control to a setting that is compatible with the new value.
- Clicking **Cancel** rejects the change that was just made, and the control remains set at its previous value.

Driver tab features

This section describes the options that are available on each tab of the Host-based driver interfaces. The following information is included:

- **Printing Preferences** tab set
- **Printer Properties** tab set

Printing Preferences tab set

The **Printing Preferences** tabs contain information for formatting documents for the product. You can gain access to the **Printing Preferences** tabs either through your software program or through the Windows **Printers** folder. For more information, see the [Access to drivers](#) section for Windows 2000 and Windows XP.

The following tabs are included in the **Printing Preferences** tab set:

- **Paper/Quality** tab
- **Effects** tab
- **Finishing** tab
- **Basics** tab

Paper/Quality tab features

Use the **Paper/Quality** tab to specify the size, type, and source of the print media. You can also use this tab to configure different media-selection choices for the first page, other pages, and back cover of the document. The following illustration shows the **Paper/Quality** tab.




Figure 4-2 Paper/Quality tab

The **Paper/Quality** tab contains the following controls:

- **Quick Sets** group box
- **Paper Options** group box
- Document preview image

Quick Sets

The first group box in the upper portion of the **Paper/Quality** tab is **Quick Sets**. Any change to the **Quick Sets** group box that is made on the **Paper/Quality** tab affects all of the **Printing Preferences** driver tabs (the **Paper/Quality**, **Effects**, **Finishing**, and **Basics** tabs) because they are all the same control.

Use the **Quick Sets** setting to store the current combination of driver settings that are on all of the other print driver tabs. **Quick Sets** are either preset by using network-administrator settings or user-defined printing specifications (such as media size, pages per sheet, and so on).



NOTE Administrators can predefine Quick Sets for their users. These administrator Quick Sets are defined on the server and are available to users, but usually cannot be modified by users. Users can also define Quick Sets for their own use. User-defined Quick Sets are described later in this section.

The following selections are available in the **Quick Sets** drop-down menu:

- **Defaults**
- **Type new Quick Set name here**

Default Print Settings

When you select **Defaults**, nearly all of the settings are restored to the combination that existed after the driver was installed (the original settings). However, if the attribute combinations that are associated with watermark definitions or custom media sizes quick sets have been changed or deleted, the original settings are not restored.

Defaults appears in the **Quick Sets** menu automatically if no other driver settings have been changed since the driver was installed, or if all of the driver settings match the original settings. Otherwise, the setting in the **Quick Sets** menu is the same label that appeared when you last closed the printing **Properties** dialog box by clicking **OK**.

Type new Quick Set name here

By default, the **Quick Sets** menu is set to **Defaults**. When you change any of the default settings on any of the **Printing Preferences** driver tabs and you want to save the configuration as a Quick Set, highlight the words **Untitled**, type the name that you want for your new Quick Set, and then click **Save**. Quick Sets are saved in the system registry. To delete a Quick Set, select it from the drop-down menu and then click **Delete**.



NOTE Administrators can predefine Quick Sets for their users. These administrator Quick Sets are defined on the server and are available to users, but usually cannot be modified by users. Users can also define Quick Sets for their own use. User-defined Quick Sets are described later in this section.

You can store a maximum of 25 Quick Sets on a particular system. If you attempt to save too many, a message box appears that reads, "There are too many Quick Sets defined. Please delete some before adding new ones."

Paper Options group box

The settings specified in the **Paper Options** group box on the **Paper/Quality** tab apply to all of the pages of the document. The following illustration shows the **Paper Options** group box and the selections available by default.




Figure 4-3 Paper Options group box

The appearance of the **Paper Options** group box changes when the **Use different paper** check box is selected. The settings in the **Paper Options** group box are described below in the following order:

- [Size is:](#)
- [Custom](#)
- [Source Is: drop-down menu](#)
- [Type is: drop-down menu](#)
- [Use different paper options](#)

Size is:

The **Size is:** setting is a drop-down menu that lists all of the supported media sizes.

You can specify a size for all the settings in the **Paper Options** group box. You must use the same media size for the entire print job. That is, if the print job uses Letter-size media, any option that you select from the available **Use different paper** options must also use Letter-size media.



NOTE Certain software programs can override the size command and specify different media sizes within a single document.

For the **Other Pages** and **Back Cover** settings, you can select a source (tray) and media type that differ from the settings selected for **First Page**. If a conflict exists among media source, media size,

and/or media type, and you choose to keep the conflicting settings, the settings are processed in the following order: media size, media type, and then media source.

Because driver settings are overridden by media-size settings in most software programs, it is generally best to use the driver to set media size only for software programs that lack a media-size setting, such as NotePad, or when you are producing a book or a booklet that does not require different media sizes.



NOTE When you use a software program that has a media-size setting, you can specify different media sizes within a single document by using the **Use different paper** options. For more information, see [Use different paper options](#).

Custom

The **Custom Paper Size** dialog box appears when you click the **Custom** button on the **Paper/Quality** tab. The following illustration shows the initial appearance of the **Custom Paper Size** dialog box.



NOTE The **Custom** button is not available when **Use different paper** is selected *and* any setting other than **First Page** is also selected.




Figure 4-4 Custom Paper Size dialog box

When the **Custom Paper Size** dialog box appears, the drop-down menu in the **Name** group contains one of two things, depending on the current media-size selection on the **Paper/Quality** tab:

- If the media-size selection is a previously defined custom size, then the drop-down menu contains the name of that custom size.
- If the media-size selection is a standard media size, then the drop-down menu shows the default name **Untitled** for a custom media size.



NOTE In Windows 98 SE and Windows Me, two names for the same size media can coexist (for example, "big" and "BIG" can both be used as names for custom-size media measuring 8.4 inches x 11 inches). In Windows NT 4.0, Windows 2000, and Windows XP, both uppercase and lowercase names can be used, but they cannot be used to name the same media size.

The new name is compared only against the list of user-defined custom media-size names, and not against the standard media-size names.

The complete set of titles for this button and the specific characteristics that determine its title and capabilities are discussed in the [Save, Delete, or Rename](#) section.

Name

The **Name** drop-down menu shows the name of the custom media size that was selected most recently. Use the **Name** drop-down menu to select from the list of currently defined custom media sizes, or to type a new name for a custom media size.

The name that appears in the **Name** drop-down menu is one of three things, depending on the following conditions:

- If a saved custom media size has been selected from the drop-down menu and the other controls in the dialog box have not been changed since then, the **Name** drop-down menu shows the name of the last selected custom media size.
- If the width or height controls have been changed since a custom size was selected or saved, or if a saved media size has just been deleted, then the **Name** drop-down menu shows the default name of **Untitled**.
- If a new name has been typed into the **Name** drop-down menu for the purpose of saving a new size or renaming an existing size, then that new name will remain in the drop-down menu until a saved custom media size has been selected from the drop-down menu.

If you type a new name into the **Name** drop-down menu, but then do not click the **Save** button, you should be able to change the width and height values without losing the name. However, if a saved media-size name is selected from the drop-down menu, any unsaved name or size values are lost without warning, and replaced by the values of the selected custom media size.

Save, Delete, or Rename

The dynamic command button located next to the **Name** drop-down menu has three possible labels: **Save**, **Delete**, or **Rename**.

- **Save** is the button title whenever the height and width values have been changed since the most recent save action or since the selection of an existing custom media size. Clicking the button causes the name in the **Name** drop-down menu to be compared against each of the saved names. If a duplicate is found, a dialog box appears, asking if it is okay to replace the existing item. If you click **Yes**, the old item is updated with the new values. If you click **No**, the driver returns to the **Custom Paper Size** dialog box, where you can type a different name. The new name is compared only against the list of user-defined custom media names, and not against the standard media-size names. Whenever the command button has the **Save** title, it is the default button.
- **Delete** is the button title whenever the name of an existing (previously saved) custom media size appears in the **Name** drop-down menu, such as immediately after selecting an item from the drop-down menu or clicking the **Save** button. Clicking the **Delete** button causes the saved custom media size to be deleted, after which the **Name** drop-down menu changes to **Untitled**, the height and width controls are unchanged, and the button title changes to **Save**.
- **Rename** is the button title when you type something into the **Name** drop-down menu after selecting an existing custom media size from the drop-down menu. If no duplicate is found, then the name of the stored custom media size changes to match the contents of the **Name** drop-down menu.

The following table illustrates the relationships between the **Name** drop-down menu, the command button, and the actions that take users from one state to another.

Table 4-1 Name drop-down menu text strings

State	Drop-down menu contents	Button label	Action	Next state
1	Untitled	Save	Click Save .	3
			Type something into the Name drop-down menu.	2
			Change the width or height values.	1
			Select a saved item from the drop-down menu.	3
2	<user-typed text>	Save	Click Save .	3
			Type something into the Name drop-down menu.	2
			Change the width or height values.	2
			Select a saved item from the drop-down menu.	3
3	<name of saved item>	Delete	Click Delete .	1
			Type something into the Name drop-down menu.	4
			Change the width or height values.	1
			Select a saved item from the drop-down menu.	3
4	<user-typed text>	Rename	Click Rename (when the name is unique).	3
			Click Rename (when the name is a duplicate).	4
			Type something into the Name drop-down menu.	4

Table 4-1 Name drop-down menu text strings (continued)

State	Drop-down menu contents	Button label	Action	Next state
			Change the width or height values.	2
			Select a saved item from the drop-down menu.	3

Paper Size (width and height controls)

The width and height values can be changed either by typing numeric strings into the edit boxes, or by using the up and down arrows.

Any entry that is greater than the maximum limits of the width and height control is rounded down to the maximum valid entry, while any entry that is smaller than the minimum limits of the width and height control is rounded up to the minimum valid entry.

If units are in millimeters, the custom media-size range minimum is the limit rounded up to the nearest whole millimeter. The custom media-size range maximum is the limit rounded down to the nearest whole millimeter. Any non-numerical entry reverts to the last valid entry. Width and height entries are validated when the focus has changed.

The resolution of each control is one millimeter or one-tenth of an inch, depending on the current measurement units. Clicking the up and down arrows increases or decreases the current value by the increment amount (within the allowed range of values). The computer determines the rate at which the values change.

Unit indicator labels change dynamically to indicate inches or millimeters, depending on the measurement units the driver is currently using. To change measurement units, click the dynamic Measurement Units button (either **Use Inches** or **Use Millimeters**).

Custom width and height control limits

The minimum media size for the HP LaserJet 1022 is 76.2 x 127 mm (3 x 5 inches) and the maximum is 216 x 356 mm (8.5 x 14 inches). The following table summarizes media size limits for each media-handling device.

Table 4-2 Host-based custom media sizes

Tray	Dimensions	Minimum	Maximum
Tray 1 (10-sheet priority input slot)	Width	76.2 mm (3 inches)	216 mm (8.5 inches)
	Height	127 mm (5 inches)	356 mm (14 inches)
Tray 2 (250-sheet)	Width	148 mm (5.83 inches)	216 mm (8.5 inches)
	Height	210 mm (8.27 inches)	356 mm (14 inches)

Units

Select the **Inches** or **Millimeters** button to show the unit of measurement in either standard (inches) or metric (millimeters).

OK

The **OK** button closes the **Custom Paper Size** dialog box according to the logic in the following table. In all cases, any custom media sizes that are successfully saved (and not renamed or deleted)

while the dialog box is open will remain in the **Size is:** drop-down menu on the **Paper/Quality** tab. The following table lists options that appear when you click the **OK** button.

Table 4-3 OK dialog box text strings

If the drop-down menu contains	And the button says	Then this happens when you click the OK button
Custom	Save	The dialog box closes, but you lose the changes that were not saved. The current media size remains the same as it was when the Custom button was selected.
<user-typed text>	Save	The dialog box closes, but you lose the changes that were not saved. The current media size remains the same as it was when the Custom button was selected.
<name of saved item>	Delete	The dialog box closes, and the current media size is set to that which was last shown in the drop-down menu.
<user-typed text>	Rename	The dialog box closes, but you lose the changes that were not saved. The current media size remains the same as it was when the Custom button was selected.

Use different paper check box

When the **Use different paper** check box is selected and different options are configured, the **Size is:**, **Source is:**, and **Type is:** menus change, offering a variety of options. For more information, see [Use different paper check box](#).

Source Is: drop-down menu

The **Source is:** setting specifies the source tray to use for printing a document. The list of source trays depends on the printer accessories. Any optional source trays that are installed through the **Device Settings** tab also appear here.

The **Source is:** drop-down menu can contain the following options:

- **Auto Select**
- **Manual Feed**

The default setting is **Auto Select**. When this setting is selected, the product uses the source tray that supports the media size that you have selected. If you select a source tray other than **Auto Select**, make sure that the correct media size is loaded in the source tray.

Type is: drop-down menu

The **Type is:** drop-down menu shows all of the media types that the product supports.

The following standard media types appear in the list.

Table 4-4 Standard media types

Media type
Bond Paper
Cardstock (106 to 163 g/m ² or 28 to 43 lb.)
Color
Envelope
Heavy (90 to 105 g/m ² or 24 to 28 lb.)
Labels
Letterhead
Light (< 75 g/m ²)
Plain
Preprinted
Prepunched
Recycled
Rough Paper
Transparency
Vellum

The default setting is **Unspecified**, and the program selects the media type. If you select a different setting, make sure that the correct media type is loaded in the tray you selected in the **Source is:** setting.

Use different paper options

You can print books that include different types of print media by using the **Use different paper** options.

When you select the **Use different paper** check box, the following settings can appear in the group box, along with associated options:

- **First Page**
- **Other Pages**
- **Back Cover**

To use **Use different paper** options, you must configure the setting for the print job. Each option for the **Use different paper** setting is described in the sections that follow this procedure. Use the procedure to configure the setting.

To configure the Use different paper options for a print job

For each option, you can set a different tray in the **Source Is:** drop-down menu. For some options, the **Type is:** drop-down menu is also available.

- 1 To use different media or cover stock, select the **Use different paper** check box. A list of options appears in the dialog box. The full set of selections is visible when you scroll by using the down arrow button to the right of the list.
- 2 To use different media for the pages within the print job, select the appropriate option (**First Page**, **Other Pages**, or **Back Cover**) in the dialog box.
- 3 Click **OK** to print.



NOTE You must use the same size of media for the entire print job. All options that you select from the available **Use different paper** options use the size selected in the **First Page** settings.

When you change the type and source of the media and covers, the settings you select remain configured until you close the software program.

Each option for the **Use different paper** setting is described in the following sections, in the order they appear in the pane below the **Use different paper** check box.

Back Cover options

The following illustration shows the **Back Cover** setting and options that you use to include a blank or preprinted back cover on a document.




Figure 4-5 Back Cover setting

The **Back Cover** options are as follows:

- **Source is:** drop-down menu
- **Type is:** drop-down menu



NOTE The **Back Cover** options are not available when the **Booklet Layout** setting is enabled on the **Finishing** tab. For two-page-per-sheet (2-up) booklet printing, you can include a cover by selecting different media for the first page only. The back cover setting is unavailable, because this page would be printed in the middle of a booklet.

The **Source is:** setting specifies the source tray to use for adding a back cover to the document. The list of source trays depends on the product accessories. Any optional trays that are installed through the **Configure** tab also appear here. For more information about the **Source is:** setting, see the [Source Is: drop-down menu](#) section of this chapter.

The **Type is:** drop-down menu shows all of the media types that the product supports. For more information about the **Type is:** drop-down menu settings, see the **Type is:** in the [Type is: drop-down menu](#) section of this chapter.

First Page and Other Pages options

Use these options to select an alternative media size, type, or source for the first page or other pages of a document. The following illustration shows the appearance of the **Paper Options** group box when you select the **Use different paper** check box.




Figure 4-6 First Page and Other Page options

The **First Page**, and **Other Pages** options are as follows:

- **Size is:** drop-down menu
- **Source is:** drop-down menu
- **Type is:** drop-down menu

The **Size is:** driver setting for the first page applies to the entire print job. When this is set for the **First Page** option, the setting becomes unavailable for all the other **Use different paper** options.

The **Source is:** setting specifies the source tray to use for printing a document. The list of source trays depends on the product accessories. Any optional source trays that are installed through the **Device Settings** tab also appear here.

The **Type is:** drop-down menu shows all of the media types that the product supports.

Document preview image

The document preview image is a line-drawn image of a page that represents graphics and text. The document preview image is always oriented so that the contents of the page are right-side up. The document preview image appears in the upper-right corner of the **Paper/Quality**, **Effects**, **Finishing**, and **Basics** tabs.

Switching between tabs does not change the location or appearance of the document preview image. When you move the mouse over the document preview image, the mouse cursor changes from an arrow to a gloved hand. You can toggle between portrait and landscape page orientation by clicking on the image.

Effects tab features

Use the **Effects** tab to create unique media effects such as scaling and watermarks. The following illustration shows the **Effects** tab.




Figure 4-7 Effects tab

The **Effects** tab contains the following controls:

- **Quick Sets** group box
- **Fit to Page** group box
- Document preview image

- **Watermarks** group box

Quick Sets

Use the **Quick Sets** control to store the current combination of driver settings that are found on all of the other **Printing Preferences** driver tabs. Quick sets are either preset or user-defined printing specifications, such as media size and pages per sheet. For more information, see [Quick Sets](#) in the **Paper/Quality** tab section of this guide.

Fit to Page options group box

The **Fit to Page** group box consists of the following controls:

- **Print Document On** setting
- **Scale to Fit** option
- **% of Normal Size** setting

Print Document On setting

Select the **Print Document On** option button to format the document for one media size and then print the document on a different media size, with or without scaling the image to fit the new media size.

The **Print Document On** control is disabled by either of the following conditions:

- The **% of Normal Size** value is not 100.
- The **Pages per Sheet** value (on the **Finishing** tab) is not 1.

When **Print Document On** is selected, the drop-down menu shows the media sizes on which you can print. The list contains all of the standard media sizes that the selected media source supports and any custom media sizes that you have created. When **Print Document On** is selected, **Scale to Fit** is automatically selected.

Scale to Fit option

The **Scale to Fit** option box specifies whether each formatted document page image is scaled to fit the target media size. By default, **Scale to Fit** is selected when **Print Document On** is selected. If the setting is turned off, then the document page images will not be scaled, and are instead centered at full size on the target media. If the document size is larger than the target media size, then the document image is clipped. If it is smaller, then it is centered within the target media. The following illustration shows preview images for a document that has been formatted for legal-size media with the **Print Document On** check box selected, and the target size specified as **Letter**.




Figure 4-8 Preview images - Legal on Letter; Scale to Fit off (left) and on (right)

When the size for which the document is formatted (that is, the logical size) differs from the target size, the preview image uses a dashed gray line to show the boundaries of the logical page in relation to the target page size.

% of Normal Size option

The **% of Normal Size** option provides a slider bar to use for scaling the percentage setting. The default setting in the entry box is 100 percent of normal size. Normal size is defined as the media size that is selected within the driver or what the driver receives from the software program (if the software program does not negotiate the media size with the driver). The driver scales the page by the appropriate factor and sends it to the product.

The limits of the range are from 25 percent to 400 percent, and any values outside of the range are adjusted to those limits as soon as the focus is removed from the control (that is, when the **Tab** key is pressed or another control is selected).

Any change to the scale also changes the page preview, which increases or decreases from the upper-left corner of the preview.

The slider bar controls the scale directly. The value in the edit box changes as the scroll bar indicator is dragged, and the preview image is updated to the new image scale. Each click on the scroll bar arrows increases or decreases the scale by one percent. Each click on the slider bar affects the scale by 10 percent.

You cannot achieve an exact value by dragging the scroll bar indicator at the default Windows resolution. Use the scroll bar indicator to approximate the value that you want, and then use the scroll bar arrows to refine the value.

The following settings disable **% of Normal Size**:

- **Print Document On** (on the **Effects** tab) is selected
- **Pages per Sheet** (on the **Finishing** tab) is not 1

Document preview image

The document preview image is a line-drawn image of a page that represents graphics and text. The document preview image is always oriented so that the contents of the page are right-side up. The document preview image appears in the upper-right corner of the **Finishing**, **Effects**, and **Paper/Quality** tabs.

Switching between tabs does not change the location or appearance of the document preview image. When you move the mouse over the document preview image, the mouse cursor changes

from an arrow to a gloved hand. You can toggle between portrait and landscape page orientation by clicking the document preview image.

Watermarks group box

Use the **Watermarks** feature to choose a watermark, create your own custom watermarks (text only), or edit an existing watermark. The following watermarks are preset in the driver:

- **(none)**
- **Confidential**
- **Draft**
- **SAMPLE**

The drop-down menu shows alphabetically sorted watermarks that are currently available on the system, plus the string "(none)", which indicates that no watermark is selected. This is the default setting. Any watermark selected from this list appears in the preview image.

When the **First Page Only** check box is selected, the watermark is printed only on the first page of the document. The **First Page Only** check box is disabled when the current watermark selection is **(none)**.

Watermarks are applied to logical pages. For example, when **Pages per Sheet** is set to **4** and **First Page Only** is turned off, four watermarks appear on the physical page (one on each logical page).

Click **Edit**, and the **Watermark Details** dialog box appears.




Figure 4-9 Watermark Details

The dialog box shows a preview image and provides options for creating a new watermark and controlling the message angle and font attributes.

Click **OK** to accept all of the changes that are made in the **Watermark Details** dialog box. However, clicking **Cancel** does not cancel all of the changes. If you make changes to a watermark, and then select a different watermark or click **New**, all of the changes that you made to the previous watermark are saved, and only the current, unsaved changes can be canceled.

Current Watermarks

The **Current Watermarks** group box contains a list of available watermarks, both predefined watermarks made available in the driver and any new watermarks that you have created.

To create a new watermark, click **New**. The new watermark appears in the **Current Watermarks** list and in the **Watermark Message** edit box as **Untitled** until you name it. The name that you type in the **Watermark Message** field appears in the **Current Watermarks** group box in the **Watermark Details** dialog box and in the **Watermarks** group box on the **Effects** tab.

To name the new watermark, type the selected watermark text in the **Watermark Message** edit box. To delete a watermark, select the watermark in the **Current Watermarks** list and click **Delete**. A warning appears asking whether you are sure you want to delete the selected item. Click **Cancel** if you want to keep the watermark. Click **OK** to delete the selected watermark.



NOTE You can have no more than 30 watermarks in the **Current Watermarks** list at one time. When the limit of 30 watermarks is reached, the **New** button is disabled, and a Bubble Help appears that explains why the button is disabled and how to enable it.

To edit an existing watermark, select the watermark in the **Current Watermarks** list. If you change the **Watermark Message** for that watermark, you are, in effect, creating a new watermark.

Watermark Message

The **Watermark Message** is also the name that identifies the watermark in the **Current Watermarks** list, except when more than one watermark has the same message. For example, you might want several different watermarks with the message DRAFT, each with a different typeface or font size. When this occurs, the string is appended with a space, a pound sign, and a number (for example, **Draft #2**). When a number is added, the number two is used first, but if the resulting name is also in the list, then the number increases until the name is unique (**Draft #3**, **Draft #4**, and so on).

Message Angle

Use the controls in the **Message Angle** group box to print the watermark in different orientations in relation to the text. The settings are **Diagonal**, **Horizontal**, or **Angle** (custom). The default is **Diagonal**. All three settings automatically center the watermark string within the page; the selection of a particular setting affects only the angle of the string placement. **Diagonal** places the text along a line that spans the lower-left to upper-right corners of the page. **Horizontal** places the text along a line that spans the mid-left and mid-right edges of the page. **Angle** places the text at the specified angle across the page.

Font Attribute

Use the controls in the **Font Attributes** group box to change the font and the shading, size, and style of the font.

The **Font Attributes** group box contains the following controls:

- **Name** drop-down menu
- **Color** drop-down menu
- **Shading** drop-down menu
- **Size** spin box
- **Style** drop-down menu

Name

The **Name** drop-down menu lists fonts that are currently installed on the system. The default is language-dependent.

Color

The default **Gray** setting is the only setting available from the **Color** drop-down menu.

Shading

The default **Shading** setting for new and preset watermarks is **Very Light**. The following range of shades is available from the **Shading** drop-down menu.

- **Lightest**
- **Very Light** (default)
- **Light**
- **Medium Light**
- **Medium**
- **Medium Dark**
- **Dark**
- **Very Dark**
- **Darkest**

These values represent the intensity of the gray that is used. A choice of **Light** produces a lightly saturated gray watermark. A choice of **Lightest** produces the lightest shade of watermark; **Darkest** produces a black watermark.

Size

Font sizes from 1 to 999 points are available from the **Size** menu. The default point size is language-dependent. The choice of **Regular**, **Bold**, **Italic**, and **Bold Italic** is available from the **Style** drop-down menu.

Style

The choice of **Regular**, **Bold**, **Italic**, and **Bold Italic** is available from the **Style** drop-down menu. The default **Style** setting for new and preset watermarks is **Regular**.

Default settings

The default settings for new watermarks are **Arial** font, **Gray** color, **Very Light** shading, **80** points, and **Regular** style. The default settings for preset watermarks are **Arial** font, **Very Light** shading, and **Bold** style. The default point size for preset watermarks is language-dependent, and varies.

Finishing tab features

Use the **Finishing** tab to print booklets and control the media output. The following illustration shows the **Finishing** tab.




Figure 4-10 Finishing tab

The **Finishing** tab contains the following controls:

- **Quick Sets** group box
- **Document Options** group box
- Document preview image
- **Print Quality** group box

Quick Sets

Use the **Quick Sets** control to store the current combination of driver settings that are found on all other **Printing Preferences** driver tabs. Quick sets are either preset or user-defined printing specifications, such as media size and pages per sheet. For more information, see [Quick Sets](#) in the **Paper/Quality** tab section of this guide.

Document Options

The **Document Options** group box contains the following controls:

- **Print on Both Sides (Manually)** check box
- **Flip Pages Up** option

- **Booklet Printing** drop-down menu
- **Pages per Sheet** drop-down menu
- **Print Page Borders** check box
- **Page Order** drop-down menu

Print on Both Sides (Manually) option

The default setting for the **Print on Both Sides (Manually)** option is off (not selected). Selecting **Print on Both Sides (Manually)** makes the **Flip Pages Up** and **Booklet Printing** options available.

Manually printing on both sides

Follow these steps to manually print on both sides:

- 1 Print all of the even-numbered pages in your document. Some software programs have a selection in the **Print** dialog box that you can use to specify printing even- or odd-numbered pages.
- 2 Follow the instruction on the **Print on Both Sides Instructions** dialog box.




Figure 4-11 Print on Both Sides Instructions

Flip Pages Up

The **Flip Pages Up** check box, which is available only when **Print on Both Sides** is selected, is used to specify the duplex-binding option. By default, the **Flip Pages Up** check box is not selected.

The following table demonstrates the results of selecting this box, depending on the media orientation that you selected on the **Finishing** tab.

Table 4-5 Page orientation

Orientation (Finishing tab)	Flip Pages Up selected	Flip Pages Up not selected
Portrait	Short-edge binding	Long-edge binding
Landscape	Long-edge binding	Short-edge binding

When **Print on Both Sides (Manually)** is selected, the document preview image changes to show a spiral binding along either the left edge or the top edge of the page. In addition, a folded-over corner appears in the lower-right portion of the preview image, indicating that printing occurs on the back side. An arrow on the folded-over corner points in the direction that the pages would be flipped if they were bound together.

Short-side binding is for print jobs with pages that read by flipping over like the pages of a note pad. Long-side binding is for print jobs with pages that read by turning like the pages of a book.

Booklet layout

The **Booklet Layout** drop-down menu, visible when **Print on Both Sides** is selected, offers choices that are based on the current media size. The default setting for the **Booklet Printing** drop-down menu is **Off**.

- **Left Edge Binding**
- **Right Edge Binding**

When you select **Left Edge Binding** or **Right Edge Binding**, the document preview image changes to show the location of the binding. If the **Pages per Sheet** setting is on the default setting of 1, it automatically changes to **2 pages per sheet**. If you change the **Pages per Sheet** setting manually to 4, 6, 9, or 16 pages per sheet, the booklet setting is disabled. See the [Printing a Booklet](#) section of this chapter for more information.

The **Booklet Layout** setting is disabled when A6 or B6 (JIS) is selected as the media size, and an incompatibility error message appears when you click **OK** to close the driver.

Book and Booklet printing

The HP LaserJet 1022 supports book and booklet printing.

A book is a print job consisting of at least two pages that can have a different media type for the first page, other pages, or back cover. Use the **First Page**, **Other Pages**, and **Back Cover** settings on the **Paper/Quality** tab (available when you select the **Use different paper** check box) to select different media for these pages.

A booklet is a print job that places two pages on each side of a sheet that can be folded into a booklet that is half the size of the media type. Use the **Booklet Layout** drop-down menu on the **Finishing** tab to control booklet settings.

Printing a Booklet

Complete the following steps to print a booklet.

- 1 Click **File**, click **Print**, and then click **Properties**.
- 2 Click the **Finishing** tab and select the **Print on Both Sides (Manually)** check box.
- 3 In the **Booklet Layout** drop-down menu, select the type of booklet printing that you want (for example, **Right Edge Binding**).
- 4 Click **OK** in the print driver.
- 5 Click **OK** in the print dialog box to print.

Printing a Book

You can print a book in which the first page, other pages, and back cover have different media types. For more information, see the [Paper/Quality tab features](#) section of this chapter.

Pages per Sheet

Use the **Pages per Sheet** option to select the number of pages that you want to print on a single sheet of media. If you choose to print more than one page per sheet, the pages appear smaller and are arranged on the sheet in the order that they would otherwise be printed. The **Pages per Sheet** drop-down menu provides six settings:

- 1 page per sheet (default)
- 2 pages per sheet
- 4 pages per sheet
- 6 pages per sheet
- 9 pages per sheet
- 16 pages per sheet



NOTE When you select an option other than **2 pages per sheet**, booklet printing is unavailable.

Print Page Borders

Related controls indented beneath the **Pages per Sheet** edit box are **Print Page Borders** and **Page Order**, which become active when **Pages per Sheet** is greater than 1.

Print Page Borders sets a line around each page image on a printed sheet to help visually define the borders of each logical page.

Page Order

The **Page Order** drop-down menu contains four selections:

- **Right, then Down**
- **Down, then Right**

- **Left, then Down**
- **Down, then Left**

The preview document image changes to reflect alterations in these settings, as shown by the examples in the following illustration.




Figure 4-12 Page-order preview images

- **2 pages per sheet**
- **4 pages per sheet**
- **6 pages per sheet**
- **9 pages per sheet**
- **16 pages per sheet**

Document preview image

The document preview image is a line-drawn image of a page that represents graphics and text. The document preview image is always oriented so that the contents of the page are right-side-up. The document preview image appears in the upper-right corner of the **Paper/Quality**, **Effects**, **Finishing**, and **Basics** tabs.

Switching between tabs does not change the location or appearance of the document preview image. When you move the mouse over the document preview image, the mouse cursor changes from an arrow to a gloved hand. You can toggle between portrait and landscape page orientation by clicking the document preview image.

Print Quality

Print quality settings affect how light or dark the print is on the page and the style for printing graphics. You can also use the print quality settings to optimize the print quality for a specific media type.

The **Print Quality** group box contains the following controls:

- **Print Quality drop-down menu**
- **Print All Text as Black**
- **Economode**

Print Quality drop-down menu

You can change the setting to accommodate the type of job that you are printing. The following are the settings:

- **ProRes 1200** This setting uses ProRes 1200 to provide fine-line detail at 1200 x 1200 dpi.
- **FastRes 1200** This setting uses FastRes 1200 to provide 600 x 600 x 2. This is the default setting.
- **600 dpi** This setting provides 600 x 600 dpi.

Print All Text as Black

The **Print All Text as Black** feature is **Disabled** by default. When **Enabled** is selected, the driver prints all text as black regardless of the original document text color. Color text is printed as black, except for white text, which remains white. White text is a reliable method of printing reverse typeface against a dark background. This setting does not affect graphic images on the page, nor does it affect any text that is part of a graphic.

Economode

EconoMode is a feature that allows the product to use less toner per page. Selecting this option will extend the life of the toner supply and will reduce cost per page. However, it will also reduce print quality. The printed image is lighter, but it is adequate for printing drafts or proofs.

HP does not recommend the full-time use of EconoMode. If EconoMode is used full-time when the average toner coverage is significantly less than 5 percent, it is possible that the toner supply will outlast the mechanical parts in the print cartridge. If print quality begins to degrade under these circumstances, you must install a new print cartridge, even if there is toner supply remaining in the cartridge.

Basics tab features

The **Basics** tab provides options for setting the number of copies to be printed and the orientation of the print job. You can also use the **Basics** tab to retrieve information about the driver. The following illustration shows the **Basics** tab.




Figure 4-13 Basics tab

The **Basics** tab contains the following controls:

- **Quick Sets** group box
- **Copies** group box
- **Orientation** group box
- Document preview image
- **About** button

Quick Sets

Use the **Quick Sets** control to store the current combination of driver settings that are found on all of the other **Printing Preferences** driver tabs. Quick sets are either preset or user-defined printing specifications, such as media size and pages per sheet. For more information, see [Quick Sets](#) in the **Paper/Quality** tab section of this guide.

Copies group box

The **Copies** feature allows you to specify the number of copies to print.

The number of copies you request appears in the **Copies** box. You can select the number by typing in the box or by using the up and down arrows to the right of the edit box. Valid entries are numbers

from **1** to **999** . The copies value will not advance from the maximum number (999) to 1 when the up arrow is used, or change from 1 to the maximum number (999) when the down arrow is used. Invalid entries into the edit box (such as non-numerical input, numbers less than 1 or greater than the maximum allowed) are changed to the last valid value entered when you click on another group box or leave the **Basics** tab. The default number of copies is **1**.

Because you can set the number of copies that you want from some software programs, conflicts between the software program that you are using and the driver can arise. In most cases, the software program and the driver communicate, so that the number of copies set in one location (such as the program) will appear in the other (such as the driver). For some programs, this communication does not take place, and the copies values are treated independently. For these programs, setting 10 copies in the program and then setting 10 copies in the driver will result in 100 copies (10 x 10) being printed. It is recommended that you set the number of copies in the program wherever possible.

Orientation

Orientation refers to the layout of the image on the page, and does not affect the manner in which media is fed into the printer. You can specify the orientation of the print job.

Orientation can toggle between portrait and landscape by left-clicking the preview image. If you check **Rotate by 180 degrees**, there is no change in the preview image.

The **Orientation** group box contains the following options:

- **Portrait** option button
- **Landscape** option button
- **Rotated** check box

Portrait option button

Select this feature to print your document in **Portrait** orientation. This is the default setting.

Landscape option button

Select this feature to print your document in **Landscape** orientation.

Rotated check box

Select this feature to rotate the document image on the media 180 degrees. For example, if the return address on an envelope is smudged, try this setting and feed the envelope so that the return address area is fed first into the printer.

Document preview image

The document preview image is a line-drawn image of a page that represents graphics and text. The document preview image is always oriented so that the contents of the page are right-side up. The document preview image appears in the upper-right corner of the **Finishing**, **Effects**, and **Paper/Quality** tabs.

Switching between tabs does not change the location or appearance of the document preview image. When you move the mouse over the document preview image, the mouse cursor changes from an arrow to a gloved hand. You can toggle between portrait and landscape page orientation by clicking the document preview image.

About button

Click the **About** button on the **Basics** tab or select the HP logo on any of the driver property pages to open the **About** dialog box. To close the **About** box, click **OK**, press **ESC**, press **ALT + F4**, or press **ENTER**. The figure below shows the **About** box. The information varies according to HP LaserJet 1022 model number, driver, date, and versions.




Figure 4-14 About This Driver dialog box

Printer Properties tab set

The printer **Properties** tab set contains information about and options for configuring the printer. To gain access to the printer **Properties** tabs, click **Start** on the Windows task bar, click **Settings**, and then click **Printers** for Windows 2000 or **Printers and Faxes** for Windows XP. Right-click the product name, and then click **Properties**.

The following HP printer driver tab is included in the printer **Properties** tab set:

- **Configure** tab features



NOTE The printer **Properties** tab set also includes Windows-specific tabs. For information about those tabs, see the documentation that came with your computer.

Configure tab features

The **Configure** tab contains controls for




Figure 4-15 Configure tab

The **Configure** tab contains the following controls:

- **Quick Sets** group box
- **Jam Recovery** buttons
- **Status Messages** buttons
- **Cleaning Page**
- **Print Density** control
- **Courier Font Type** buttons

Quick Sets

Use the **Quick Sets** control to store the current combination of driver settings that are found on all of the other **Printing Preferences** driver tabs. Quick sets are either preset or user-defined printing specifications, such as media size and pages per sheet. For more information, see [Quick Sets](#) in the **Paper/Quality** tab section of this guide.

Jam Recovery

Select **On** to reprint a page if a paper jam occurs. Select **Off** to *not* reprint a page if a paper jam occurs. **Off** is the default setting.



NOTE Jobs print faster when **Off** is selected.

Status Messages

Select **On** to allow error messages to display on the computer screen during error conditions. Select **Off** to *not* allow error messages to display on the computer screen during error conditions. **On** is the default setting.



NOTE The paper-out message still appears when **Off** is selected

Cleaning Page

Click **Start** to launch the cleaning page process. This process cleans the product paper path and takes approximately two minutes to complete.

Print Density

Use this control to specify how much toner is put on the page. **3** is the default setting.

Courier Font Type

Select **Regular** to print any text by using TrueType Courier or Courier New with normal weight. Select **Dark** to print any text by using TrueType Courier or Courier New with a dark weight but without changing the font attributes in a program. **Regular** is the default setting.

Properties tab features - Windows 98 SE and Windows Me

In Windows 98 SE and Windows Me, click **Start**, select **Settings**, click **Printers**, right-click the product name, click **Properties**, and then click **Printing Preferences** to gain access to all of the print-driver tabs.

The following figure shows the **Properties** tabs in Windows 98 SE.




Figure 4-16 Properties tabs - Windows 98 SE

5 HP Embedded Web Server (HP LaserJet 1022n and HP LaserJet 1022nw printers only)

The HP Embedded Web Server (HP EWS) is a standard feature for the HP LaserJet 1022n and HP LaserJet 1022nw printers. The HP EWS provides a simple, easy-to-use solution for one-to-one product management. In offices that have a limited number of products, remote management of printing devices can be accomplished without installing any management software.

The HP EWS can be directly accessed on the HP LaserJet 1022n and HP LaserJet 1022nw printers. You do not need to install any software on the computer. You only need to have a supported Web browser. To use the HP EWS, you must have Apple Safari, Microsoft Internet Explorer V5.5 and later, or Netscape Navigator V4.75 and later.



NOTE The HP EWS does not provide e-mail or status alerts. The HP EWS is available in English only.

This chapter provides information about the following topics:

- [Using HP Embedded Web Server \(EWS\)](#)
- [HP EWS tabs](#)

Using HP Embedded Web Server (EWS)

The HP EWS allows you to view product and network status and to manage printing functions from your computer instead of from the product control panel. Below are examples of what you can do using the HP EWS:

- View product status information.
- View and print internal pages.
- Order new supplies.
- Set the type of paper loaded in each tray.
- View and change the product default configuration settings.
- View and change network configuration.

The HP EWS works when the product is connected to an IP-based network. The HP EWS does not support IPX-based product connections.



NOTE You do not have to have Internet access to open and use the HP EWS. However, if you click a link in the **Other Links** area, you must have Internet access to go to the site associated with the link.

To open the HP Embedded Web Server

- 1 In a supported Web browser, type the TCP/IP address or the hostname for the product. To find the TCP/IP address, print a Configuration page at the product by pressing and holding the **GO** button for 5 seconds.



NOTE Once you open the URL, you can bookmark it so that you can return to it quickly in the future.

- 2 The HP Embedded Web Server has three tabs that contain settings and information about the product: the **Information** tab, the **Settings** tab, and the **Networking** tab. Click the tab that you want to view.

HP EWS tabs

Each screen in the HP EWS has a frame that contains a top banner, category tabs, a left-aligned navigation menu bar, and a main-content area. Selecting one of the category tabs causes the corresponding left-aligned navigation bar to appear. The left-aligned navigation menu includes links to content that is appropriate for that tab. The main-content area shows information and opens options in response to navigation tab selections and menu bar selections.

Information tab

The **Information** tab contains the following pages:

- **Device Status** page
- **Configuration** page

Device Status page

The **Device Status** page shows product status, network identification information and basic product information.



Figure 5-1 Device Status page

Device Configuration page

The **Device Configuration** page shows the values of all of the product settings and other configuration settings.

HP LaserJet 1022n

Information Settings Networking

Device Status
Configuration

Other Links
[HP Instant Support](#)
[Product Registration](#)
[Order Supplies](#)
[Product Support](#)

Device Configuration

Product Information

Product Name:	HP LaserJet 1022n
Formatter Number:	
Product Serial Number:	FM00122
Service ID:	05033
Firmware Datecode:	20041129
Total Memory:	8 MBytes
Max Monochrome Print Quality:	ProRes 1200

Network Information

Host Name:	NPI4710CA
Hardware Address:	0012794710CA
Link Settings:	100TX Full
IP Configured By:	Manual
IP Address:	63.230.114.51
IP Subnet Mask:	255.255.255.0
IP Default Gateway:	63.230.114.1
WINS Configured By:	Manual
Preferred WINS Server:	63.230.114.15
Total Packets Received:	7618
Unicast Packets Received:	196
Broadcast Packets Received:	7422
Bad Packets Received:	0
Total Packets Transmitted:	235
Unicast Packets Transmitted:	213
Broadcast Packets Transmitted:	23
Bad Packets Transmitted:	0

Print Settings

Jam Recovery:	Off
IO Timeout:	120
Symbol Set:	PC8
Font:	0
Default Paper Size:	Letter
Economode:	Off
Print Density:	3

Figure 5-2 Device Configuration page

Settings tab

The **Settings** tab contains the **Print Settings** page.

Print Settings page

Use the **Print Settings** page to configure the print settings and the PCL settings for the product.



NPI4710CA/

HP LaserJet 1022n

Information

Settings

Networking

Print Settings

Print Settings

Other Links

[HP Instant Support](#)
[Product Registration](#)
[Order Supplies](#)
[Product Support](#)

Print Settings

Density: ▼

Jam Recovery: ▼

Auto Continue: ▼

IO Timeout: (5-255)

Restore Factory Settings:

PCL Settings

Default Paper Size: ▼

Orientation: ▼

Manual Feed: ▼

Copies: (1-999)

Font Number: (0-25)

Font Pitch: (0.44-99.99)

Font Point Size: (4-999.75)

Symbol Set: ▼

Form Length: (5-128)

Economode: ▼

Apply

Figure 5-3 Print Settings page

Networking tab

The **Networking** tab contains the following pages:

- **IP Configuration** page
- **Advanced** page
- **mDNS** page
- **Password** page

IP Configuration page

Use the **IP Configuration** page to configure the TCP/IP address and the WINS server address for the product.

The screenshot displays the HP Embedded Web Server interface for an HP LaserJet 1022n printer. The page is titled "IP Configuration" and is part of the "Networking" tab. It includes a warning message: "Warning: A change in the IP Address will result in loss of connectivity to the browser." The "Host Name" field is set to "NP14710CA". Under "IP Address Configuration", the "Manual IP" option is selected. The "Manual IP Address" is set to "63.230.114.51", the "Manual Subnet Mask" is "255.255.255.0", and the "Manual Default Gateway" is "63.230.114.1". Under "WINS Address Configuration", the "Manual WINS Server" option is selected, with the "Manual Preferred WINS Server" set to "63.230.114.15". The page concludes with "Apply" and "Cancel" buttons.

Figure 5-4 IP Configuration page

Advanced page

Use the **Advanced** page to configure advanced network settings for the product.




Figure 5-5 Advanced page

mDNS page

mDNS is used on small networks for IP address and name resolution where a conventional DNS server is not available. Use the **mDNS** page to configure mDNS settings for the product.




Figure 5-6 mDNS page

Password page

Use the **Password** page to set or change the administrator password for the product.

The screenshot shows the HP Embedded Web Server interface for an HP LaserJet 1022n printer. The top navigation bar includes 'Information', 'Settings', and 'Networking'. The 'Networking' section is expanded to show 'IP Configuration', 'Advanced', 'mDNS', and 'Password'. The 'Password' page is selected, displaying instructions: 'Use the fields below to set or change the Administrator Password. When set, the Administrator Password will be required before you can access and change configuration parameters. To disable the Administrator Password, leave the entries blank.' The 'User Name' field is set to 'Admin'. There are two password input fields: 'Password' and 'Confirm Password', both masked with dots. 'Apply' and 'Cancel' buttons are located at the bottom right of the page.

Figure 5-7 Password page

Other links

The following links are also available through the HP EWS:

- **HP Instant Support**
- **Product Registration**
- **Order Supplies**
- **Product Support**

HP Instant Support

This link connects you to a set of dynamic Web pages to solve specific problems and to determine what additional services are available for the product.

Product Registration

This link connects you to the product registration page on the HP Web site.

Order Supplies page

This link connects you to the HP Web site to order genuine HP supplies from HP or a reseller of your choice.

Product Support page

This link connects you to the support site for the HP LaserJet 1022 series printer. You can search for help regarding general topics.

6 Windows software installation



NOTE This chapter covers information about the HP LaserJet 1022 printing-system software for Windows. For information about Macintosh installations, see [Macintosh software overview and installation](#).

This chapter provides information about the following topics:

- [Installation overview](#)
- [Installation options](#)
- [Installation dialog-box options for Windows](#)
- [Uninstall](#)

Installation overview

The software for the HP LaserJet 1022 Series printer is shipped on one CD. On Windows systems, the Setup program installs the HP LaserJet 1022 printing-system software from the CD onto the hard disk and updates the Windows files.

On all of the supported platforms, a series of query dialog boxes guides you through the installation process. You are asked to provide information about your computer environment. The Installer guides you through the installation, whether you are configuring a directly-connected or a networked product.

Installation options

The HP LaserJet 1022 printing-system software can be used in the following configurations:

- You install the HP LaserJet 1022 printing-system software on a computer that is directly connected to the product through a USB port. On Windows systems, you can share your HP LaserJet 1022 Series printer with other users on your network.
- The HP LaserJet 1022 Series printer is directly connected to a computer and you install only the printer driver.
- You install the HP LaserJet 1022 printing-system software on a computer that has access to a local area network (LAN). The HP LaserJet 1022n and HP LaserJet 1022nw printers connect to a LAN through an internal HP network port.

HP recommends that you install the software before connecting the product to the computer (software-first installation). However, if the product is already connected to the computer, you can install the software by using the Plug-n-Play method or by using the Add Printer Wizard. For more information, see [Plug-n-Play](#) and [Add Printer Wizard](#).

Windows installation for direct connections

Use the following instructions to install the product software on a computer that is running Windows 98 SE, Windows Me, Windows 2000, or Windows XP (32-bit only).



NOTE Set up and turn on the product before installing the printing-system software. Do not connect the product to the computer until the software installation program prompts you to do so.

NOTE You must have administrator privileges to install the printing-system software on Windows 2000 or Windows XP.

- 1 Close all of the programs that are open on the computer.
- 2 Insert the HP LaserJet 1022 printing-system software CD into the CD-ROM drive.



NOTE If your CD does not start automatically, click **Start**, click **Run**, and then browse to and double-click the SETUP.EXE file in the root directory of the CD.

- 3 Click **Next** and follow the onscreen prompts.
- 4 When the installation is nearly complete, the **Finish** dialog box appears and you can print a test page. Click the **Print Test Page** check box, and then click **Finish** to finish the installation and print a test page.
- 5 If you are prompted to restart your computer, click **Yes**.

Setting up Windows sharing (peer-to-peer networking)



NOTE This section describes procedures for sharing a product using Microsoft Windows Sharing (peer-to-peer networking). Peer-to-peer networking is a feature of Microsoft operating systems, not of HP print drivers. If these procedures are not successful, or for more information about peer-to-peer networking procedures, contact Microsoft at the following Web site: www.microsoft.com

This section contains instructions for using Windows sharing to make the product available to network users when the product is directly connected to a host computer.



NOTE Using Windows sharing, the person using the computer directly connected to the product can allow other users on the network to print to the product.

When the product is shared, install the printer drivers on all of the computers that you want to print to the product.

When you have set up the host computer to share your product, you must also configure the client computers. Perform the following steps at the computers of all other network users who want to print to the product.

Setting up the host computer running Windows 98 SE, Windows Me, or Windows 2000

At the computer that is directly connected to the product, perform the following steps:

- 1 Click **Start**, click **Settings**, and then click **Printers**.
- 2 In the printer list, right-click the icon for your HP LaserJet 1022 Series printer, and then click **Sharing**.



NOTE If **Sharing** does not appear on the right-click menu, you must first enable printer sharing for Windows 98 SE or Windows Me. Follow these steps:

1. Click **Start**, click **Settings**, and then click **Control Panel**.
 2. Double-click the **Network** icon.
 3. On the **General** tab, click **File and Print Sharing**.
 4. Click the **I want to be able to allow others to print to my printers check box**, and then click **OK**.
 5. Click **OK** again, and then close the **Control Panel**. If you are prompted to restart your computer, click **Yes**.
-

- 3 On the **Sharing** tab, click the **Share As** option button, and then type a name for the product in the **Share Name** field. Click **OK**.

Setting up the host computer running Windows XP

At the computer that is directly connected to the product, perform the following steps:

- 1 Click **Start**, and then click **Printers and Faxes**.
- 2 In the printer list, right-click the icon for your HP LaserJet 1022 Series printer, and then click **Sharing**.
- 3 On the **Sharing** tab, click the **Share this printer** option button, and then type a name for the product in the **Share Name** field. Click **OK**.
- 4 Click the **Ports** tab. Click to clear the **Enable bidirectional support** check box, and then click **OK**.

Setting up client computers running Windows 98 SE, Windows Me, or Windows 2000

- 1 Click **Start**, click **Settings**, and then click **Printers**.
- 2 Double-click the **Add Printer** icon to open the **Add Printer** wizard.
- 3 Click **Next** to start the wizard.
- 4 Click the **Network Printer** option button, and then click **Next**.
- 5 Type in the path and share name of the HP LaserJet 1022 Series printer to which you want to connect.

- OR -

Click **Browse** and navigate to find the HP LaserJet 1022 Series printer to which you want to connect.

Click **Next**.

- 6 Click the **Yes** or **No** option button when asked if you want to use this product as your default printer for Windows-based programs, and then click **Next**.
- 7 Click **Finish** to complete the installation and close the **Add Printer** wizard.



NOTE You might need the product software CD to complete the printer driver installations.

Setting up client computers running Windows XP

- 1 Click **Start**, and then click **Printers and Faxes**.
- 2 On the left-hand column, under **Printer Tasks**, click **Add a printer** to open the **Add Printer** wizard.
- 3 Click **Next** to start the wizard.
- 4 Click the **A network printer or a printer attached to another computer** option button, and then click **Next**.
- 5 Type in the path and share name of the HP LaserJet 1022 Series printer to which you want to connect.

- OR -

Click **Browse** and navigate to find the HP LaserJet 1022 Series printer to which you want to connect.

Click **Next**.

- 6 Click the **Yes** or **No** option button when asked if you want to use this product as your default printer for Windows-based programs, and then click **Next**.
- 7 Click **Finish** to complete the installation and close the **Add Printer** wizard.

Installation instructions for networked computers

This section provides information about the following topics:

- Installing the software on networked computers (HP LaserJet 1022n and HP LaserJet 1022nw printers only)
- Installing the print driver only

Installing the software on networked computers (HP LaserJet 1022n and HP LaserJet 1022nw printers only)

Each computer that has the HP LaserJet 1022 printing-system software installed can use all of the product features that are available over a network connection through the internal network port that comes as standard equipment on the HP LaserJet 1022n and HP LaserJet 1022nw models.

To install the HP LaserJet 1022 printing-system software on networked Windows operating systems, follow these steps:



NOTE You must have administrator privileges to install the software on Windows 2000 or Windows XP.

- 1 Close all of the programs that are open on the computer.
- 2 Insert the HP LaserJet 1022 printing-system software CD into the CD-ROM drive.



NOTE If the CD does not start automatically, click **Start**, click **Run**, and then browse to and double-click the HPSETUP.EXE file in the root directory of the CD.

- 3 Click **Next** and follow the onscreen prompts.
- 4 When the Installer software prompts you to select how the product will be connected, select **Connected via the network**, and then click **Next**. Follow the instructions on the screen.
- 5 When the installation is nearly complete, a setup screen appears that asks whether or not you want to print a test page. Click **Yes**.
- 6 If you are prompted to restart the computer, click **Yes**.

Installing the printer driver only



NOTE If the product is directly connected to another user's computer, the product must be shared from that computer by using Windows sharing.

Use the following instructions to install the printer driver only.

Printer-driver installation for Windows 98 SE

- 1 From the **Start** menu, click **Settings**, and then click **Printers**.
- 2 Double-click **Add Printer**, and then click **Next**.
- 3 When asked if the product is a local or network printer, click **Network Printer**, and then click **Next**.
- 4 Click **Have Disk** from the wizard screen that appears.

- 5 Insert the CD into the CD-ROM drive. Navigate to the X:\<language>\DRIVERS folder (where X is the letter of your CD-ROM drive and <language> is your chosen installation language).
- 6 Double-click the .INF file that you find in that folder.
- 7 Complete the installation. When prompted, print a test page to ensure that the printer driver is installed properly.

Printer-driver installation for Windows 2000 or XP

- 1 From the **Start** menu, click **Settings**, and then click **Printers**.



NOTE For Windows XP, click **Start**, and then click **Printers and Faxes**.

- 2 Double-click **Add Printer**, and then click **Next**.
- 3 When asked if the product is a local or network printer, click **Network Printer**, and then click **Next**.
- 4 You might need to first select the printer from the list of printers or type an IP address. If the printer driver is not available, the **Add Printer Wizard** dialog box appears. Click **Have Disk** from the wizard screen.
- 5 Insert the CD into the CD-ROM drive. Navigate to the X:\<language>\DRIVERS folder (where X is the letter of your CD-ROM drive and <language> is your chosen installation language).
- 6 Double-click the .INF file that you find in that folder.
- 7 Complete the installation. When prompted, print a test page to ensure that the printer driver is installed properly.

Plug-n-Play

If the product is already connected to a computer when you begin installing the software, Windows automatically detects the product and uses Plug-n-Play to install the product. During this process, Plug-n-Play calls the Add Printer Wizard to automatically install the printer driver and the USB port. At the end of the Add Printer Wizard, you are given the option to install the additional support files.

Add Printer Wizard



NOTE This procedure is not recommended if you are using Windows 98 SE or ME because the Add Printer Wizard does not install the USB port for these operating systems.

If the product is already connected to a computer when you begin installing the software, Windows automatically detects the product and uses Plug-n-Play to install the printer driver. If you prefer, you can cancel Plug-n-Play and run the Add Printer Wizard manually to install the printer driver. At the end of the Add Printer Wizard, you are given the option to install the additional support files.

If you are using Windows 98 SE or ME, you must also unplug the USB cable from the product and then plug it in again so that Windows can use Plug-n-Play to install the USB port.

Installation dialog-box options for Windows

HP recommends that you install the software before connecting the product to the computer. However, it is possible to install the software if the product is already connected by using Plug-n-Play and the Add Printer Wizard. The following sections show the dialog box options that appear during the HP LaserJet 1022 printing-system software installation on Windows operating systems.

Installing the software before the printer is connected to the computer



NOTE HP recommends that you install the software before connecting the HP LaserJet 1022 Series printer to the computer (software-first installation). These instructions are for a software-first installation.

These instructions are intended to be used the first time that you install the HP LaserJet 1022 printing-system software.




Figure 6-1 Step 1 - CD Browser screen

This dialog box includes three command buttons that lead to three different paths:

Documentation. Click this link to launch your Web browser and go to the **Hewlett-Packard LaserJet 1020 Series Products Software Readme File** .

Next takes you to the **Software License Agreement** screen (Step 2).




Figure 6-2 Step 2 - HP Software License Agreement screen

Back returns you to the **Welcome** dialog box (Step 1).

Yes takes you to the **Model** dialog box (Step 3).

No takes you to the **Exit Setup** dialog box (Step 18).




Figure 6-3 Step 3 - Model Selection screen

Back returns you to the **Software License Agreement** screen (Step 2).

If you click **HP LaserJet 1020** or **HP LaserJet 1022**, **Next** takes you to the **Start Copying Files** dialog box (Step 13).

If you click **HP LaserJet 1022n** or **HP LaserJet 1022nw**, **Next** takes you to the **Printer Connection** dialog box (Step 4).

Cancel takes you to the **Exit Setup** dialog box (Step 18).




Figure 6-4 Step 4 - Printer Connection screen

If you click **Connected directly to this computer** (a direct connection), **Next** causes the Installer to look for new hardware, and then takes you to the **Start Copying Files** dialog box (Step 13).

If you click **Connected via the network** or **Connected via wireless**, **Next** takes you to the **Identify Printer** dialog box (Step 5).



NOTE The **Connected via wireless** option is available for the HP LaserJet 1022nw model only.

Back returns you to the **Model** dialog box (Step 3).

Cancel takes you to the **Exit Setup** dialog (Step 18).




Figure 6-5 Step 5 - Identify Printer screen



NOTE If you are installing a direct-connection to the printer, go to Step 13.

Clicking the **Search from a list of detected printers (recommended)** option, and then clicking **Next** takes you to the **Notice about Firewalls** dialog box (Step 6).

Clicking the **Specify a printer by address** option, and then clicking **Next** takes you to the **Specify Printer** dialog box (Step 12).

Help initiates the online Help system.

Back returns you to the **Printer Connection** dialog box (Step 4).

Cancel takes you to the **Exit Setup** dialog box (Step 18).



Figure 6-6 Step 6 - Firewalls screen

Back returns you to the **Identify Printer** dialog box (Step 5).

Next takes you to the **Printer Found** dialog box (Step 7).

Cancel takes you to the **Exit Setup** dialog box (Step 18).




Figure 6-7 Step 7 - Printer Found screen

Clicking the **Yes, install this printer.** option button, and then clicking **Next** takes you to the **Confirm Settings** dialog box (Step 8).

Clicking the **No, install a different printer.** option button, and then clicking **Next** takes you to the **Check Cable Connection** dialog box (Step 11).

Help initiates the online Help system.

Back returns you to the **Identify Printer** dialog box (Step 5).

Cancel takes you to the **Exit Setup** dialog box (Step 18).



NOTE If more than one HP LaserJet 1022 Series printer is installed on the network, a list will appear from which you can select the specific HP LaserJet 1022 Series printer that you want to connect to.




Figure 6-8 Step 8 - Confirm Settings screen

Next takes you to the **Start Copying Files** dialog box (Step 13).

Clicking **Change TCP/IP Settings** takes you to the **Confirm Changing Setting** dialog box (Step 9).

Help initiates the online Help system.

Back returns you to the **Printer Found** dialog box (Step 7).

Cancel takes you to the **Exit Setup** dialog box (Step 18).




Figure 6-9 Step 9 - Confirm Changing Setting screen

Clicking **Yes** and then clicking **Next** takes you to the **Set Network Protocol** dialog box (Step 10).

Clicking **No** and then clicking **Next** takes you to the **Start Copying Files** dialog box (Step 13).

Help initiates the online Help system.

Back returns you to the **Confirm Settings** dialog box (Step 8).

Cancel takes you to the **Exit Setup** dialog box (Step 18).




Figure 6-10 Step 10 - Set Network Protocol screen

Clicking the **Network Protocol** drop-down menu displays a list of network protocols for you to choose from.

Clicking **Change Settings** allows you to change the network settings.

Next takes you to the **Start Copying Files** dialog box (Step 13).

Help initiates the online Help system.

Back returns you to the **Confirm Changing Setting** dialog box (Step 9).

Cancel takes you to the **Exit Setup** dialog box (Step 18).



NOTE Use this screen to configure an unconfigured network card.




Figure 6-11 Step 11 - Check Cable Connection screen

Clicking the **Search again** option button, and then clicking **Next** searches the network again and then takes you to the **Printer Found** dialog box (Step 7).

Clicking the **Specify a printer by address** option button, and then clicking **Next** takes you to the **Specify Printer** dialog box (Step 12).

Help initiates the online Help system.

Back returns you to the **Set Network Protocol** dialog box (Step 10).

Cancel takes you to the **Exit Setup** dialog box (Step 18).




Figure 6-12 Step 12 - Specify Printer screen

Entering any of the addresses and then clicking **Next** takes you to the **Printer Found** dialog box (Step 7).

Help initiates the online Help system.

Back returns you to the **Specify Printer** dialog box (Step 12).

Cancel takes you to the **Exit Setup** dialog box (Step 18).




Figure 6-13 Step 13 - Start Copying Files screen

Clicking **Next** starts the installation process and takes you to the **Installation Status** dialog box (Step 14).

Back returns you to the **Specify Printer** dialog box (Step 13).

Cancel takes you to the **Exit Setup** dialog (Step 18).




Figure 6-14 Step 14 - Installation Status screen



NOTE During the installation process, the status bar refreshes several times.




Figure 6-15 Step 15 - USB Cable Connect screen

Back returns you to the **Start Copying Files** dialog box (Step 13).




Figure 6-16 Step 16 - Finish screen

The **Register LaserJet 1020 series Online** and **Print Test Page** check boxes are selected by default.

Clicking **Finish** with the **Register LaserJet 1020 series Online** check box selected closes the Install wizard, opens your Web browser, and then takes you to the HP Web Registration Web site.

Clicking **Finish** with the **Print Test Page** check box selected closes the Install wizard and prints a test page.

Clearing both check boxes and clicking **Finish** closes the Install wizard.




Figure 6-17 Step 17 - Registration screen



Figure 6-18 Step 18 - Exit Setup screen

Yes cancels the print-driver installation.

No returns you to the last open screen of the installer.

Installing the software when the printer is already connected to a computer

If the product is already connected to a computer when you begin installing the software, Windows automatically detects the product and uses Plug-n-Play to install the printer driver. During this process, Plug-n-Play calls the Add Printer Wizard to automatically install the printer driver and the USB port. When Plug-n-Play completes, you are given the option to install the additional support files.

If you prefer, you can cancel Plug-n-Play and run the Add Printer Wizard manually to install the printer driver. This procedure is not recommended if you are using Windows 98 SE or Me because the Add Printer Wizard does not install the USB port for these operating systems. If you are using Windows 98 SE or Me, when the Add Printer Wizard completes you must unplug the USB cable from the product and then plug it in again so that Windows can use Plug-n-Play to install the USB port.

At the end of the Add Printer Wizard, you are given the option to install the additional support files.

This section shows the dialog box options that appear during the Add Printer Wizard.



Figure 6-19 Step 1 - Add Printer Wizard Welcome Screen

Next takes you to the **Local or Network Printer** dialog box.

Cancel exits the Add Printer Wizard.




Figure 6-20 Step 2 - Local or Network Printer screen

Select **Local printer** if the product is connected directly to your computer.

Select **Automatically detect and install my Plug and Play printer** to have Windows automatically set up the product.

Select **Network printer** if the product is connected to a network.

Back returns you to the Welcome screen (Step 1).

Next takes you to the **Select the Printer Port** screen (Step 3).

Cancel exits the Add Printer Wizard.




Figure 6-21 Step 3 - Select the Printer Port screen

Select **Use the following port** to use an existing port on your computer.

Select **Create a new port** to add a new port.

Click **Next** to continue.




Figure 6-22 Step 4 - Manufacturer and model screen

Click **Have Disk...** to install the software from the CD-ROM.




Figure 6-23 Step 5 - Install from Disk

Click **Browse** to begin searching for the driver file that is on the CD-ROM.



Figure 6-24 Step 6 - Select the correct language

Click the folder for the correct language, and then click **Open**.




Figure 6-25 Step 7 - Select the .INF file

Click the **HPLJ1020.INF** file, and then click **Open**.




Figure 6-26 Step 8 - Install from Disk, screen 2

Click **OK** to continue.




Figure 6-27 Step 9 - Manufacturer and model screen 2

Select the correct HP LaserJet 1022 Series printer model.

Click **Next** to continue.




Figure 6-28 Step 10 - Name Your Printer screen

Type a name for the product.

Click **Next** to continue.




Figure 6-29 Step 11 - Printer Sharing screen

- Select **Do not share this printer** if only one computer will use the product.
- Select **Share as:** to enable Windows sharing (peer-to-peer networking)
- Click **Next** to continue.




Figure 6-30 Step 12 - Print Test Page screen

Select **Yes** to print a test page after the software is installed.

Select **No** if you do not want to print a test page.

Click **Next** to continue.



Figure 6-31 Step 13 - Completing the Add Printer Wizard screen

Click **Finish** to complete the Add Printer Wizard.

Uninstall

This section provides information about the following topics:

- [Uninstall instructions for Windows](#)

Uninstall instructions for Windows

Choose one of the following two methods to uninstall the HP LaserJet 1022 printing-system software:

- Uninstalling using the HP program group (recommended)
- Uninstalling using the Windows Add/Remove Program feature

Uninstalling using the HP program group (recommended)



NOTE To uninstall the software from Windows 2000 or XP, you must log on with administrator privileges.

- 1 Close all of the programs that are open on the computer.
- 2 Click **Start**, click **Programs**, select **HP**, select **HP LaserJet 1020 series**, and then click **Uninstall LaserJet 1020 series**.
- 3 The **Welcome to the LaserJet 1020 series uninstall Wizard** dialog box appears.




Figure 6-32 Welcome to the LaserJet 1020 series uninstall Wizard dialog box

Click **Next** to continue.

- 4 The **LaserJet 1020 series printer driver uninstall information.** dialog box appears.




Figure 6-33 Remove the Program dialog box

Click **Next** to begin the uninstall process.

- 5 The **Uninstalling the HP LaserJet 1020 series** dialog box appears.




Figure 6-34 Uninstalling the HP LaserJet 1020 series dialog box

The progress bar reflects the status of the uninstall process.

- 6 The **Restart** dialog box appears.




Figure 6-35 Restart dialog box

Click **Yes, I want to restart my computer now.** to restart your computer and finish the uninstall process.

Uninstalling using Windows Add/Remove programs feature

Follow these steps to uninstall the HP LaserJet 1022 printing-system software by using the Windows **Add/Remove programs** feature.



NOTE Using this uninstall method, you do not need the HP LaserJet 1022 printing-system software CD.

NOTE To uninstall the software from Windows 2000 or XP, you must log on with administrator privileges.

- 1 Close all of the programs that are open on the computer.

- 2 For Windows 98 SE, Windows Me, or Windows 2000, click **Start**, click **Settings**, click **Control Panel**, and then double-click **Add/Remove programs**

For Windows XP, click **Start**, click **Control Panel**, and then double-click **Add/Remove programs**.



Figure 6-36 Windows Control Panel

- 3 Click **Change or Remove Programs**, click **LaserJet 1020 series**, and then click **Change/Remove**.




Figure 6-37 Windows Change or Remove programs

- 4 The **Remove the Program** dialog box appears.




Figure 6-38 Remove the Program dialog box

Click **Next** to begin the uninstall process.

- 5 The **Uninstalling the HP LaserJet 1020 series** dialog box appears.




Figure 6-39 Uninstalling the HP LaserJet 1020 series dialog box

The progress bar reflects the status of the uninstall process.

- 6 The **Restart** dialog box appears.




Figure 6-40 Restart dialog box

Click **Yes, I want to restart my computer now.** to restart your computer and finish the uninstall process.

This uninstall method does not automatically remove the HP Software Update utility. To remove the HP Software Update utility, click **No, I will restart my computer later.** here and then follow the instructions in the [Removing the HP Software Update utility](#) section.

Removing the HP Software Update utility

Follow these instructions to remove the HP Software Update utility from your computer.

- 1 For Windows 98 SE, Windows Me, or Windows 2000, click **Start**, click **Settings**, click **Control Panel**, and then double-click **Add/Remove programs**.
For Windows XP, click **Start**, click **Control Panel**, and then double-click **Add/Remove programs**.
- 2 Click **Change or Remove programs**, click **HP Software Update**, and then click **Remove**.
- 3 The **Remove the Program** dialog box appears. Click **Remove** to begin the uninstall process.
- 4 The **Uninstalling the HP LaserJet 1020 series** dialog box appears. The progress bar reflects the status of the uninstall process.
- 5 When the uninstall process is completed, the **Finish** dialog box appears. Click **Finish** to continue.
- 6 The **Restart** dialog box appears. Click **Yes** to restart your computer and finish the uninstall process.

Index

Symbols/Numerics

% of Normal Size option 61

A

About button 74
Add Printer Wizard 93, 109
administrator Quick Sets 49
Advanced page, EWS 84
Apple Macintosh. See Macintosh
applications, driver settings 46

B

back cover, paper for 56
Basics tab 71
bidirectional communication
 device conflicts, troubleshooting 25
 Windows operating systems supported 15
binding options 67
black, printing text as 71
Booklet Layout settings 68
both sides, printing on 67

C

cable connection screen 104
cartridges, page capacities 3
CD
 directory structure, Macintosh 29
 directory structure, Windows 5
 languages 5
 ordering 7
 ordering for Macintosh 32
CD Browser screen 94
Check cable connection screen 104
components, software
 Macintosh 29
 Windows 14

Configure tab 74
Confirm Changing Setting screen 102
Confirm Settings screen 101
conflicts, device 25
connection type, Windows installation dialog box 97
connection types 23
constraint messages 47
context-sensitive Help 47
Copies, number of 72
covers, different paper for 56
custom paper sizes 51
customer support
 HP Instant Support page, EWS 86
 Product Support page, EWS 86

D

Device Configuration page, EWS 81
device conflicts 25
Device Settings page, EWS 81
dialog boxes, Macintosh installation 37
dialog boxes, Windows installation
 CD Browser 94
 Check cable connection 104
 Confirm Changing Setting 102
 Confirm Settings 101
 Exit Setup 108
 Finish 107
 Firewalls screen 99
 HP Software License Agreement 95
 Identify Printer 98
 Installation Status 106
 Model Selection 96
 Printer Connection 97
 Printer Found 100

Registration 108
Set Network Protocol 103
Specify Printer 105
Start Copying Files 106
USB Cable Connect 107
direct connections 23
directory structure, CD
 Macintosh 29
 Windows 5
Document Options 66
document preview image 59
documentation
 CD directory structure 29
 localized versions 8
 operating systems supported 15, 30
dots per inch (dpi)
 settings 70
 specifications 3
double-sided printing 67
dpi (dots per inch)
 settings 70
 specifications 3
drivers
 Help system, Windows 46
 installing Windows 92
 localized versions 15, 30
 Macintosh 30
 operating systems supported 14, 30
 settings, accessing 46
 version number 74
duplexing (manually) 67

E

Easy Install option, Macintosh 34
EconoMode 70
Effects tab 59
EWS
 Advanced page 84

- Device Configuration page 81
- Device Settings page 81
- HP Instant Support page 86
- Information tab 81
- IP Configuration page 84
- mDNS page 85
- Networking tab 84
- Order Supplies page 86
- Password page 86
- Print Settings page 82
- Product Registration page 86
- Product Support page 86
- Settings tab 82
- Exit Setup screen 108
- F**
- FastRes settings 70
- features
 - model comparison 3
 - Windows printing-system software 14
- files, included on installation CD
 - Macintosh 29
 - Windows 5
- Finish screen 107
- Finishing tab 65
- Firewalls screen 99
- first page out 3
- first page, paper for 56
- Fit to Page options 60
- Flip Pages Up 67
- fulfillment centers 7, 32
- H**
- Help
 - localized versions 15
 - Macintosh 30
 - operating systems supported 15, 30
 - Windows driver 46
- host-based driver
 - Help system, Windows 46
 - installing Windows 92
 - localized versions 15, 30
 - Macintosh 30
 - operating systems supported 14, 30
 - settings, accessing 46
 - version number 74
- HP Instant Support page, EWS 86
- HP Print Screen utility 19
- HP Software License Agreement screen 95
- HP Software Update Utility 17
- HP Software Update utility 125
- I**
- Identify Printer screen 98
- in-box file layout
 - Macintosh 29
 - Windows 5
- inches, settings 54
- Information tab, EWS 81
- installation
 - dialog boxes, Macintosh 37
 - dialog boxes, Windows 94
 - driver-only 92
 - Macintosh software 34
 - networks, Macintosh 35
 - networks, Windows 92
 - Windows software 88, 89
- installation notes 15
- Installation Status screen 106
- installers
 - localized versions 15
 - Macintosh 30
 - Windows, included 14
 - Windows, new features 14
- IP Configuration page, EWS 84
- L**
- landscape orientation
 - Flip Pages Up 67
 - settings 73
- languages, localized versions
 - CDs 5
 - documentation 8
 - HP Print Screen utility 21
 - key to abbreviations 15, 16
 - Macintosh software components 30
 - ordering software 7
 - software components 15
- license agreement
 - Macintosh 39
 - Windows 95
- Linux support 13
- localized versions
 - CDs 5
 - documentation 8
- HP Print Screen utility 21
- key to abbreviations 15, 16
- Macintosh software
 - components 30
 - ordering software 7
 - software components 15
- M**
- Macintosh
 - components, software 29
 - dialog boxes, installation 37
 - directory structure on installation CD 29
 - installers 30
 - installing software 34
 - networks, installing software 35
 - operating systems supported 28
 - PDEs 29
 - PPDs 30
 - software license agreement 39
 - system requirements 33
- manuals
 - localized versions 8
 - operating systems supported 15, 30
- mDNS page, EWS 85
- measurement units 54
- media
 - & of Normal Size option 61
 - custom sizes 51
 - Fit to Page options 60
 - Pages per Sheet 69
 - Paper Options 50
 - Paper/Quality tab 48
 - Print Document On settings 60
 - Print on Both Sides (Manually) 67
 - Scale to Fit option 60
 - Size is settings 50
 - Source is 55
 - tray capacities 3
 - Type is settings 55
 - Use different paper options 56
- memory
 - Macintosh system requirements 33
 - product, included 3
 - Windows system requirements 12

- Microsoft Windows. See Windows
- millimeters, settings 54
- Model Selection screen 96
- models, feature comparison 3
- N**
- Networking tab, EWS 84
- networks
 - features available 23
 - installing software, Windows 92
 - Macintosh, installing software 35
 - peer-to-peer, setting up 89
 - ports 3
 - Set Network Protocol screen 103
- number of copies 72
- O**
- O/S2 support 13
- operating systems supported
 - Macintosh 28
 - UNIX, Linux, and OS/2 13
 - Windows 12
- Order Supplies page, EWS 86
- ordering software 7, 32
- orientation
 - Flip Pages Up 67
 - settings 73
- P**
- page orientation
 - Flip Pages Up 67
 - settings 73
- pages per minute 3
- Pages per Sheet settings 69
- paper
 - & of Normal Size option 61
 - custom sizes 51
 - Fit to Page options 60
 - Pages per Sheet 69
 - Print Document On settings 60
 - Print on Both Sides (Manually) 67
 - Scale to Fit option 60
 - Size is settings 50
 - Source is 55
 - tray capacities 3
 - Type is settings 55
 - Use different paper options 56
- paper handling features 3
- Paper Options 50
- Paper/Quality tab 48
- parallel ports, not supported 4
- part numbers
 - documentation 8
 - software CDs 7
- Password page, EWS 86
- PDEs (Printer Dialog Extensions) 29
- peer-to-peer networking 23, 89
- Percent of Normal Size option 61
- Plug-n-Play 93, 109
- portrait orientation
 - Flip Pages Up 67
 - settings 73
- ports
 - connecting 25
 - device conflicts 25
 - operating systems supported 4
 - specifications 3
- PPDs
 - localized versions 30
- preview image 59
- Print All Text as Black 71
- print cartridges, page capacities 3
- Print Document On settings 60
- Print on Both Sides (Manually) 67
- Print Quality tab 70
- Print Screen utility 19
- Print Settings page, EWS 82
- Printer Connection screen 97
- Printer Dialog Extensions (PDEs) 29
- printer drivers. See drivers
- Printer Found screen 100
- Printer Properties tabs 74
- Printing Preferences tabs 48
- Product Registration page, EWS 86
- Product Support page, EWS 86
- programs, driver settings 46
- ProRes settings 70
- Q**
- quality 70
- Quick Sets 49
- R**
- RAM
 - included 3
 - Macintosh system requirements 33
 - Windows system requirements 12
- registration page 86
- Registration screen 108
- release notes 30
- removing software
 - HP Software Update utility 125
 - using Add/Remove programs 121
 - using HP program group 119
- resizing settings 60
- resolution
 - settings 70
 - specifications 3
- ROM, included 3
- Rotate by 180 degrees 73
- S**
- Scale to Fit option 60
- screen capture utility 19
- Set Network Protocol screen 103
- Settings tab, EWS 82
- settings, driver
 - accessing 46
 - Quick Sets 49
- sharing
 - features available 23
 - setting up 89
- Size is option 50
- software license agreement
 - Macintosh 39
 - Windows 95
- software, ordering 7, 32
- Source is settings 55
- Specify Printer screen 105
- speed specifications 3
- Start Copying Files screen 106
- supplies, ordering 86
- support
 - HP Instant Support page, EWS 86
 - Product Support page, EWS 86
- system requirements
 - Macintosh 33
 - Windows 12

T

text, printing as black 71

trays

- capacities 3
- custom paper sizes 54
- Source is settings 55

troubleshooting

- constraint messages 47
- device conflicts 25

two-sided printing 67

Type is settings 55

U

uninstalling

- HP Software Update utility 125
- Windows software using Add/Remove programs 121
- Windows software using HP program group 119

units of measurement 54

UNIX support 13

Update utility 17, 125

USB Cable Connect screen 107

USB port

- Add Printer Wizard 93, 109
- device conflicts 25
- devices vs. hubs 25
- operating systems supported 4
- specifications 3

Use different paper options 56

user guides

- localized versions 8
- operating systems supported 15, 30

V

version number, driver 74

W

watermarks 62

Web sites

- Linux support 13
- ordering software 7
- UNIX support 13

What's this Help 47

Windows

- Add Printer Wizard 93, 109
- component availability 14
- connection types 23
- device conflicts 25
- dialog boxes, installation 94

directory structure on

installation CD 5

driver-only installation 92

installation options 88

installers 14

installing software 89

networks, installing software 92

new features for 14

operating systems supported 12

Plug-n-Play 93, 109

sharing, setting up 89

system requirements 12

uninstalling product software

using Add/Remove programs 121

uninstalling product software

using HP program group 119

uninstalling software using HP

Software Update utility 125

© 2005 Hewlett-Packard Development Company, L.P.

www.hp.com

