

## Create and print a contact sheet

<u>Printer:</u> HP Designjet 30/90/130 series <u>Software</u>: EFI Designer Edition for HP <u>Operating System:</u> Windows



- 1. First recommendations:
  - See the <u>Media type functionality & features</u> and choose the most appropriate media.
  - It is essential to have the media type correctly calibrated with the printer and print mode, consult the <u>Calibrate my printer</u> document.
- 2. Open the EFI Designer Edition RIP.
- 3. EFI Designer Edition RIP settings, Preferences:
  - Color:
    - Check that the Color Management is active.
    - Paper name: Select the paper type that is loaded on the printer (always calibrated) and "Best" print quality.
    - Print resolution: 600 x 600.
    - Color output mode: Photo print.
    - RGB: select the profile of the scanner or camera you have used to get the photo (source profile), press Add profile button to add it. If you don't have it, select one of the list and Perceptual.
    - o Check Use embedded profiles.
  - Printer:
    - **Paper size:** Select the paper size of the media loaded on the printer.
  - Nesting:
    - **Position:** Optimal space usage.
    - o Rotation: Check Images may be rotated during positioning.
    - **Size:** Select Scale all images to: and select the size you want to have the images in the contact sheet.

Preferen	ces							
General	Color	Layout	Output	Nesting	Printer	Spot Colors	Paper profiles	
		Layour	odipdi	resting	THILE	Spot Colors	i aper promes	
1.000	sition							
Optimal space usage								
1	Optimal cut	ting edges						
Rotation								
✓ Image may be rotated during positioning								
- Siz	ze				1.84		7224 63	
F	Scale all im	ages to:	100.	0 x 70.0	👻 mn	n /	Add R	emove
Place all images as landscape								
Bo	order							
Г		er around image	2					
	Under Dorde	a droand inidge						
Reset se	attinge C.	ave Prefs	Load Prefs				Cancel	ОК
	Stangs 50		road Liels					

- Click **OK**.
- 4. Add button, browse your file and click Open or drag and drop the file to the spool panel.

- 5. Select all the files and click **Nesting** button.
- Check the print layout before printing, select the nesting file and press the **Preview** button, if it is ready click **Print**. If you need to retouch any setting, you can do it in the **Individual Job Settings** (View menu > Job Info).

## For more information on HP Designjet products

www.hp.com/go/designjet

© 2005 Hewlett-Packard Development Company, L.P. The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Adobe Photoshop and PostScript are trademarks of Adobe Systems Incorporated. PANTONE is Pantone, Inc.'s check-standard trademark for color.

Rev. 1.0, 09/2005

