



© Copyright 2016 HP Development Company, L.P. The information contained herein is subject to change without notice.

Printed in

First Edition: February 2016



843989-001

## Before you begin

- Save all files and shut down the computer properly through the operating system, then turn off any external devices.
- 2. Disconnect the power cord from the electrical outlet and disconnect any external devices.
- ⚠ WARNING! To avoid the risk of serious injury or damage to the system, ensure that the power cord is unplugged from the electrical outlet at the wall before installing this product. Failure to do so may expose you to the risk of electric shock.
- NOTE: For regulatory and safety notices, refer to the *Product Notices* included with your product. The regulatory model number for this product is TPC-W024-BIO.

### **Product support**


For the online access to technical support information, self-solve tools, online assistance, community forums or IT experts, broad multivendor knowledge base, monitoring and diagnostic tools, go to www.hp.com/support.

NOTE: If you need help preparing your computer model for this installation, refer to the documentation provided with the computer, or go to <a href="https://www.hp.com/support">www.hp.com/support</a> to locate the manual for your model.


## Installing the fingerprint reader

You can install the fingerprint reader in the USB port on the left side or right side of the RP9 display head. Before installing the fingerprint reader, you must remove the display head rear cover and the side port cover.

 Press the two latches on the display head rear cover outward ①. Slide the rear cover up, and then lift it off the display head ②.



- Remove the two screws that secure the side port cover ①, and then pull the port cover off the display head ②.
- NOTE: You may need to gently loosen the port cover from inside of the screw holes with a flat screwdriver.



Insert the USB connector on the fingerprint reader into the side USB port ①, and then secure the module with the two screws that were previously removed ②.



4. Align the tabs on the display head rear cover with the slots on the display head. Place the cover on the display head, and then slide the cover down so that it snaps in place.



Reconnect the power cord and any external devices, and then turn on the computer.

# Configuring the fingerprint reader

To configure the integrated fingerprint reader, refer to the *HP Point of Sale Configuration Guide* (available in English only). The guide is located with the documentation on your retail computer and at <a href="http://www.hp.com/support">http://www.hp.com/support</a>. To access the guide on the retail computer, select **Start > HP Point of Sale Information**.

#### **Documentation feedback**

HP is committed to providing documentation that meets your needs. To help us improve the documentation, please send any suggestions, comments, or errors to <a href="document-