Interactive LED Diagnostic

HP ENVY x360 13-bd0000 Convertible PC

Welcome to the interactive LED diagnostic viewer for the HP ENVY x360 13-bd0000 Convertible PC

Here's how to use it...

LED Diagnostic (Click the link to navigate this platform's LED diagnostic states)

On this page you will find an image viewer with a menu of this product's external views. To identify the location of the LEDs for each view, simply click that view. To learn more about the diagnostic behavior of each LED, hover over the information icon (1) above the LED and review the information that presents in the right-hand pane.


That's it! On every page there is a link that brings you back to the Welcome page.

Top View

Top View


Right Edge

Display View



Right Edge

Top View Right Edge Display View



Display View

