

# Notebook Tour

---

## User Guide

© Copyright 2006 Hewlett-Packard  
Development Company, L.P.

Microsoft and Windows are U.S. registered  
trademarks of Microsoft Corporation.  
Bluetooth is a trademark owned by its  
proprietor and used by Hewlett-Packard  
Company under license. SD logo is a  
trademark of its proprietor.

The information contained herein is subject  
to change without notice. The only  
warranties for HP products and services are  
set forth in the express warranty statements  
accompanying such products and services.  
Nothing herein should be construed as  
constituting an additional warranty. HP shall  
not be liable for technical or editorial errors  
or omissions contained herein.

First Edition: July 2006

Document Part Number: 416608-001

# Table of contents

## 1 Components

Top components .....	2
TouchPad .....	2
Lights .....	3
Buttons, switches, and speakers .....	6
Keys .....	9
Hotkey quick reference .....	9
Front components .....	11
Rear components .....	12
Right-side components .....	13
Left-side components .....	14
Bottom components .....	15
Display components .....	16
Wireless antennae (select models only) .....	17
Additional hardware components .....	18
Labels .....	19

## 2 Specifications

Operating environment .....	20
Rated input power .....	21
Expansion port input/output signals .....	22

Index .....	23
-------------	----



# 1 Components

This chapter explains the hardware features of the computer.

To see a list of hardware installed in the computer:

1. Select **Start > My Computer**.
2. Under **Hard Disk Drives**, click the name of your computer hard drive.
3. In the left pane under **System Tasks**, click **View system information**.
4. Select **Hardware** tab > **Device Manager**.

You can also add hardware or modify device configurations using Device Manager.




---

**NOTE** Components included in the computer may vary by region and by model. The illustrations in this chapter identify the standard features included in most computer models.

---

# Top components

## TouchPad



Component	Description
(1) TouchPad light	Blue: TouchPad is enabled. Amber: TouchPad is disabled.
(2) TouchPad*	Moves the pointer and selects or activates items on the screen.
(3) Left TouchPad button*	Functions like the left button on an external mouse.
(4) Right TouchPad button*	Functions like the right button on an external mouse.
(5) TouchPad scroll zone*	Scrolls up or down.
(6) TouchPad on/off button	Enables/disables the TouchPad.

\*This table describes factory settings. To view and change pointing device preferences, select **Start > Control Panel > Printers and Other Hardware > Mouse**.

# Lights




**NOTE** Refer to the illustration that most closely matches your computer.



Component	Description
(1) Power lights (2)*	<p>On: The computer is on.</p> <p>Blinking: The computer is in standby.</p> <p>Off: The computer is off or in hibernation.</p>
(2) Battery light	<p>On: A battery is charging.</p> <p>Blinking: A battery that is the only available power source has reached a low-battery condition. When the battery reaches a <i>critical</i> low-battery condition, the battery light begins blinking rapidly.</p> <p>Off: If the computer is plugged into an external power source, the light is turned off when all batteries in the computer are fully charged. If the computer is not plugged into an external power source, the light stays off until the battery reaches a low-battery condition.</p>
(3) Drive light	Blinking: The hard drive or optical drive is being accessed.
(4) Caps lock light	On: Caps lock is on.
(5) Media button light	Blinks once when the media button is pressed.
(6) DVD button light	Blinks once when the DVD button is pressed.
(7) Previous/rewind light	Blinks once when the previous/rewind button is pressed.
(8) Play/pause light	Blinks once when the play/pause button is pressed.
(9) Next/fast forward light	Blinks once when the next/fast forward button is pressed.
(10) Stop light	Blinks once when the stop button is pressed.
(11) Volume mute light	<p>Blue: Computer sound is turned on.</p> <p>Amber: Computer sound is turned off.</p>

Component	Description
(12) Volume down light	Blinking: The volume scroll zone is being used to decrease speaker volume.
(13) Volume up light	Blinking: The volume scroll zone is being used to increase speaker volume.
(14) Num lock light	On: Num lock is on or the embedded numeric keypad is enabled.

\*The 2 power lights display the same information. The light on the power button is visible only when the computer is open. The power light on the front of the computer is visible whether the computer is open or closed.



Component	Description
(1) Power lights (2)*	On: The computer is on. Blinking: The computer is in standby. Off: The computer is off or in hibernation.
(2) Battery light	On: A battery is charging. Blinking: A battery that is the only available power source has reached a low-battery condition or a <i>critical</i> low-battery condition. Off: If the computer is plugged into an external power source, the light is turned off when all batteries in the computer are fully charged. If the computer is not plugged into an external power source, the light stays off until the battery reaches a low-battery condition.
(3) Drive light	Blinking: The hard drive or optical drive is being accessed.
(4) Caps lock light	On: Caps lock is on.
(5) Media button light	Blinks once when the media button is pressed.
(6) Volume mute light	Blue: Computer sound is turned on. Amber: Computer sound is turned off.
(7) Volume down light	Blinking: The volume scroll zone is being used to decrease speaker sound.




Component	Description
(8) Volume up light	Blinking: The volume scroll zone is being used to increase speaker sound.
(9) Num lock light	Blinking: Num lock is on or the embedded numeric keypad is enabled.

\*The 2 power lights display the same information. The light on the power button is visible only when the computer is open. The power light on the front of the computer is visible whether the computer is open or closed.

## Buttons, switches, and speakers



**NOTE** Refer to the illustration that most closely matches your computer.



Component	Description
(1) Power button*	<p>When the computer is</p> <ul style="list-style-type: none"> <li>• Off, press to turn on the computer.</li> <li>• On, press to enter hibernation.</li> <li>• In standby, briefly press to exit standby.</li> <li>• In hibernation, briefly press to exit hibernation.</li> </ul> <p>If the computer has stopped responding and Microsoft® Windows® shutdown procedures cannot be used, press and hold the power button for at least 5 seconds to turn off the computer.</p>
(2) Speakers (2)	Produce sound.
(3) Media button	<p>If QuickPlay is not installed and the computer is</p> <ul style="list-style-type: none"> <li>• On, opens the music program or Media menu, which allows you to select a multimedia program.</li> <li>• Off, does not function.</li> <li>• In standby, resumes from standby into Windows.</li> </ul> <p>If QuickPlay is installed and the computer is</p> <ul style="list-style-type: none"> <li>• On, opens the music program or Media menu, which allows you to select a multimedia program.</li> <li>• Off, opens the music program or the Media menu, which allows you to select a multimedia program.</li> <li>• In standby, resumes from standby into Windows.</li> </ul>




**NOTE** The media button does not affect the procedure for restoring from hibernation.

Component	Description
(4) DVD button	<p>When the computer is</p> <ul style="list-style-type: none"> <li>On, opens the default DVD program to start a DVD in the optical drive.</li> <li>Off, opens QuickPlay to start a DVD in the optical drive. If the QuickPlay software is not installed, the DVD button starts in Windows.</li> <li>In hibernation, opens QuickPlay to start a DVD in the optical drive. If QuickPlay is not installed, the computer resumes from hibernation.</li> </ul>
(5) Previous/rewind button	<p>When a disc is playing in the optical drive:</p> <ul style="list-style-type: none"> <li>Plays the previous track or chapter, when pressed once.</li> <li>Rewinds when pressed with the <b>fn</b> key.</li> </ul>
(6) Play/pause button	<p>When a disc is in the optical drive and is</p> <ul style="list-style-type: none"> <li>Not playing, plays the disc.</li> <li>Playing, pauses the disc.</li> </ul>
(7) Next/fast forward button	<p>When a disc is playing in the optical drive:</p> <ul style="list-style-type: none"> <li>Play the next track or chapter, when pressed once.</li> <li>Fast forwards when pressed with the <b>fn</b> key.</li> </ul>
(8) Stop button	<p>When a disc is playing in the optical drive, stops the current disc activity.</p>
(9) Volume mute button	<p>Mutes and restores speaker sound.</p>
(10) Volume scroll zone	<p>Adjusts speaker volume. Slide your finger to the left to decrease volume and to the right to increase volume. You can also tap the minus sign on the scroll zone to decrease volume, or tap the plus sign on the scroll zone to increase volume.</p>
<p>*This table describes factory settings. For information about changing factory settings, refer to the user guides located in the Help and Support Center.</p>	



**NOTE** Refer to the QuickPlay online Help for details on using QuickPlay.



Component	Description
<p>(1) Power button*</p>	<p>When the computer is</p> <ul style="list-style-type: none"> <li>• Off, press to turn on the computer.</li> <li>• On, press to enter hibernation.</li> <li>• In standby, briefly press to exit standby.</li> <li>• In hibernation, briefly press to exit hibernation.</li> </ul> <p>If the computer has stopped responding and Microsoft® Windows® shutdown procedures cannot be used, press and hold the power button for at least 5 seconds to turn off the computer.</p>
<p>(2) Speakers (2)</p>	<p>Produce sound.</p>
<p>(3) Media button</p>	<p>If QuickPlay is not installed and the computer is</p> <ul style="list-style-type: none"> <li>• On, opens the music program or Media menu, which allows you to select a multimedia program.</li> <li>• Off, does not function.</li> <li>• In standby, resumes from standby into Windows.</li> </ul> <p>If QuickPlay is installed and the computer is</p> <ul style="list-style-type: none"> <li>• On, opens the music program or Media menu, which allows you to select a multimedia program.</li> <li>• Off, opens the music program or the Media menu, which allows you to select a multimedia program.</li> <li>• In standby, resumes from standby into Windows.</li> </ul> <p> <b>NOTE</b> The media button does not affect the procedure for restoring from hibernation.</p>
<p>(4) Volume mute button</p>	<p>Mutes and restores speaker sound.</p>


Component	Description
(5) Volume scroll zone	Adjusts speaker volume. Slide your finger to the left to decrease volume and to the right to increase volume. You can also tap the minus sign on the scroll zone to decrease volume, or tap the plus sign on the scroll zone to increase volume.

\*This table describes factory settings. For information about changing factory settings, refer to the user guides located in the Help and Support Center.

## Keys



**NOTE** Your computer may look slightly different from the illustration in this section.



Component	Description
(1) <a href="#">esc</a> key	Displays system information when pressed in combination with the <a href="#">fn</a> key.
(2) <a href="#">fn</a> key	Executes frequently used system functions when pressed in combination with a function key or the <a href="#">esc</a> key.
(3) Windows logo key	Displays the Microsoft Windows Start menu.
(4) Windows applications key	Displays a shortcut menu for items beneath the pointer.
(5) Embedded numeric keypad keys	Can be used like the keys on an external numeric keypad.
(6) Function keys	Execute frequently used system functions when pressed in combination with the <a href="#">fn</a> key.

## Hotkey quick reference

To perform this function	Press
Display information.	<a href="#">fn+esc</a>
Open the Help and Support Center.	<a href="#">fn+f1</a>


To perform this function	Press
Open the Print Options window.	fn+f2
Open a Web browser.	fn+f3
Alternate between computer display and external display.	fn+f4
Initiate standby.	fn+f5
Initiate QuickLock.	fn+f6
Decrease screen brightness.	fn+f7
Increase screen brightness.	fn+f8
Play, pause, or resume an audio CD or a DVD.	fn+f9
Stop an audio CD or a DVD.	fn+f10
Play the previous track or section on an audio CD or a DVD.	fn+f11
Play the next track or section on an audio CD or a DVD.	fn+12

# Front components



**NOTE** Your computer may look slightly different from the illustration in this section.



Component	Description
(1) Wireless switch	Turns the wireless feature on or off, but does not create a wireless connection.   <b>NOTE</b> A wireless network must be set up in order to establish a wireless connection.
(2) Wireless light	Blue: An integrated wireless device, such as a wireless local area network (LAN) device and/or a Bluetooth® device, is turned on.  Amber: All wireless devices are turned off.
(3) Consumer infrared lens (select models only)	Receives a signal from the HP Remote Control.
(4) Audio-in (microphone) jack	Connects an optional computer headset microphone, stereo array microphone, or monaural microphone.
(5) Audio-out (headphone) jack	Produces sound when connected to optional powered stereo speakers, headphones, ear buds, a headset, or television audio.
(6) Audio-out (headphone) S/PDIF jack (select models only)	Provides enhanced audio performance, including surround sound and other high-end audio output.

# Rear components



Component	Description
Vent	Enables airflow to cool internal components.  <div data-bbox="810 512 863 558"></div> <div data-bbox="890 520 1437 646"><b>CAUTION</b> To prevent overheating, do not obstruct vents. Use the computer only on a hard, flat surface. Do not allow another hard surface, such as an adjoining optional printer, or a soft surface, such as pillows or thick rugs or clothing, to block airflow.</div> <div data-bbox="810 688 863 743"></div> <div data-bbox="890 697 1437 802"><b>NOTE</b> The computer fan starts up automatically to cool internal components and prevent overheating. It is normal for the internal fan to cycle on and off during routine operation.</div>







## Right-side components




Component	Description
(1) ExpressCard slot	Supports optional ExpressCard/54 cards.
(2) Optical drive	Reads an optical disc.
(3) Optical drive light	Blinking: The optical drive is being accessed.
(4) USB port (select models only)	Connects optional USB devices.
(5) Power connector	Connects an AC adapter.

## Left-side components



Component	Description
(1) Security cable slot	Attaches an optional security cable to the computer.   <b>NOTE</b> The security cable is designed to act as a deterrent, but may not prevent the computer from being mishandled or stolen.
(2) S-Video-out jack	Connects an optional S-Video device such as a television, VCR, camcorder, overhead projector, or video capture card.
(3) External monitor port	Connects an external VGA monitor or projector.
(4) Expansion port 3	Connects the computer to an optional expansion product.   <b>NOTE</b> The computer has only one expansion port. The term <i>expansion port 3</i> describes the type of expansion port.
(5) RJ-45 (network) jack	Connects a network cable.   <b>NOTE</b> On select computer models, the network jack provides Gigabit Ethernet functionality.
(6) RJ-11 (modem) jack	Connects a modem cable.
(7) HDMI port (select models only)	Connects an optional video or audio device such as a high-definition television, set-top box, DVD player, or any compatible digital or audio component.
(8) USB ports (2)	Connect an optional USB device.
(9) 1394 port (select models only)	Connects an optional IEEE 1394 or 1394a device, such as a camcorder.
(10) Digital Media Slot light (select models only)	On: A digital card is being accessed.
(11) Digital Media Slot (select models only)	Supports the following optional digital card formats: Secure Digital (SD) Memory Card, MultiMediaCard (MMC), Secure Digital Input/Output (SD I/O), Memory Stick (MS), Memory Stick Pro (MSP), xD-Picture Card (XD), xD-Picture Card (XD) Type M.

## Bottom components



Component	Description
(1) Battery bay	Holds the battery.
(2) Battery release latch	Releases the battery from the battery bay.
(3) Vents (5)	Enable airflow to cool internal components.
	<p><b>CAUTION</b> To prevent overheating, do not obstruct vents. Use the computer only on a hard, flat surface. Do not allow another hard surface, such as an adjoining optional printer, or a soft surface, such as pillows or thick rugs or clothing, to block airflow.</p> <p><b>NOTE</b> The computer fan starts up automatically to cool internal components and prevent overheating. It is normal for the internal fan to cycle on and off during routine operation.</p>
(4) Memory module compartment	Contains the memory module slots.
(5) Hard drive bay	Holds the hard drive.

## Display components



Component	Description
(1) Internal display switch	Turns off the display and initiates standby if the display is closed while the power is on.
(2) Internal microphones (2) (select models only)	Record sound.  <b>NOTE</b> A microphone icon next to each microphone opening indicates that the computer has internal microphones.
(3) Integrated camera light (select models only)	On: The integrated camera is in use.
(4) Integrated camera (select models only)	Records video and captures still photos.

## Wireless antennae (select models only)

On select computer models, at least 2 antennae send and receive signals from one or more wireless devices. These antennae are not visible from the outside of the computer.

To see wireless regulatory notices, refer to your region's section of the *Regulatory, Safety and Environmental Notices* located in the Help and Support Center.



---

**NOTE** For optimal transmission, keep the areas immediately around the antennae free from obstructions.

---

## Additional hardware components



Component	Description
(1) Power cord*	Connects an AC adapter to an AC outlet.
(2) AC adapter	Converts AC power to DC power.
(3) Battery*	Powers the computer when the computer is not plugged into external power.
(4) Modem cable (select models only)*	Connects the internal modem to an RJ-11 telephone jack or to a country-specific modem adapter.
(5) Country-specific modem cable adapter (select models only)	Adapts the modem cable to a non-RJ-11 telephone jack.

\*Modem cables, batteries, and power cords vary in appearance by region and country.

# Labels

The labels affixed to the computer provide information you may need when you troubleshoot system problems or travel internationally with the computer.

- Service tag—Provides the product brand and series name, serial number (s/n), and product number (p/n) of your computer. Have this information available when you contact Customer Care. The service tag label is affixed to the bottom of the computer.
- Microsoft Certificate of Authenticity—Contains the Microsoft® Windows® Product Key. You may need the Product Key to update or troubleshoot the operating system. This certificate is affixed to the bottom of the computer.
- Regulatory label—Provides regulatory information about the computer. The regulatory label is affixed to the bottom of the computer.
- Modem approval label—Provides regulatory information about the modem and lists the agency approval markings required by some of the countries in which the modem has been approved for use. You may need this information when traveling internationally. The modem approval label is affixed inside the hard drive bay.
- Wireless certification label(s) (select models only)—Provide information about optional wireless devices and the approval markings of some of the countries in which the devices have been approved for use. An optional device may be a wireless local area network (WLAN) device or an optional Bluetooth® device. If your computer model includes one or more wireless devices, one or more certification labels are included with your computer. You may need this information when traveling internationally. Wireless certification labels are affixed inside the memory module compartment.

## 2 Specifications

### Operating environment

The operating environment information in the following table may be helpful if you plan to use or transport the computer in extreme environments.

Factor	Metric	U.S.
<b>Temperature</b>		
Operating	5°C to 35°C	41°F to 95°F
Nonoperating	-20°C to 60°C	-4°F to 140°F
<b>Relative humidity (noncondensing)</b>		
Operating	10% to 90%	10% to 90%
Nonoperating	5% to 95%	5% to 95%
<b>Maximum altitude (unpressurized)</b>		
Operating (14.7 to 10.1 psia*)	-15 m to 3,048 m	-50 ft to 10,000 ft
Nonoperating (14.7 to 4.4 psia*)	-15 m to 12,192 m	-50 ft to 40,000 ft

\*Pounds per square inch absolute (psia) is another unit of measurement for altitude.



## Rated input power

The power information in this section may be helpful if you plan to travel internationally with your computer.

The computer operates on DC power, which can be supplied by an AC or a DC power source. Although the computer can be powered from a stand-alone DC power source, it should be powered only with an AC adapter or a DC power source supplied and approved by HP for the computer.

The computer is capable of accepting DC power within the following specifications.

Input power	Rating
Operating voltage	18.5 V dc — 19.0 V dc
Operating current	3.5 A or 4.74 A

This product is designed for IT power systems in Norway with phase-to-phase voltage not exceeding 240 V rms.

## Expansion port input/output signals

The signal information in this section may be helpful if you plan to use an optional expansion product that connects to the expansion port 3 on the computer. (The computer has only one expansion port. The term expansion port 3 describes the type of expansion port.)

The following table identifies the input and output signals supported by the expansion port 3 on the computer.

Feature	Support
USB 2.0	Yes
Gigabit Ethernet	Yes
IEEE 1394 (4-pin port)	No
Consumer infrared (for optional remote control only)	Yes
Power inputs	65-W to 90-W maximum
Composite TV	Yes
S-Video TV	Yes
Component TV	Yes
S/PDIF audio	Yes
DVI	No
Headphone/speaker audio-out	Yes
Microphone audio-in	Yes
VGA	Yes
Power button	Yes
Volume control (up/down)	Yes
Mute/unmute status	Yes

# Index

## Symbols/Numerics

1394 port, identifying 14

## A

AC adapter, identifying 18  
altitude specifications 20  
antennae 17  
applications key, Windows 9  
audio-in (microphone) jack,  
identifying 11  
audio-out (headphone) jack,  
identifying 11  
audio-out (headphone) S/PDIF  
jack, identifying 11

## B

battery  
identifying 18  
battery bay 15, 19  
battery light, identifying 3, 4  
battery release latch,  
identifying 15  
bays  
battery 15, 19  
hard drive 15  
Bluetooth label 19  
buttons  
DVD 7  
media 6, 8  
next/fast forward 7  
play/pause 7  
power 6, 8  
previous/rewind 7  
stop 7  
TouchPad 2  
TouchPad on/off 2  
volume mute 7, 8

## C

cable  
RJ-11 (modem) 18  
camera, identifying 16  
caps lock light, identifying 3, 4  
Certificate of Authenticity label 19  
compartments  
memory module 15  
components  
bottom 15  
display 16  
front 11  
left-side 14  
rear 12  
right-side 13  
top 2  
connector, power 13  
cord, power, identifying 18

## D

Digital Media Slot light,  
identifying 14  
Digital Media Slot, identifying 14  
display switch, identifying 16  
drive light, identifying 3, 4  
drives  
hard 15  
optical 13  
DVD button light, identifying 3  
DVD button, identifying 7

## E

environmental specifications 20  
esc key, identifying 9  
expansion port, identifying 14  
expansion port, input/output  
signals 22  
ExpressCard slot, identifying 13  
external monitor port,  
identifying 14

## F

fn key, identifying 9  
function keys, identifying 9

## H

hard drive bay, identifying 15  
HDMI port, identifying 14  
headphone (audio-out) jack 11  
headphone (audio-out) S/PDIF  
jack 11  
hotkeys, quick reference 9  
humidity specifications 20

## I

IEEE 1394 port, identifying 14  
infrared lens, identifying 11  
integrated camera light,  
identifying 16  
integrated camera, identifying 16  
internal display switch,  
identifying 16  
internal microphones,  
identifying 16

## J

jacks  
audio-in (microphone) 11  
audio-out (headphone) 11  
audio-out (headphone) S/  
PDIF 11  
RJ-11 (modem) 14  
RJ-45 (network) 14  
S-Video-out 14

## K

keypad keys, identifying 9  
keys  
esc 9  
fn 9  
function 9

- keypad 9
- Windows applications 9
- Windows logo 9

## L

### labels

- Bluetooth 19
- Microsoft Certificate of Authenticity 19
- modem approval 19
- regulatory 19
- service tag 19
- wireless certification 19
- WLAN 19

- latch, battery release 15

### lights

- battery 3, 4
- caps lock 3, 4
- Digital Media Slot 14
- drive 3, 4
- DVD button 3
- integrated camera 16
- media button 3, 4
- mute 3, 4
- next/fast forward 3
- num lock 4, 5
- optical drive 13
- play/pause 3
- power 3, 4
- previous/rewind 3
- stop 3
- TouchPad 2
- volume down 4
- volume mute 3, 4
- volume up 4, 5
- wireless 11

## M

- media activity buttons, identifying 7
- media activity lights, identifying 3
- media button light, identifying 3, 4
- media button, identifying 6, 8
- memory module compartment, identifying 15
- microphone (audio-in) jack 11
- Microsoft Certificate of Authenticity label 19
- modem approval label 19

- modem cable adapter 18
- monitor port, external 14
- mute button, identifying 7, 8
- mute light, identifying 3, 4

## N

- next/fast forward button, identifying 7
- next/fast forward light, identifying 3
- num lock light, identifying 4, 5

## O

- operating environment specifications 20
- operating system
  - Microsoft Certificate of Authenticity label 19
  - Product Key 19
- optical drive light, identifying 13
- optical drive, identifying 13

## P

- play/pause button, identifying 7
- play/pause light, identifying 3
- ports
  - 1394 14
  - expansion 14
  - external monitor 14
  - HDMI 14
  - USB 13, 14
- power button, identifying 6, 8
- power connector, identifying 13
- power cord 18
- power lights, identifying 3, 4
- Previous/rewind button, identifying 7
- previous/rewind light, identifying 3
- Product Key 19
- product name and number, computer 19

## R

- rated input power specifications 21
- regulatory information
  - modem approval label 19
  - regulatory label 19
  - wireless certification labels 19
- release latch, battery 15

- RJ-11 (modem) cable 18
- RJ-11 (modem) jack, identifying 14
- RJ-45 (network) jack, identifying 14

## S

- S-Video-out jack, identifying 14
- scrolling regions, TouchPad 2
- security cable slot, identifying 14
- serial number, computer 19
- service tag 19
- slots
  - Digital Media 14
  - ExpressCard 13
  - memory module 15
  - security cable 14
- speakers, identifying 6, 8
- specifications
  - operating environment 20
  - rated input power 21
- stop button, identifying 7
- stop light, identifying 3

## T

- temperature specifications 20
- TouchPad
  - buttons 2
  - identifying 2
  - scrolling regions 2
- TouchPad light, identifying 2
- TouchPad on/off button 2
- traveling with the computer
  - environmental specifications 21
  - modem approval label 19
  - wireless certification labels 19

## U

- USB ports, identifying 13, 14

## V

- vents, identifying 12, 15
- volume down light, identifying 4
- volume mute button, identifying 7, 8
- volume mute light, identifying 3, 4
- volume scroll zone, identifying 7, 9
- volume up light, identifying 4, 5

## W

- Windows applications key,  
  identifying 9
- Windows logo key, identifying 9
- wireless antennae 17
- wireless certification label 19
- wireless light, identifying 11
- wireless switch, identifying 11
- WLAN device 19
- WLAN label 19

