



# **Lucent/Agere Command Set (Advanced Users Only)**

## **Compaq Notebook Series**

Document Part Number: 277662-001

**April 2002**

This document describes the Lucent/Agere command set for advanced users, including AT commands, S-Registers, AT FAX commands, and other advanced modem commands.

© 2002 Compaq Information Technologies Group, L.P.

Compaq, the Compaq logo, Evo, and Presario are trademarks of Compaq Information Technologies Group, L.P. in the U.S. and/or other countries.

Microsoft and Windows are trademarks of Microsoft Corporation in the U.S. and/or other countries.

All other product names mentioned herein may be trademarks of their respective companies.

Compaq shall not be liable for technical or editorial errors or omissions contained herein. The information is provided "as is" without warranty of any kind and is subject to change without notice. The warranties for Compaq products are set forth in the express limited warranty statements accompanying such products. Nothing herein should be construed as constituting an additional warranty.

Lucent/Agere Command Set

(Advanced Users Only)

First Edition April 2002

Document Part Number: 277662-001

---

# Contents

## **1 AT Command Set**

AT Data Command Set Summary .....	1-1
New AT Commands .....	1-4
Result Code Summary .....	1-5
AT Command Descriptions .....	1-11

## **2 S-Registers**

Setting S-Register Default Values .....	2-2
Modifying an S-Register .....	2-2
Reading an S-Register .....	2-3
S-Register Descriptions .....	2-5

## **3 AT FAX Command Set**

Class 1 FAX Commands .....	3-1
AT FAX Command Set Descriptions .....	3-2

## **4 V.25ter AT Command Set**

## **5 V.80 AT Command Set**

**A New V.250 Commands to Support V.92 AT Command Set**

+PMH Modem on Hold Enable . . . . . A-5  
+PMHR Initiate Modem on Hold (MOH) . . . . . A-7  
+PIG PCM Upstream Ignore . . . . . A-8  
+PQC V.92 Phase 1 and Phase 2 Control . . . . . A-9  
+PMHF V.92 Modem Hook Flash . . . . . A-10  
+DS44 V.44 Data Compression . . . . . A-10

---

# AT Command Set

## AT Data Command Set Summary

Command	Description	Command	Description
+++	Escape to online command mode	&S	Data set ready (DSR) option
A	Answer command	&T	Self-test commands
A/	Repeat last command	&V	View active configuration
B	Communication standard setting	&W	Store current configuration
C	Carrier control	&Y	Select stored profile for hard reset
D	Dial command	&Zn=x	Store telephone number
E	Echo command	\A	MNP Block Size
F	Online data character echo command	\B	Send Break
H	Hook control	\G	Modem port flow control
I	Request ID information	\J	Adjust bits/s rate control
L	Monitor speaker volume	&S	Data set ready (DSR) option

## AT Data Command Set Summary

Command	Description	Command	Description
M	Monitor speaker mode	&T	Self-test commands
N	Modulation handshake	\N	Error control mode selection
O	Return to online data mode	\Q	Local flow control selection
P	Select pulse dialing	\R	Ring indicator off after answer
Q	Result code control	\T	Inactivity timer
S	Set or Query S-Register values	\V	Protocol result code
T	Select tone dialing	\X	XON/XOFF pass through
V	DCE response format	-C	Data calling tone
W	Result code option	-V90	Enable/disable V.90 settings
X	Result code selection and call progress monitoring	%B	View numbers in blacklist
Y	Long-space disconnect	%C	Data compression control
Z	Reset and recall stored profile	%E	Automatic rate change
&B	V.32 auto retrain	DR	Compression reporting
&C	Data carrier detect (DCD) control	DS	V.42bis

## AT Data Command Set Summary

Command	Description	Command	Description
&D	Data Terminal Ready (DTR) control	ER	Error control reporting
&F	Local factory settings	ES	Buffered mode
&G	V.22bis guard tone control	IFC	Flow control
&J	Auxiliary relay options	ILRR	DTE rate reporting
&K	Local flow control selection	MR	Modulation reporting
&M	Asynchronous communications mode	MS	Modem carrier
&P	Pulse dial make-to-break ration selection		

## New AT Commands

Command	Description
+DS44+<direction>, <compression_negotiation>	V.44 data compression
+EB=<break selection>, <timed>,<default length>	Break handling in error control operation
+ESA=<trans idle>,<frame idle>,<framed un ov>,<hd auto>,<crc type>,<nrzi en>,<syn1>	Set up error control parameters
+ESR=<value>	Selective repeat
+ETBM=<pending_TD>, <pending_RD>,<timer>	Call termination buffer management
+GCI+<T.35 country code>	Country of installation
+GMI	Manufacturer identification
+GMM	Modem identification
+GMR	Request revision information
+IPR+<DTE rate>	Fixed DTE rate
+ITF+<off>,<on>	Transmit flow control threshold
+PCW+<call_waiting>	Call waiting enable
+PIG+<value>	PCM upstream ignore
+PMH+<value>	Modem on hold enable
+PMHF	Modem on hold hook flash
+PMHR	Initiate modem on hold
+PMHT+<value>	Modem on hold timer
+PQC_<value>	V.92 phase 1 and phase 2 control
+PSS+<value>	Use short sequence



## Result Code Summary

Result Code	Numeric	Description
OK	0	Command executed
CONNECT	1	Modem connected to line
RING	2	A ring signal has been detected
NO CARRIER	3	Modem lost carrier signal, or does not detect carrier signal, or does not detect answer tone
ERROR	4	Invalid command
CONNECT 1200 EC*	5	Connection at 1200 bits/s
NO DIALTONE	6	No dial tone detected
BUSY	7	Busy signal detected
NO ANSWER	8	Remote end never answered
CONNECT 2400 EC*	10	Connection at 2400 bits/s
CONNECT 4800 EC*	11	Connection at 4800 bits/s
CONNECT 9600 EC*	12	Connection at 9600 bits/s
CONNECT 14400 EC*	13	Connection at 14400 bits/s
CONNECT 19200 EC*	14	Connection at 19200 bits/s
CONNECT 7200 EC*	24	Connection at 7200 bits/s
CONNECT 12000 EC*	25	Connection at 12000 bits/s
CONNECT 16800 EC*	86	Connection at 16800 bits/s
CONNECT 300 EC*	40	Connection at 300 bits/s
CONNECT 21600 EC*	55	Connection at 21600 bits/s
CONNECT 24000 EC*	56	Connection at 24000 bits/s
CONNECT 26400 EC*	57	Connection at 26400 bits/s
CONNECT 28800 EC*	58	Connection at 28800 bits/s

## Result Code Summary (*Continued*)

Result Code	Numeric	Description
CONNECT 31200 EC*	59	Connection at 31200 bits/s
CONNECT 33600 EC*	60	Connection at 33600 bits/s
CONNECT 38400 EC*	28	Connection at 38400 bits/s (DTE rate)
CONNECT 57600 EC*	18	Connection at 57600 bits/s (DTE rate)
CONNECT 115200 EC	87	Connection at 115200 bits/s (DTE rate)
DELAYED	88	Delay is in effect for the dialed number
BLACKLISTED	89	Dialed number is blacklisted
OK	0	Command executed
CONNECT	1	Modem connected to line
RING	2	A ring signal has been detected
NO CARRIER	3	Modem lost carrier signal, or does not detect carrier signal, or does not detect answer tone
ERROR	4	Invalid command
CONNECT 1200 EC*	5	Connection at 1200 bits/s
NO DIALTONE	6	No dial tone detected
BUSY	7	Busy signal detected
NO ANSWER	8	Remote end never answered
CONNECT 2400 EC*	10	Connection at 2400 bits/s
CONNECT 4800 EC*	11	Connection at 4800 bits/s
CONNECT 9600 EC*	12	Connection at 9600 bits/s

## Result Code Summary (*Continued*)

Result Code	Numeric	Description
CONNECT 14400 EC*	13	Connection at 14400 bits/s
CONNECT 19200 EC*	14	Connection at 19200 bits/s
CONNECT 7200 EC*	24	Connection at 7200 bits/s
CONNECT 12000 EC*	25	Connection at 12000 bits/s
CONNECT 16800 EC*	86	Connection at 16800 bits/s
CONNECT 300 EC*	40	Connection at 300 bits/s
CONNECT 21600 EC*	55	Connection at 21600 bits/s
CONNECT 24000 EC*	56	Connection at 24000 bits/s
CONNECT 26400 EC*	57	Connection at 26400 bits/s
CONNECT 28800 EC*	58	Connection at 28800 bits/s
CONNECT 31200 EC*	59	Connection at 31200 bits/s
CONNECT 33600 EC*	60	Connection at 33600 bits/s
CONNECT 38400 EC*	28	Connection at 38400 bits/s (DTE rate)
CONNECT 57600 EC*	18	Connection at 57600 bits/s (DTE rate)
CONNECT 115200 EC	87	Connection at 115200 bits/s (DTE rate)
DELAYED	88	Delay is in effect for the dialed number
BLACKLISTED	89	Dialed number is blacklisted
BLACKLIST FULL	90	Blacklist is full
CONNECT 32000 EC*	70	Connection at 32000 bits/s (K56flex mode) or V.90
CONNECT 34000 EC*	71	Connection at 34000 bits/sbits/s (K56flex mode)

## Result Code Summary (Continued)

Result Code	Numeric	Description
CONNECT 36000 EC*	72	Connection at 36000 bits/s (K56flex mode) or V.90
CONNECT 38000 EC*	73	Connection at 38000 bits/s (K56flex mode)
CONNECT 40000 EC*	74	Connection at 40000 bits/s (K56flex mode) or V.90
CONNECT 42000 EC*	75	Connection at 42000 bits/s (K56flex mode)
CONNECT 44000 EC*	76	Connection at 44000 bits/s (K56flex mode) or V.90
CONNECT 46000 EC*	77	Connection at 46000 bits/s (K56flex mode)
CONNECT 48000 EC*	78	Connection at 48000 bits/s (K56flex mode) or V.90
CONNECT 50000 EC*	79	Connection at 50000 bits/s (K56flex mode)
CONNECT 52000 EC*	80	Connection at 52000 bits/s (K56flex mode) or V.90
CONNECT 54000 EC*	81	Connection at 54000 bits/s (K56flex mode)
CONNECT 56000 EC*	82	Connection at 56000 bits/s (K56flex mode)
CONNECT 28000 EC*	100	Connection at 28000 bits/s (V.90 mode)
CONNECT 29333 EC*	101	Connection at 29333 bits/s (V.90 mode)
CONNECT 30666 EC*	102	Connection at 30666 bits/s (V.90 mode)
CONNECT 33333 EC*	103	Connection at 33333 bits/s (V.90 mode)

## Result Code Summary (*Continued*)

Result Code	Numeric	Description
CONNECT 34666 EC*	104	Connection at 34666 bits/s (V.90 mode)
CONNECT 37333 EC*	105	Connection at 37333 bits/s (V.90 mode)
CONNECT 38666 EC*	106	Connection at 38666 bits/s (V.90 mode)
CONNECT 41333 EC*	107	Connection at 41333 bits/s (V.90 mode)
CONNECT 42666 EC*	108	Connection at 42666 bits/s (V.90 mode)
CONNECT 45333 EC*	109	Connection at 45333 bits/s (V.90 mode)
CONNECT 46666 EC*	110	Connection at 46666 bits/s (V.90 mode)
CONNECT 49333 EC*	111	Connection at 49333 bits/s (V.90 mode)
CONNECT 50666 EC*	112	Connection at 50666 bits/s (V.90 mode)

## Result Code Summary (*Continued*)

Result Code	Numeric	Description
CONNECT 53333 EC*	113	Connection at 53333 bits/s (V.90 mode)
CONNECT 54666 EC*	114	Connection at 54666 bits/s (V.90 mode)

\*EC only appears when the extended result codes configuration option is enabled. EC is replaced by one of the following symbols, depending upon the error control method used:

- V.42bis–V.42 error control and V.42bis data compression
  - V.42–V.42 error control only
  - MNP 5–MNP class 4 error control and MNP class 5 data compression
  - MNP 4–MNP class 4 error control only
  - NoEC–No error control protocol
-

## **AT Command Descriptions**

### **+++ Escape Sequence**

The escape sequence allows the modem to exit data mode and enter online command mode. While in online command mode, you may communicate directly to your modem using AT commands. Once you are finished, you may return to data mode using the AT0 command.

A pause, the length of which is set by the Escape Guard Time (S12), must be used after an escape sequence is issued. This pause prevents the modem from interpreting the escape sequence as data.

The value of the escape sequence character may be changed using Register S2.

Do not precede this command with an AT prefix or conclude it by pressing **enter**.

### **A Answer Command**

This command instructs the modem to go off-hook and answer an incoming call.

### **A/ Repeat Last Command**

This command repeats the last command string entered. Do not precede this command with an AT prefix or conclude it by pressing **enter**.

## Bn Communication Standard Setting

This command determines CCITT vs. Bell standard.

- B0 Selects CCITT V.22 mode when the modem is at 1200 bits/s.
- B1 Selects Bell 212A when the modem is at 1200 bits/s (default).
- B2 Deselects V.23 reverse channel (same as B3).
- B3 Deselects V.23 reverse channel (same as B2).
- B15 Selects V.21 when the modem is at 300 bits/s.
- B16 Selects Bell 103J when the modem is at 300 bits/s (default).

### Result Codes

- OK n = 0, 1, 2, 3, 15, 16
- ERROR Otherwise

## Cn Carrier Control

The modem will accept the C1 command without error in order to assure backward compatibility with communications software that issues the C1 command. However, this modem does not support the C0 command. The C0 command may instruct some other modems to not send carrier (i.e., it puts them in a receive-only mode).

- C0 Transmit carrier always off.
- C1 Normal transmit carrier switching.

### Result Codes

- OK n = 1
- ERROR Otherwise



## Dn Dial

This command instructs the modem to begin the dialing sequence. The dial string (n, including modifiers and the telephone number) is entered after the ATD command.

A dial string can be up to 40 characters long. Any digit or symbol (0–9, \*, #, A, B, C, D) may be dialed as touch-tone digits. Characters such as spaces, hyphens, and parentheses do not count; they are ignored by the modem and may be included in the dial string to enhance readability.

The following may be used as dial string modifiers.

L	Redials last number. Should be the first character following ATD, ignored otherwise.
P	Pulse dialing.
T	Touch-tone dialing (default).
,	Pause during dialing. Pause for time specified in Register S8 before processing the next character in the dial string.
W	Wait for dial tone. Modem waits for a second dial tone before processing the dial string.
@	Wait for quiet answer. Wait for five seconds of silence after dialing the number. If silence is not detected, the modem sends a NO ANSWER result code back to the user.
!	Hook flash. Causes the modem to go on-hook for 0.5 seconds and then return to off-hook.
;	Return to command mode. Causes the modem to return to command mode after dialing the number without disconnecting the call.
^	Disable data calling tone transmission.
S=n	Dial a telephone number previously stored using the &Zn=x command (see the &Zn=x command for further information). The range of n is 0–3.
\$	Bong tone detection.

## En Echo Command

This command controls whether the characters entered from your computer keyboard are echoed back to your monitor while the modem is in command mode.

- E0 Disables echo to the computer.
- E1 Enables echo to the computer (default).

### Result Codes

- OK n = 0, 1
- ERROR Otherwise

## Fn Online Data Character Echo Command

This command determines whether the modem will echo data from the DTE. This modem does not support the F0 version of the command. However, the modem will accept F1, which may be issued by older communication software, to assure backward compatibility.

- F0 Online data character echo enabled (NOT SUPPORTED, responds ERROR).
- F1 Online character echo disabled.

### Result Codes

- OK n = 1
- ERROR Otherwise

## Hn Hook Control

This command instructs the modem to go on-hook to disconnect a call, or off-hook to make the phone line busy.

- H0 Modem goes on-hook (default).
- H1 Modem goes off-hook.

## Result Codes

OK            n = 0, 1  
ERROR        Otherwise

## In     Request ID Information

This command displays specific product information about the modem.

- l0     Returns default speed and controller firmware version, same as l3.
- l1     Calculates ROM checksum and displays it on the DTE.
- l2     Performs a ROM check and calculates and verifies the checksum displaying OK or ERROR.
- l3     Returns the default speed and the controller firmware version, same as l0.
- l4     Returns firmware version for data pump.
- l5     Returns the board ID: software version, hardware version, and country ID.
- l6     Returns OK.
- l7     Returns OK.
- l8     Returns OK.
- l9     Returns country code (i.e., NA Ver. 1).
- l11    Displays connection information as described in following table.

## Result Codes

OK            n = 0, 1, 2, 3, 4, 9  
ERROR        Otherwise

The AT+I11 result has two pages; the user must hit a key to get the second page.

	<b>Description</b>	<b>K56flex Connection</b>	<b>V.90 Connection</b>
1	Last Connection	56K	V.90
2	Initial Transmit Carrier Rate	28800	28800
3	Initial Receive Carrier Rate	50000	49333
4	Final Transmit Carrier Rate	28800	28800
5	Final Receive Carrier Rate	50000	49333
6	Protocol Negotiation Result	LAPM	LAPM
7	Data Compression Result	V42bis	V42bis
8	Estimated Noise Level	152	152
9	Receive Signal Power Level (-dBm)	25	25
10	Transmit Signal Power Level (-dBm)	16	16
11	Round Trip Delay (msec)	4	4

Press any key to continue; ESC to quit.

	<b>Description</b>	<b>K56flex Connection</b>	<b>V.90 Connection</b>
12	Near Echo Level (-dBm)	NA	NA
13	Far Echo Level (-dBm)	NA	NA
14	Transmit Frame Count	3	3
15	Transmit Frame Error Count	0	0
16	Receive Frame Count	0	0
17	Receive Frame Error Count	0	0
18	Retrain by Local Modem	0	0
19	Retrain by Remote Modem	0	0
20	Call Termination Cause	0	0
21	Robbed-Bit Signaling	00	00
22	Digital Loss (dB)	6	6
23	Remote Server ID	4342C3	NA

OK

The AT+I11 command may be issued from online command mode or after the end of a call. After a call, some values are no longer valid; it is useful to know which ones. Each of the line items in the AT+I11 result is explained next:

1. V.90, 56K, V.34, or V.32 depending on the type of connection negotiated.
2. Initial upstream rate.

3. Initial downstream rate.
4. Current or final upstream rate.
5. Current or final downstream rate.
6. LAPM or MNP or None, depending on V.42 negotiation.
7. V42bis or MNP or None, depending on V.42 negotiation.
8. Mean-square error of received downstream signal. This is the difference between received constellation point and reference decision point. This is a dimensionless decimal number, only valid during a call. Higher numbers are worse. There is no absolute quality threshold; it depends on the downstream data rate. The number varies during a call, so it can be useful to sample a few times.

The received signal power, although labeled -dBm, is only a relative measure for comparing calls to/from different locations. Only valid during a call.
9. Upstream transmit signal power.
10. Round-trip delay in milliseconds.
11. Echo levels are valid for V.34 only.
12. Echo levels are valid for V.34 only.
13. Number of LAPM frames sent upstream during this call. Count wraps around at 65535.
14. Number of REJ frames received at the analog client modem.
15. Number of LAPM frames received by the client during this call. Count wraps around at 65535.
16. Number of frames received in error by the client.
17. Number of retrains or rate renegotiations requested by this modem.
18. Number of retrains or rate renegotiations requested by remote modem.

19. Reason for call ending, only valid after call ends:
  - 0 Local modem command: ATH, DTR drop
  - 1 Remote modem: cleardown, loss of signal
  - 2 No answer, busy, etc.
  - 3 Training failure V.90, K56flex or V.34.
  - 4 Protocol failure if required by W4, for example.
20. For PCM connection only, a hexadecimal 6-bit pattern of T1 frames with robbed-bit signaling.
21. For PCM connection only, the downstream digital loss.
22. For K56flex connection only, the V.8bis info sent by the server. Meaning is defined at the server and by convention.
23. Example above is from a recent Ascend MAX in u-Law.

## **Ln Monitor Speaker Volume**

This command sets speaker volume to low, medium, or high.

- L0 Selects low volume.
- L1 Selects low volume.
- L2 Selects medium volume (default).
- L3 Selects high volume.

### **Result Codes**

- OK            n = 0, 1, 2, 3
- ERROR        Otherwise

## Mn Monitor Speaker Mode

This command turns the speaker on or off.

- M0 The speaker is off.
- M1 The speaker is on until the modem detects the carrier signal (default).
- M2 The speaker is always on when modem is off-hook.
- M3 The speaker is on until the carrier is detected, except while dialing.

### Result Codes

- OK n = 0, 1, 2, 3
- ERROR Otherwise

## Nn Modulation Handshake

This command controls whether or not the local modem performs a negotiated handshake at connection time with the remote modem when the communication speed of the two modems is different.

- N0 When originating or answering, this is for handshake only at the communication standard specified by S37 and the ATB command.
- N1 When originating or answering, begin the handshake only at the communication standard specified by S37 and the ATB command. During handshake, fallback to a lower speed may occur (default).

### Result Codes

- OK n = 0, 1
- ERROR Otherwise



## **On Return Online to Data Mode**

- 00 Instructs the modem to exit online command mode and return to data mode (see AT Escape Sequence, +++).
- 01 This command issues a retrain before returning to online data mode.
- 03 This command issues a rate renegotiation before returning to online data mode.

### **Result Codes**

- OK            n = 0, 1, 3
- ERROR        Otherwise

## **P Select Pulse Dialing**

This command configures the modem for pulse (non touch-tone) dialing. Dialed digits are pulsed until a T command or dial modifier is received. Tone dial is the default setting.

## **Qn Result Code Control**

Result codes are informational messages sent from the modem and displayed on your monitor. Basic result codes are OK, CONNECT, RING, NO CARRIER, and ERROR. The ATQ command allows the user to turn result codes on or off.

- Q0 Enables modem to send result codes to the computer (default).
- Q1 Disables modem from sending result codes to the computer.

### **Result Codes**

- OK            n = 0, 1
- ERROR        Otherwise

## T Select Tone Dialing

This command instructs the modem to send DTMF tones while dialing. Dialed digits are tone dialed until a P command or dial modifier is received. This is the default setting.

## Vn DCE Response Format

This command controls whether result codes (including call progress and negotiation progress messages) are displayed as words or their numeric equivalents.

For the result code, see the “Result Code Summary” section of this document.

- V0 Displays result codes as digits.
- V1 Displays result codes as text (default).

## Result Codes

- OK n = 0, 1
- ERROR Otherwise

	ATV0	ATV1
<b>Result Code Format</b>	<numeric code><CR>	<CR><LF> <verbose code><CR><LF>

## Wn Result Code Option

- W0 CONNECT result code reports DTE speed. Disable protocol result codes.
- W1 CONNECT result code reports DTE speed. Enable protocol result codes.
- W2 CONNECT result code reports DCE receive speed. Enable protocol result codes (default).

## Result Codes

OK            n = 0, 1, 2

ERROR        Otherwise

## Xn Result Code Selection and Call Progress Monitoring

This command enables tone detection options used in the dialing process. As these functions are chosen, the result codes of the modem chip set are also affected. Therefore, this command is frequently used to control the responses of the modem chip set.

	<b>Extension Result Code</b>	<b>Dial Tone Detect</b>	<b>Busy Tone Detect</b>
X0	Disable	Disable	Disable
X1	Enable	Disable	Disable
X2	Enable	Enable	Disable
X3	Enable	Disable	Enable
X4	Enable	Enable	Enable (default)
X5	Enable	Enable	Enable
X6	Enable	Enable	Enable
X7	Disable	Enable	Enable

## Extended Result Codes

Disabled:        Displays only the basic result codes OK, CONNECT, RING, NO CARRIER, and ERROR.

Enabled:         Displays basic result codes, along with the connect message and the modem's data rate, and an indication of the modem's error correction and data compression operation.

## Dial Tone Detect

- Disabled: The modem dials a call regardless of whether it detects a dial tone. The period of time the modem waits before dialing is specified in Register S6.
- Enabled: The modem dials only upon detection of a dial tone, and disconnects the call if the dial tone is not detected within 10 seconds.

## Busy Tone Detect

- Disabled: The modem ignores any busy tones it receives.
- Enabled: The modem monitors for busy tones.

## Result Codes

- OK            n = 0, 1, 2, 3, 4, 5, 6, 7
- ERROR        Otherwise

## Yn Long Space Disconnect

Long space disconnect is always disabled.

- Y0    Disables long space disconnect (default).
- Y1    Enables long space disconnect—NOT SUPPORTED.

## Result Codes

- OK            n = 0
- ERROR        Otherwise

## Zn Recall Stored Profile

This command instructs the modem chip set to go on-hook and restore the profile saved by the last &W command. Either Z0 or Z1 restores the same single profile.

### Result Codes

OK            n = 0, 1  
ERROR        Otherwise

## &Bn V.32 Auto Retrain

This modem always auto retrains.

&B0    Disables V.32 auto retrain—NOT SUPPORTED.  
&B1    Enables V.32 auto retrain (default).

### Result Codes

OK            n = 1  
ERROR        Otherwise

## &Cn Data Carrier Detect (DCD) Control

Data Carrier Detect is a signal from the modem to your computer indicating that the carrier signal is being received from a remote modem. DCD normally turns off when the modem no longer detects the carrier signal.

&C0    The state of the carrier from the remote modem is ignored. DCD circuit is always on.  
&C1    DCD turns on when the remote modem's carrier signal is detected, and off when the carrier signal is not detected (default).

## Result Codes

OK            n = 0, 1  
ERROR        Otherwise

## &Dn DTR Control

This command interprets how the modem responds to the state of the DTR signal and changes to the DTR signal.

- &D0 Ignore. The modem ignores the true status of DTR and treats it as always on. This should only be used if your computer does not provide DTR to the modem.
- &D1 If the DTR signal is not detected while in online data mode, the modem enters command mode, issues OK result code, and remains connected.
- &D2 If the DTR signal is not detected while in online data mode, the modem disconnects (default).
- &D3 Reset on the on-to-off DTR transition.

## Result Codes

OK            n = 0, 1, 2, 3  
ERROR        Otherwise

## &Fn Load Factory Settings

This command loads the configuration stored and programmed at the factory. This operation replaces all of the command options and the S-register settings in the active configuration with factory values.

## &Gn V.22bis Guard Tone Control

This command determines which guard tone, if any, to transmit while transmitting in the high band (answer mode). This command is only used in V.22 and V.22bis mode. This option is not used in North America and is for international use only.

&G0 Guard tone disabled (default).

&G1 Sets guard tone to 550 Hz.

&G2 Sets guard tone to 1800 Hz.

### Result Codes

OK n = 0, 1, 2

ERROR Otherwise

## &Jn Auxiliary Relay Option

&J0 The auxiliary relay is never closed.

&J1 NOT SUPPORTED, responds ERROR.

### Result Codes

OK n = 0

ERROR Otherwise

## **&Kn Local Flow Control Selection**

- &K0 Disables flow control.
- &K1 Reserved.
- &K2 Reserved.
- &K3 Enables RTS/CTS flow control (default).
- &K4 Enables XON/XOFF flow control.

### **Result Codes**

- OK            n = 0, 3, 4
- ERROR        Otherwise

## **&Mn Asynchronous Communications Mode**

- &M0 Asynchronous mode (default).
- &M1 Reserved.
- &M2 Reserved.
- &M3 Reserved.
- &M4 Reserved.

### **Result Codes**

- OK            n = 0
- ERROR        Otherwise



## &Pn Pulse Dial Make-to-Break Ration Selection

- &P0 39/61 make/break ratio, 10PPS.
- &P1 33/67 make/break ratio, 10PPS (default).
- &P2 33/67 make/break ratio, 20PPS.
- &P3 Reserved.
- &P4 Reserved.

### Result Codes

- OK n = 0, 1, 2
- ERROR Otherwise

## &Qn Asynchronous Communications Mode

- &Q0 Asynchronous Mode, buffered. Same as \N0.
- &Q5 Error Control Mode, buffered (default). Same as \N3.
- &Q6 Asynchronous Mode, buffered. Same as \N0.
- &Q8 MNP error control mode. If an MNP error control protocol is not established, the modem will fall back according to the current user setting in S36.
- &Q9 V.42 or MNP error control mode. If either error control protocol is established, the modem will fall back according to the current user setting in S36.

### Result Codes

- OK n = 0, 5, 6, 8, 9
- ERROR Otherwise

## &Sn Data Set Ready (DSR) Option

This command selects DSR action.

&S0 DSR always ON (default).

&S1 DSR comes on when establishing a connection and goes off when the connection ends.

## Result Codes

OK            n = 0, 1

ERROR        Otherwise

## &Tn Self-Test Commands

This command allows the user to perform diagnostic tests on the modem. These tests can help to isolate problems when experiencing periodic data loss or random errors.

&T0 Abort. Stops any test in progress.

&T1 Local analog loop. This test verifies modem operation, as well as the connection between the modem and computer. Any data entered at the local DTE is modulated, then demodulated, and returned to the local DTE. To work properly, the modem must be offline.

&T3 Local digital loopback test.

&T6 Remote digital loopback test. This test can verify the integrity of the local modem, the communications link, and the remote modem. Any data entered at the local DTE is sent to, and returned from the remote modem. To work properly, the modems must be online with error control disabled.

## Result Codes

OK            n = 0  
 CONNECT n = 1, 3, 6  
 ERROR        Otherwise

## &V View Active Configuration and Stored Profile

This command is used to display the active profiles.

&V0 View active file.

For example:

Option	Selection	AT Command
Comm Standard	Bell	B
CommandCharEcho	Enabled	E
Speaker Volume	Medium	L
Speaker Control	OnUntilCarrier	M
Result Codes	Enabled	Q
Dialer Type	Tone	T/P
Result Code Form	Text	V
Extend Result Code	Enabled	X
Dial Tone Detect	Enabled	X
Busy Tone Detect	Enabled	X
LSD Action	Standard RS232	&C
DTR Action	Standard RS232	&D

Press any key to continue; ESC to quit.

<b>Option</b>	<b>Selection</b>	<b>AT Command</b>
V22b Guard Tone	Disabled	&G
Flow Control	Hardware	&K
Error Control Mode	V42, MNP, Buffer	\N
Data Compression	Enabled	%C
AutoAnswerRing#	0	S0
AT Escape Char	43	S2
CarriageReturnChar	13	S3
Linefeed Char	10	S4
Backspace Char	8	S5
Blind Dial Pause	2 sec	S6
NoAnswer Timeout	50 sec	S7
" , " Pause Time	2 sec	S8

Press any key to continue; ESC to quit.

<b>Option</b>	<b>Selection</b>	<b>AT Command</b>
No Carrier Disc	2000 msec	S10
DTMF Dial Speed	95 msec	S11
Escape GuardTime	1000 msec	S12
Data Calling Tone	Disabled	S35
Line Rate	33600	S37
DSVD mode	Disabled	-SSE

## Stored Phone Numbers

&Z0=

&Z1=

&Z2=

&Z3=

OK

## &Wn Store Current Configuration

This command stores certain command options and S-register values into the nonvolatile memory of the modem. The ATZ command or a power-up reset of the modem restores this profile.

### Result Codes

OK            n = 0

ERROR        Otherwise

## &Yn Select Stored Profile for Hard Reset

This command does not change the behavior of the modem, but is included for compatibility with applications that issue the &Y0 command.

&Y0    Select stored profile 0 on power-up.

&Y1    ERROR

### Result Codes

OK            n = 0

ERROR        Otherwise

## **&Zn=x Store Telephone Number**

This command is used to store up to four dialing strings in the nonvolatile memory of the modem for later dialing. The format for the command is &Zn = "stored number" where n is the location 0–3 to which the number should be written. The dial string may contain up to 40 characters. The ATDS = n command dials using the string stored in location n.

### **Result Codes**

OK            n = 0, 1, 2, 3  
ERROR        Otherwise

## **\An Select Maximum MNP Block Size**

The modem will operate an MNP error corrected link using a maximum block size controlled by the parameter supplied.

\A0    64 characters  
\A1    128 characters  
\A2    192 characters  
\A3    256 characters (default)

### **Result Codes**

OK            n = 0, 1, 2, 3  
ERROR        Otherwise

## **\Bn Transmit Break to Remote**

In non-error-control mode, the modem will transmit a break signal to the remote modem with a length in multiples of 100ms according to parameter specified. The command works in conjunction with the \K command.

\B1–\B9 Break length in 100ms units. (Default = 3; non-error-control mode only.)

## Result Codes

OK                    If connected in data modem mode.  
NO CARRIER    If not connected or connected in fax  
                          modem mode.

## \Gn    Modem Port Flow Control

\G0    Returns an “OK” for compatibility (default).  
\G1    NOT SUPPORTED, responds ERROR.

## Result Codes

OK            n = 0  
ERROR        Otherwise

## \J     Bits/s Rate Adjusted

This command determines whether or not the negotiated connect speed of the modem forces the adjustment of the speed of the DTE to the speed of the modem.

\J0    Buffer mode. Error control selected (or not) by  
          \Wn command (default).  
\J1    Force the max DCE rate to the DTE rate.

## Result Codes

OK            n = 0, 1  
ERROR        Otherwise

## **\K Break Control**

Controls the response of the modem to a break received from the DTE or the remote modem or the \B command. The response is different in three separate cases.

The first case is where the modem receives a break from the DTE when the modem is operating in data transfer mode:

- \K0 Enter online command mode, no break sent to remote modem.
- \K1 Clear data buffers and send break to remote modem.
- \K2 Same as \K0.
- \K3 Send break to remote modem immediately.
- \K4 Same as \K0.
- \K5 Send break to remote modem in sequence with transmitted data (default).

The second case is where the modem is in the online command state (waiting for AT commands) during a data connection, and the \B is received in order to send a break to the remote modem:

- \K0 Clear data buffers and send break to remote modem.
- \K1 Clear data buffers and send break to remote modem. Same as \K0.
- \K2 Send break to remote modem immediately.
- \K3 Send break to remote modem immediately. Same as \K2.
- \K4 Send break to remote modem in sequence with transmitted data.
- \K5 Send break to remote modem in sequence with transmitted data. Same as \K4; default.



The third case is where there is a break received from a remote modem during a connection:

- W0 Clear data buffers and send break to the DTE.
- W1 Clear data buffers and send break to the DTE. Same as W0.
- W2 Send break immediately to DTE.
- W3 Send break immediately to DTE. Same as W2.
- W4 Send break in sequence with received data to DTE.
- W5 Send break in sequence with received data to DTE. Same as W4; default.

## Result Codes

- OK n = 0, 1, 2, 3, 4, 5
- ERROR Otherwise

## Wn Error Control Mode Selection

This command determines the type of error control used by the modem when sending or receiving data.

- W0 Buffer mode. No error control. Same as &Q6.
- W1 Direct mode.
- W2 MNP or disconnect mode. The modem attempts to connect using MNP 2-4 error control procedures. If this fails, the modem disconnects. This is also known as MNP reliable mode.
- W3 V.42, MNP, or buffer (default). The modem attempts to connect in V.42 error control mode. If this fails, the modem attempts to connect in MNP mode. If this fails, the modem connects in buffer mode and continues operation. This is also known as V.42/MNP auto reliable mode. Same as &Q5.

- \N4 V.42 or disconnect. The modem attempts to connect in V.42 error control mode. If this fails, the call will be disconnected.
- \N5 V.42. MNP or buffer. Same as \N3.
- \N7 V.42. MNP or buffer. Same as \N3.

### Result Codes

OK            n = 0, 1, 2, 3, 4,5,7

### \Qn Local Flow Control Selection

- \Q0 Disable flow control. Same as &K0.
- \Q1 XON/XOFF software flow control. Same as &K4.
- \Q2 CTS-only flow control. This is not supported and the response is ERROR.
- \Q3 RTS/CTS to DTE (default). Same as &K3.

### Result Codes

OK            n = 0, 1, 3  
ERROR        Otherwise

### \Rn Ring indicator signal off after the telephone call is answered (Compatibility command)

- \R0 Ring indicator signal is off after the telephone call is answered.

### Result Codes

OK            n = 0  
ERROR        Otherwise

## **\Tn Inactivity Timer**

This command specifies the length of time (in minutes) that the modem will wait before disconnecting when no data is sent or received. A setting of zero disables the timer. Alternatively, this timer may be specified in Register S30. This function is only applicable to buffer mode.

\T0 Inactivity timer disabled (default).

### **Result Codes**

OK            n = 0-255  
ERROR        Otherwise

## **\Wn Protocol Result Code**

W0    Disable protocol result code appended to DCE speed.  
W1    Enable protocol result code appended to DCE speed  
      (default).  
W2    Same as W1.

### **Result Codes**

OK            n = 0, 1  
ERROR        Otherwise

## **\Xn XON/XOFF Pass Through**

**X0** Modem processes XON/XOFF flow control characters locally (default).

**X1** Modem processes and passes XON/XOFF flow control characters.

### **Result Codes**

**OK**            n = 0, 1

**ERROR**        Otherwise

## **-Cn Data Calling Tone**

Data Calling Tone is a tone of certain frequency and cadence as specified in V.25 which allows remote Data/FAX/Voice discrimination. The frequency is 1300 Hz with a cadence of .5 s on and 2 s off.

**-C0** Disabled (default).

**-C1** Enabled.

### **Result Codes**

**OK**            n = 0, 1

**ERROR**        Otherwise

## **-V90=<n> Command to enable/disable V.90 and change downstream rate**

- V90=0 Disables V.90.
- V90=1 Enables V.90 Auto Rate (default value).
- V90=n Controls the downstream rate.
- V90? Shows the current value.
- V90=? Shows the range [0–21].

The table below shows the possible values of n.

<b>AT-V90=n</b>	<b>Downstream Rate</b>
0	V.90 disabled
1	Auto Rate (default)
2	28000 kbit/s
3	29333 kbit/s
4	30666 kbit/s
5	32000 kbit/s
6	33333 kbit/s
7	34666 kbit/s
8	36000 kbit/s
9	37333 kbit/s
10	38666 kbit/s
11	40000 kbit/s
12	41333 kbit/s
13	42666 kbit/s
14	44000 kbit/s

*(Continued)*

<b>AT-V90=n</b>	<b>Downstream Rate</b>
15	45333 kbit/s
16	46666 kbit/s
17	48000 kbit/s
18	49333 kbit/s
19	50666 kbit/s
20	52000 kbit/s
21	53333 kbit/s

## **%B View Numbers in Blacklist**

If blacklisting is in effect, this command displays the numbers for which the last call attempted in the past two hours failed. The ERROR result code appears in countries that do not require blacklisting.

## **%Cn Data Compression Control**

This command determines the operation of V.42bis and MNP class 5 data compression. Online changes do not take effect until a disconnect occurs first.

**%C0** V.42bis/MNP 5 disabled. No data compression.

**%C1** V.42bis/MNP 5 enabled. Data compression enabled (default).

## **Result Codes**

OK            n = 0, 1

ERROR        Otherwise

## **%En Enable/Disable Auto-Retrain and Fallback/Fall Forward**

Provides option for the modem to automatically monitor line quality to fall back when line quality is insufficient and to fall forward when line quality is sufficient.

- %E0 Disables fallback/fall forward.
- %E1 Enables fallback/disable fall forward.
- %E2 Enables fallback/fall forward (default).

### **Result Codes**

- OK            n = 0, 1, 2
- ERROR        Otherwise

## **VDR Distinctive Ring and Cadence Report**

This command enables the distinctive ring feature which allows a report of DROF/DRON to follow an exact ring cadence sent over the phone line.

- VDR?            Returns the current values of <enable> and <report>/.
- VDR+?            Queries the DCE for the range of supported distinctive ring configurations.
- DCE returns:    (0,1), (0-255)

---

## S-Registers

### Setting S-Register Default Values

The S-register default values function reliably under most circumstances. However, these values may be modified if necessary.

For example, it may take an especially long time to get a dial tone in your office, so you may choose to reset S7 for a longer wait time.

### Modifying an S-Register

You can modify or change the value of an S-register from Command Mode (Terminal Mode) or from a standard data or fax communication application. For example:

- Type `ATS11=70`, then press **enter**.
- This sets S11 to a value of 70.
- If you then enter `AT = 95`, it resets S11 to a value of 95 since the modem remembered that S11 was the last register referenced.
- If you enter an `S =` command with no parameter (value), the register number defaults to zero and the modem changes the value of S0. Therefore, the following commands are equivalent: `ATS0 = 3` and `ATS = 3`.



## Reading an S-Register

To read the contents of a given S-register in the Terminal Mode (Command Mode), type `ATS $n$` ? (where  $n$  is the number of the register), then press **enter**.

When modifying a register, the modem also remembers the location of the last inquiry. For example, the following sequence of commands display the contents of the S11 register:

`ATS11?`     This command displays the value of S11.

`AT?`         This command also displays the value of S11.

When you use an `S?` with no value, the register number defaults to zero and the modem responds with the value of S0 (for example `ATS?`).

Register	Default	Description
S0	0	Automatic answer ring number
S1	0	Ring counter
S2	43	AT escape character
S3	13	Command line termination character
S4	10	Response formatting character
S5	8	Command line editing character
S6	2	Wait before dialing
S7	50	Connection completion time-out
S8	2	Comma dial modifier time
S10	20	Automatic disconnect delay
S11	95	DTMF dialing speed
S12	50	Escape guard time
S14	8	General bit-mapped options status
S21	48	V.24 bit-mapped options status

Register	Default	Description
S22	112	Results bit-mapped options status
S24	10	Timer to control sleep mode
S28	1	V.34 modulation enable/disable
S30	0	Inactivity timer
S32		Synthetic ring volume
S33		Synthetic ring frequency
S35	0	Data calling tone
S36	7	Negotiation fallback
S37	0	Dial line rate
S38	1	Enable/disable K56flex settings
S42*	1	Auto rate
S43*	1	Auto mode
S48	7	LAPM error control and feature negotiation
S89	10	Timer to control sleep mode
S90		Read-only local phone
S91	15	Line transmit level
S108	7	Network codec type
S109		Enable

\*S-registers 42 and 43 are for test and debugging purposes only.

## S-Register Descriptions

### **S0 Auto Answer Ring Number**

This register determines the number of rings the modem will count before automatically answering a call. Enter 0 (zero) if you do not want the modem to automatically answer at all. When disabled, the modem can only answer with an ATA command.

Range: 0-255

Default: 0

Units: Rings

### **S1 Ring Counter**

This register is read-only. The value of S1 is incremented with each ring. If no rings occur over a six second interval, this register is cleared.

Range: 0-255

Default: 0

Units: Rings

### **S2 AT Escape Character (user defined)**

This register determines the ASCII value used for an escape sequence. The default is the + character. The escape sequence allows the modem to exit data mode and enter command mode when online. Values greater than 127 disable the escape sequence.

Range: 0-255

Default: 43

Units: ASCII

### **S3 Command Line Termination Character (user defined)**

This register determines the ASCII values as the carriage return character. This character is used to end command lines and result codes.

Range: 0-127, ASCII decimal

Default: 13 (carriage return)

Units: ASCII

### **S4 Response Formatting Character (user defined)**

This register determines the ASCII value used as the line feed character. The modem uses a line feed character in command mode when it responds to the computer.

Range: 0-127, ASCII decimal

Default: 10 (line feed)

Units: ASCII

## **S5 Command Line Editing Character (user defined)**

This register sets the character recognized as a backspace and pertains to asynchronous only. The modem will not recognize the backspace character if it is set to a value that is greater than 32 ASCII. This character can be used to edit a command line. When the echo command is enabled, the modem echoes the backspace character, an ASCII space character, and a second backspace character back to the local DTE. This means a total of three characters are transmitted each time the modem processes the backspace character.

Range: 0-127, ASCII decimal

Default: 8 (backspace)

Units: ASCII

## **S6 Wait Before Dialing**

This register sets the length of time, in seconds, that the modem must wait after going off-hook before dialing the first digit of the telephone number. The modem always pauses for a minimum of two seconds, even if the value of S6 is less than two seconds. The wait for dial tone call progress feature (W dial modifier in the dial string) will override the value in Register S6. This operation, however, may be affected by some ATX options according to country restrictions.

Range: 2-65

Default: 2

Units: Seconds

## **S7 Connection Completion Time-Out**

This register sets the time, in seconds, that the modem must wait before hanging up because carrier is not detected. The timer is started when the modem finishes dialing (originate), or goes off-hook (answer). In originate mode, the timer is reset upon detection of an answer tone if allowed by country restriction. The timer also specifies the wait for silence time for the @ dial modifier in seconds. S7 is not associated with the W dial modifier.

Range: 1-255

Default: 50

Units: Seconds

## **S8 Comma Dial Modifier Time**

This register sets the time, in seconds, that the modem must pause when it encounters a comma (,) in the dial command string.

Range: 0-65

Default: 2

Units: Seconds

## **S10 Automatic Disconnect Delay**

This register sets the length of time, in tenths of a second, that the modem waits before hanging up after a loss of carrier. This allows for a temporary carrier loss without causing the local modem to disconnect.

The actual interval the modem waits before disconnecting is the value in Register S10.

Range: 1-254

Default: 20

Units: .1 seconds

## S11 DTMF Dialing Speed

This register determines the dialing speed which is prefixed for each country.

Range: 50-150

Default: 95

Units: .001 seconds

## S12 Escape Guard Time

This register sets the value (in 20 ms increments) for the required pause after the escape sequence (default 1 s).

Range: 0-255

Default: 50

Units: .02 seconds

## S14 General Bit Mapped Options Status

Indicates the status of command options. Only bit 3 and bit 6 are used, read-only.

Bit 3 Result codes (Vn)

0 Numeric (V0)

1 Verbose (V1) (Default)

Bit 6 Pulse dial PPS selection (&Pn)

0 10 PPS (&P0, &P1) (Default)

1 20 PPS (&P2)

Default: 8 (00001000b)

## S21 V.24/General Bit Mapped Options Status

Indicates the status of command options. Only bits 3, 4, and 5 are used, read-only.

Bits 3-4	DTR behavior (&Dn)
0	&D0 selected
1	&D1 selected
2	&D2 selected (Default)
3	&D3 selected
Bit 5	DCD behavior (&Cn)
0	&C0 selected
1	&C1 selected (Default)
Default:	48 (00110000b)

## S22 Results Bit Mapped Options Status

Indicates the status of command options. Only bits 4, 5, and 6 are used, read only.

Bits 4-6	Result codes (Xn)
0	X0 selected
4	X1 selected
5	X2 selected
6	X3 selected
7	X4 selected (Default)
Bit 7	Pulse dial make/break ratio (&Pn)
0	33/67 make/break ratio (&P1, &P2) (Default)
1	39/61 make/break ratio (&P0)
Default:	112 (01110000b)



## S24 Timer to Control Sleep Mode

This command displays the number of seconds of inactivity (no characters sent from DTE, no RING) in the off-line command state before the modem places itself into standby mode. A value of zero prevents standby mode. S24 is an alias for S89.



---

If a number between 1 and 4 is entered for this register, it will set the value to 5, and the inactivity before standby will be 5 seconds. This is done for compatibility with previous products that allowed time-outs down to one second.

---

Range: 0, 5-255

Default: 10

Units: Seconds

## S28 V.34 Modulation Enable/Disable

This register enables/disables V.34 modulation.

0 = disabled, 1-255 = enabled

Range: 0-255

Default: 1

## S30 Inactivity Timer

S30 specifies the length of time (in minutes) that the modem will wait before disconnecting when no data is sent or received. This function is only applicable to buffer mode.

Range: 0-255

Default: 0

Units: Minutes

## S35 Data Calling Tone

Data Calling Tone is a tone of certain frequency and cadence as specified in V.25 which allows remote Data/FAX/Voice discrimination. The frequency is 1300 Hz with a cadence of .5 s on and 2 s off.

0 = disabled, 1 = enabled

Range: 0-1

Default: 0

## S36 Negotiation Fallback

This is a non-operational command that is included for compatibility with older programs. Use the W command to change EC protocol behavior.

## S37 Dial Line Rate (default 0)

This register sets the maximum line data rate. In K56flex and V.90 mode, S37 controls the upstream V.34 rate.

S37 = 0 Auto rate

S37 = 1 Reserved

S37 = 2 1200/75 bits/s

S37 = 3 300 bits/s

S37 = 4 Reserved

S37 = 5 1200 bits/s

S37 = 6 2400 bits/s

S37 = 7 4800 bits/s

S37 = 8 7200 bits/s

S37 = 9 9600 bits/s

S37 = 10 12000 bits/s

S37 = 11	14400 bits/s
S37 = 12	16800 bits/s
S37 = 13	19200 bits/s
S37 = 14	21600 bits/s
S37 = 15	24000 bits/s
S37 = 16	26400 bits/s
S37 = 17	28800 bits/s
S37 = 18	31200 bits/s
S37 = 19	33600 bits/s

## S38 K56flex Downstream Rate

To force a particular K56flex downstream rate, use Register S38. S38 = 0 disables K56flex, and may allow a more reliable V.34 connection. S38 = 1 default allows the modem to select the downstream rate automatically. Other values of S38 force the downstream rate, with fallback to V.34 if unsuccessful at the configured rate:

S38 = 0	56K disabled
S38 = 1	56K enabled—automatic rate selection (default)
S38 = 2	32000 bits/s
S38 = 3	34000 bits/s
S38 = 4	36000 bits/s
S38 = 5	38000 bits/s
S38 = 6	40000 bits/s
S38 = 7	42000 bits/s
S38 = 8	44000 bits/s
S38 = 9	46000 bits/s
S38 = 10	48000 bits/s

S38 = 11 50000 bits/s

S38 = 12 52000 bits/s

S38 = 13 54000 bits/s

S38 = 14 56000 bits/s

The following chart shows how the number of robbed-bit signaling (RBS) frames detected decreases the true DCE rate.

RBS Links	Rate Hit (kbit/s)
0	0
1	2
2	4
3	4
4	6
5	8
6	8

For example, if S38 = 10 and there are 3 RBS links, the K56flex downstream rate will be  $48 - 4 = 44$  kbit/s. The exception is for 32 kbit/s and 34 kbit/s, which are the true rates regardless of RBS frames detected.

## S42 Auto Rate

This command is used for testing and debugging only.

V.32bis and V.22bis auto rate is disabled. Retrain operation is disabled or enabled in data mode, and fallback is disabled in data mode.

0 = auto rate disabled, 1 = enabled.

Range: 0-1

Default: 1

## S43 Auto Mode

This command is used for testing and debugging only.

V.32bis startup auto mode operation disabled.

0 = auto mode disabled, 1 = enabled.

Range: 0-1

Default: 1

## S48 LAPM Error Control and Feature Negotiation (default 7)

This is a non-operational command that is included for compatibility with older programs. Use the `W` command to change EC protocol behavior.

## S89 Timer to Control Sleep Mode

This command displays the number of seconds of inactivity (no characters sent from the DTE, no RING) in the offline command state before the modem places itself into standby mode. A value of zero prevents standby mode.



If a number between 1 and 4 is entered for this register, it will set the value to 5, and the inactivity before standby will be 5 seconds. This is done for compatibility with previous products that allowed time-outs down to one second.

---

Range: 0, 5-255

Default: 10

## S91 Line Transmit Level

This register is effective only for Japan. It specifies the line transmit level in dBm with an implied minus sign.

Range: 6-15

Default: 15

Unites: 1dB

## S108 Network Codec Type

S108 = 22 U-Law

S108 = 33 A-law

S108 = 7 Default, or any other value



This coding is as specified by digital modem in V.8bis information. If an old server does not tell its code type in V.8bis, then the client modem chooses based on its country ID. U-law regions are Japan, Taiwan, Korea, Hong Kong, North America, and Latin America. Everywhere else is A-law. This S-register is valid only in K56flex mode.

---

---

## AT FAX Command Set

### Class 1 FAX Commands

The Lucent Technologies HSM Data/FAX Complete Chip Set supports FAX commands conforming to EIA standard 578. These commands are given here with short descriptions; complete explanations are given in the standard, available from the Electronic Industry Association.

#### AT FAX Command Set Summary

Command	Description
+FCLASS?	Service class indication
+FCLASS=?	Service class capabilities
+FCLASS=n	Service class selection
+FTS=<n>	Transmission silence
+FRS=<n>	Receive silence
+FTM=<m>	Transmit FAX data with <m> carrier
+FRM=<m>	Receive FAX data with <m> carrier
+FTH=<m>	Transmit HDLC data with <m> carrier
+FRH=<m>	Receive HDLC data with <m> carrier
+FTM=?	Transmit FAX modulation
+FRM=?	Receive FAX modulation
+FTH=?	Transmit HDLC data modulation
+FRH=?	Receive HDLC data modulation

**AT FAX Command Set Summary (Continued)**

<b>Command</b>	<b>Description</b>
+FMI?	Manufacturer identification
+FMM?	Product identification
+FMR?	Version/revision information
+FPR=<n>	Set DTE-DCE fax port rate
+FPR=	Reports all fax port rate that DCE supports
+FPR?	Reports the current fax port rate of DTE-DCE
+FAA=<n>	Set DCE adaptive answer mode
+FAA=?	Display valid adaptive answer values that DCE supports
+FAA?	Display current set value of adaptive answer mode
+FLO+ <value>	Flow control selection

## AT FAX Command Set Descriptions

### +FCLASS? Service Class Indication

This command causes the modem to display the current setting. The modem can operate either as a Class 0 data modem or a Class 1 FAX modem.

Typical responses:

+FCLASS?            000 if in data mode; 001 if in FAX Class 1.



## **+FCLASS=? Service Class Capabilities**

This command causes the modem to display the classes it supports.

Typical responses:

+FCLASS=?      0, 1

## **+FCLASS=n Service Class Selection**

This command sets the modem for Class n operation, where n is either a 0 or 1.

Parameters:      0, 1

Default:          0

Command options:

+FCLASS=0      Select data mode.

+FCLASS=1      Select facsimile Class 1.

## **+FTS=<n> Transmission Silence**

This command causes the modem to stop transmitting data and pause for  $10*n$  ms. At the end of this period, the modem then responds OK. You can specify any number from 0 through 255 as the value of n; for example, a value of 5 specifies a period of 50 ms.

n = 0-255 (10 ms intervals)

## **+FRS=<n> Receive Silence**

This command causes the modem to listen and wait for a  $10*n$  ms period of silence on the line. At the end of this period, the modem then responds OK. You can specify any number from 0 through 255 as the value of n; for example, a value of 5 specifies a period of 50 ms.

n = 0-255 (10 ms intervals)

## **+FTM=<m> Transmit FAX Data with <m> Carrier**

This command causes the modem to transmit data at the modulation specified by <m>. The following chart shows the values you can enter for this command and the meaning of those values.

<b>Command Option</b>	<b>Modulation</b>	<b>Speed (bits/s)</b>
+FTM=3	V.21 Channel 2	300
+FTM=24	V.27ter	2400
+FTM=48	V.27ter	4800
+FTM=72	V.29	7200
+FTM=96	V.29	9600
+FTM=73	V.17	7200
+FTM=74	V.17 (short train)	7200
+FTM=97	V.17	9600
+FTM=98	V.17 (short train)	9600
+FTM=121	V.17	12000
+FTM=122	V.17 (short train)	12000
+FTM=145	V.17	14400
+FTM=146	V.17 (short train)	14400

## **+FRM=<m> Receive FAX Data with <m> Carrier**

This command causes the modem to receive data at the modulation specified by <m>.

<b>Command Option</b>	<b>Modulation</b>	<b>Speed (bits/s)</b>
+FRM=3	V.21 Channel 2	300
+FRM=24	V.27ter	2400
+FRM=48	V.27ter	4800
+FRM=72	V.29	7200
+FRM=96	V.29	9600
+FRM=73	V.17	7200
+FRM=74	V.17 (short train)	7200
+FRM=97	V.17	9600
+FRM=98	V.17 (short train)	9600
+FRM=121	V.17	12000
+FRM=122	V.17 (short train)	12000
+FRM=145	V.17	14400
+FRM=146	V.17 (short train)	14400

## **+FTH=<m> Transmit HDLC Data with <m> Carrier**

This command causes the modem to transmit data framed in the HDLC protocol at the modulation specified by <m>.

<b>Command Option</b>	<b>Modulation</b>	<b>Speed (bits/s)</b>
+FTH=3	V.21 Channel 2	300
+FTH=24	V.27ter	2400
+FTH=48	V.27ter	4800
+FTH=72	V.29	7200
+FTH=96	V.29	9600
+FTH=73	V.17	7200
+FTH=74	V.17 (short train)	7200
+FTH=97	V.17	9600
+FTH=98	V.17 (short train)	9600
+FTH=121	V.17	12000
+FTH=122	V.17 (short train)	12000
+FTH=145	V.17	14400
+FTH=146	V.17 (short train)	14400

**+FRH=<m> Receive HDLC Data with <m> Carrier**

This command causes the modem to receive data framed in the HDLC protocol at the modulation specified by <m>.

Command Option	Modulation	Speed (bits/s)
+FRH=3	V.21 Channel 2	300
+FRH=24	V.27ter	2400
+FRH=48	V.27ter	4800
+FRH=72	V.29	7200
+FRH=96	V.29	9600
+FRH=73	V.17	7200
+FRH=74	V.17 (short train)	7200
+FRH=97	V.17	9600
+FRH=98	V.17 (short train)	9600
+FRH=121	V.17	12000
+FRH=122	V.17 (short train)	12000
+FRH=145	V.17	14400
+FRH=146	V.17 (short train)	14400

## +FPR=<n> Select Fax Port Rate

This command sets the DTE to DCE fax port rate.

DTE Command	DCE Action	Description or Notes
+FPR=0	Execute +IPR=0	Select automatic rate detection
+FPR=1	Execute +IPR=2400	Set DTE-DCE to 2400 bit/s
+FPR=2	Execute +IPR=4800	Set DTE-DCE to 4800 bit/s
+FPR=4	Execute +IPR=9600	Set DTE-DCE to 9600 bit/s
+FPR=8	Execute +IPR=19200	Set DTE-DCE to 19200 bit/s
+FPR=10	Execute +IPR=38400	Set DTE-DCE to 38400 bit/s
+FPR=18	Execute +IPR=57600	Set DTE-DCE to 57600 bit/s
+FPR=? (if all values listed above are supported)	Report (0,1,2,4,8,10,18)	DCE supports 2400, 4800, 9600, 19200, 38400, and 57600 bit/s
+FPR? (if +IPR=0)	Report 0	DTE-DCE rate is automatically detected
+FPR? (if +IPR=2400)	Report 1	DTE-DCE rate is 2400 bit/s
+FPR? (if +IPR=4800)	Report 2	DTE-DCE rate is 4800 bit/s
+FPR? (if +IPR=9600)	Report 4	DTE-DCE rate is 9600 bit/s
+FPR? (if +IPR=19200)	Report 8	DTE-DCE rate is 19200 bit/s

DTE Command	DCE Action	Description or Notes
+FPR? (if +IPR=38400)	Report 10	DTE-DCE rate is 38400 bit/s
+FPR? (if +IPR=57600)	Report 18	DTE-DCE rate is 57600 bit/s
+FPR? (all other +IPR settings)	Report 255	255 indicates invalid setting

## +FAA Adaptive Answer

A Service Class 1 Facsimile DCE may have the ability to answer as a data modem DCE or as a Facsimile DCE. It also may be able to adaptively change from Class 1 facsimile mode (+FCLASS = 1.0) to data modem operation (+FCLASS = 0) in response to the incoming call. The +FAA parameter controls this feature.

Write syntax: +FAA=<value>

Valid values: 0, 1

Default value: 0

Mandatory value: 0

+FAA=0 The DCE answers only as a Class 1 facsimile device. No automatic switching of service class shall occur based on the calling device type.

+FAA=1 The DCE can answer and automatically determine whether to answer as a facsimile DCE or as a data modem. If a data modem is detected, the DCE operates as described in 8.3.2.4.



The +FAA parameter controls automatic switching only from Class 1 to Class 0 for call answering only. It does not affect call origination, switching to Class 1 from other classes, or switching to classes other than Class 0.

## **+FMI?            Manufacturer Identification**

Read Syntax:    AT+FMI?

This parameter reports the manufacturer identification.

## **+FMM?            Product Identification**

Read Syntax:    AT+FMM?

This parameter reports product identification.

## **+FMR?            Version / Revision Information**

Read Syntax:    AT+FMR?

This parameter reports the version, revision level, or other pertinent information for the device.



---

## V.25ter AT Command Set

These +GMx commands are required by Microsoft PC9x specifications:

- Manufacturer Identification (+GMI?)
- Version/Revision Information (+GMR?)
- Modem Identification (+GMM?)

The PC99 reporting command's values and parameters are displayed using the following:

- Current subparameter value (+command?)
- Where command is the command set (e.g., AT+DR?)
- Supported range of values (+command=?)
- Where command is the command set (e.g., AT+DR=?)

The chip set supports the following functionalities of the V.25ter for a H.324 call:

- The modified function of the ATD command when issued while the analog voice connection is established. This command will not cause the DTMF dialing and tone detection associated with the usual ATD # command.
- The AT commands, subparameters, and values listed in the following chart.

### V.25ter AT Commands

Command	Subparameter	Values	Description
AT+A8E= <v80>, <v8a>, <v8cf>	v80	<p>&lt;1&gt; (default) Disables the CI option while in V.8 origination. However, the modem detects ANSam and is capable of starting in V.34 mode when initiating the call as a data call.</p> <p>&lt;6&gt; Enables DCE control of V.8 and CI option.</p>	<p>Defined for two conditions: as a parameter to configure V.8 originating and answering operation while the DCE is on-hook, and to initiate an action if the DCE is off-hook.</p> <p>V.8 negotiation does not preclude simultaneous implementation of other negotiation means such as V.8bis, V.18, or V.32bis.</p>
	v8a	<p>&lt;1&gt; (default) Disables the CI option while in V. negotiation. However, the modem sends the ANSam and is capable of starting in V.34 mode when answering a call.</p> <p>&lt;5&gt; Enables DCE control of V.8 and CI option.</p>	

**V.25ter AT Commands (Continued)**

Command	Subparameter	Values	Description
AT+A8E= <v80>, <v8a>, <v8cf> (continued)	v8cf	<21h> Call function for H.324 calls. <c1h> Call function for DSVD calls.	
AT+A8E?			Reports current values of sub-parameters.
AT+A8E=?			Reports supported ranges of values <v80>, <v8a>, and <v8cf>.
+A8I:<v8cf> <CR>			Used by an answering DCE if +A8E,<v8a> !=0, to indicate detection of a V.8 CI signal and to report the recovered Call Function octet(s). Value <v8cf> is a hexadecimal code octet that can take values as shown above in +A8E command.
+A8M= <hexadecimal coded CM or JM octet string>	Coded CM or JM octet	Refer to V.8 document for coding.	Directs the DCE to send a V.8 CM or JM signal using the specified hexadecimal coded string.

**V.25ter AT Commands (Continued)**

Command	Subparameter	Values	Description
+A8A:<type> <CR>	<type>	<1> Indicates V.8 ANSam signal flags. <0> Indicates no ANSam signal detected.	Used by a calling DCE if +A8E <v80> #0 to indicate detection of an answering signal.
AT+DR		<1> Compression reporting on. <0> Compression reporting off.	Turns compression reporting on or off.
AT+MR		<1> Modulation reporting on. <0> Modulation reporting off.	Turns modulation reporting on or off.
AT+ER		<1> Error control reporting on. <0> Error control reporting off.	Turns error control reporting on or off.
AT+A8E?			Reports current values of sub-parameters.
AT+A8E=?			Reports supported ranges of values <v80>, <v8a>, and <v8cf>.

**V.25ter AT Commands (Continued)**

Command	Subparameter	Values	Description
+A8l:<v8cf> <CR>			Used by an answering DCE if +A8E,<v8a> !=0, to indicate detection of a V.8 CI signal and to report the recovered Call Function octet(s). Value <v8cf> is a hexadecimal code octet that can take values as shown above in +A8E command.
+A8M= <hexadecimal coded CM or JM octet string>	Coded CM or JM octet	Refer to V.8 document for coding.	Directs the DCE to send a V.8 CM or JM signal using the specified hexadecimal coded string.
+A8A:<type> <CR>	<type>	<1> Indicates V.8 ANSam signal flags. <0> Indicates no ANSam signal detected.	Used by a calling DCE if +A8E <v8o> #0 to indicate detection of an answering signal.
AT+DR		<1> Compression reporting on. <0> Compression reporting off.	Turns compression reporting on or off.

**V.25ter AT Commands (Continued)**

Command	Subparameter	Values	Description
AT+MR		<1> Modulation reporting on. <0> Modulation reporting off.	Turns modulation reporting on or off.
AT+ER		<1> Error control reporting on. <0> Error control reporting off.	Turns error control reporting on or off.
AT+ILRR		<1> DTE rate reporting on. <0> DTE rate reporting off.	Turns DTE rate reporting on or off.
AT+ES= <1,0,1>, <0,1,0>, <4,4,6>, <2,3,5>, <3,3,5>, <4,0,6>, <3,0,2>, <2,0,2>, <3,2,4>	<1,0,1>	Buffered mode.	Determines the error correction mode.
	<0,1,0>	Direct mode.	
	<4,4,6>	MNP or disconnect mode.	
	<2,3,5>	LAPM or disconnect mode.	
	<3,3,5>	LAPM or disconnect mode.	
	<4,0,6>	MNP or buffered mode.	

**V.25ter AT Commands (Continued)**

Command	Subparameter	Values	Description
AT+ES= <1,0,1>, <0,1,0>, <4,4,6>, <2,3,5>, <3,3,5>, <4,0,6>, <3,0,2>, <2,0,2>, <3,2,4> (continued)	<3,0,2>	LAPM, MNP, or buffered modem (default).	
	<2,0,2>	LAPM or buffered mode.	
	<3,2,4>	LAPM, MNP, or disconnect mode.	
AT+IFC= <0,0>, <1,1>, <3,1>, <2,2>	<0,0>	No flow control.	Determines the local flow control method.
	<1,1>	Software flow control, XON/XOFF characters processed by modem.	
	<3,1>	Software flow control, XON/XOFF characters passed to DTE.	
	<2,2>	Hardware flow control.	

**V.25ter AT Commands (Continued)**

Command	Subparameter	Values	Description
AT+DS= <3,0>, <0,0>,<0>	<3,0>	V42bis	Determines the data compression method.
	<0,0>	No compression	
	<0>	No compression	

**Data and General Commands**

AT+ MS= <carrier> <automode> <max_rate> <max_rx_rate>			Use this command to set the modems modulation and its associated parameters. Leave blank any optional parameter whose value is not going to change.
---	--	--	---



**V.25ter AT Commands (Continued)**

Command	Subparameter	Values	Description
AT+MS=	<carrier>		Specifies the preferred modem carrier to use in originating or answering a connection.
		V92	V.92 (default)
		V90	V.90
		K56	K56flex
		V34	V.34
		V32	V.32
		V32B	V.32bis
		V22	V.22
		V.22B	V.22bis
		V23C	V.23, Constant carrier, , asymmetric FDM
		V21	V.21
		Bell212A	Bell 212A
		Bell103	Bell 103

**V.25ter AT Commands (Continued)**

Command	Subparameter	Values	Description
AT+MS=	<automode>		Automatic modulation negotiation is enabled or disabled by <automode>. However, if values are specified for the <max rate> and the <max rx rate> parameters, automatic rate selection will be disabled and the modem will attempt to connect at the specified rates.
		0	Disables
		1	Enabled (default)

**V.25ter AT Commands (Continued)**

Command	Subparameter	Values	Description
AT+MS=	<max_rate>	0  300 - 33600	The <max rate> specifies the highest connections rate for the DCE.  Determined by modulation selected in <carrier> (default). Value limited by modulation selected in <carrier>.

**V.25ter AT Commands (Continued)**

Command	Subparameter	Values	Description
		V90, V34	The Valid <max_rate> for each <carrier>  2400 bits/s—33600 bits/s in steps of 2400 bits/s.
		V32bis	4800 bits/s—19200 bits/s in steps of 2400 bits/s.
		V32	4800 bits/s—14400 bits/s in steps of 2400 bits/s.
		V22bis	2400 bits/s.
		V22	2200 bits/s.
		V23C, Bell212A	1200 bits/s.
		V.21, Bell103	300 bits/s.
AT+MS=	<max_rx_rate>	0	The <max rx rate> specifies the rate limit used in the receive direction.
		75 - 56000	Determined by modulation selected in <carrier> (default). Value limited by modulation selected in <carrier>.

**V.25ter AT Commands (Continued)**

Command	Subparameter	Values	Description
			The Valid <max_rx_rate> for each <carrier>
		V90	28000 bits/s—56000 bits/s in steps of 1333 bits/s.
		K56	32000 bits/s—56000 bits/s in steps of 2000 bits/s.
		V34	2400 bits/s—33600 bits/s in steps of 2400 bits/s.
		V32bis	4800 bits/s—19200 bits/s in steps of 2400 bits/s.
		V32	4800 bits/s—14400 bits/s.
		V22bis	240 bits/s.
		V22	2200 bits/s.
		V23C, Bell212A	1200 bits/s.
		V.21, Bell103	300 bits/s.

**V.25ter AT Commands (Continued)**

Command	Subparameter	Values	Description
<b>Extended Syntax Commands</b>			
AT+MS			<p>Select or deselect transmission of the rate report result code.</p> <p>The current active settings are reported under control of the +MR parameter. Optional subparameters do not need to be reported if not implemented or set to 0.</p>

**V.25ter AT Commands (Continued)**

Command	Subparameter	Values	Description
AT+MS	AT+ MS= <carrier> <automode> <min_rate> <max_rate> <min_rx_rate> <max_rx_rate>		Once a modulation is selected by the +MS command, the auto rate in both directions and the auto mode will be activated unless either parameter, <max rate> or <max rx rate> is specified by the same command. The settings of this command overwrite the settings of S28, S37, S38, S109. Likewise, changes to these registers overwrite the settings of the +MS command.
AT+MS ?			Display the current status of the rate report result code.
AT+MS =?			Display the supported parameter values for DTE-DCE local rate reporting.

---

## V.80 AT Command Set

The chip set supports the Synchronous Access Mode and most of the commands specified in V.80 standards. The commands are either AT commands issued in the command mode, or in-band commands transmitted in the data stream. These in-band commands are delimited by the EM character (hexadecimal 19, or numerically, 19H). Refer to ITU - V.80 Recommendations for details of in-band signaling.

---

### V.80 AT Commands

Command	Subparameters	Values	Description
+ES=[<orig_rqst>[, <ans_fbk>]]	Orig_rqstans_fbk	<6> Initiate Synchronous Access Mode when the data state is entered. <8> Initiate Synchronous Access Mode when connection is completed and Data State is entered.	Controls operation of the V.42 protocol in the DCE.



**V.80 AT Commands (Continued)**

Command	Subparameters	Values	Description
+ES?			<p>Reads syntax command to query current values of the +ES sub-parameters. The DCE transmits this string of information text to the DTE: +ES:&lt;orig_rqst&gt;,, &lt;ans_fbk&gt;.</p>
+ES=?			<p>Tests syntax command to obtain all defined values of the +ES sub-parameters. The DCE transmits this string of information text to the DTE: +ES:( list of supported &lt;orig_rqst&gt; values),, (list of supported &lt;ans_fbk&gt; values).</p>

---

## New V.250 Commands to Support V.92 AT Command Set

No extra space is allowed in the commands. Otherwise, the modem will return an error response. All the settings of these commands can overwrite, or be overwritten by, the results of the related commands in the current modem command set.

The commands support both read and test syntax. The format of the read syntax is “+XXX?” This type of command will return the current settings in use for the command. The format of the test syntax is “+XXX=?” This type of command will return a list of the support values for the command.

### +MS Modulation Selection

Added support for a valid carrier value of V.92

Valid Parameter Syntax:

```
+MS=<carrier>,<automode>,<0>,<max_rate>,<0>,<max_rx_rate>  
+MS?  
+MS=?
```

To support V.92, a new valid carrier value has been defined. A list of the valid <carrier> values which are currently supported are shown below in Table 1. The current version of code does not support V.92 upstream. Therefore, no other modifications have been made to the +MS command. Note that the maximum rate upstream, <max\_rate>, is limited to 31200 for V.90 and V.92. Please see the Venus AT Command Document for a complete description of the +MS command.

### Valid Carrier Values

Value	Description
V92	V.92 (default)
V90	V.90
K56	K56flex
V34	V.34
V32	V.32
V32B	V.32bis
V22	V.22
V.22B	V.22bis
V23C	V.23, constant carrier, asymmetric FDM
V21	V21
Bell212A	Bell 212A
Bell103	Bell 103

### +DCS Selection of Data Compression Algorithm

Added support for V.44

Valid Parameter Syntax:

+DCS=[<v42bis>,<v44>]

+DCS=?

+DCS?

This command will select the data compression algorithm.

The parameter <v42bis> specifies whether the V.42 *bis* algorithm should be enabled. The parameter <v44> specifies whether the V.44 algorithm should be enabled.

---

**Table A-1: Valid <v42bis> Values**

Value	Description
0	V.42bis must not be used
1	V.42bis acceptable (default)

---

---

**Table A-2: Valid <v44> Values**

Value	Description
0	V.44 must not be used
1	V.44 acceptable
2	V.44 only if V92 server (default)

---

## **+DR Data Compression Reporting**

Added support for V.44

Valid Parameter Syntax:

+DR=<value>

+DR?

+DR=?

This command will turn on/off the compression report.

---

**Table A-3: DR=x Data Compression Report Value**

Value	Description
0	Disables the compression report (default).
1	Enables the compression report.

---

If the compression report is enabled, the +DR:<type>,intermediate result code, reports the current DCE-DCE data compression type. It is issued after the Error Control Report (+ER) and before the final result code (e.g., CONNECT). The format is shown in Table 5.

---

**Table A-4: DR=x Data Compression Reporting Intermediate Result Codes**

Value	Description
+DR: NONE	Data compression not in use.
+DR: V42B	V.42bis is in use in both directions.
+DR: V44	V.44 is in use in both directions.

---

## +PCW Call Waiting Enable

Added for V.92 support

Valid Parameter Syntax:

+PCW=<call waiting>

+PCW?

+PCW=?

This command will control the action to be taken upon detection of call waiting in a V.92. The values specified by this command are not modified when an AT&F command is issued.

---

**Table A-5: Valid <call waiting> Values**

Value	Description
0	Toggle V.24 Circuit 125 and collect Caller ID if enabled by +VCID.
1	Hang up.
2	Ignore V.92 call waiting (default).

---

## +PMH Modem on Hold Enable

Added for V.92 support

Valid Parameter Syntax:

+PMH=<value>

+PMH?

+PMH=?

This command will control if modem on hold procedures are enabled during V.92 operation. The values specified by this command are not modified when an AT&F command is issued.

---

**Table A-6: Valid +PMH=<value> Values**

Value	Description
0	Enables V.92 modem on hold.
1	Disables V.92 modem on hold (default).

---

## +PMHT Modem on Hold Timer

Added for V.92 support

Valid Parameter Syntax:

+PMHT=<value>

+PMHT?

+PMHT=?

This command will determines if the modem will accept a Modem on Hold (MOH) request and will set the MOH Timeout.

---

**Table A-7: +PMHT=<value> Values**

Value	Description
0	Deny MOH Request (default)
1	Grant MOH Request with 10 sec timeout
2	Grant MOH Request with 20 sec timeout
3	Grant MOH Request with 30 sec timeout
4	Grant MOH Request with 40 sec timeout
5	Grant MOH Request with 1 min timeout
6	Grant MOH Request with 2 min timeout
7	Grant MOH Request with 3 min timeout
8	Grant MOH Request with 4 min timeout
9	Grant MOH Request with 6 min timeout
10	Grant MOH Request with 8 min timeout
11	Grant MOH Request with 12 min timeout
12	Grant MOH Request with 16 min timeout
13	Grant MOH Request with indefinite timeout

---

## +PMHR Initiate Modem on Hold (MOH)

Added for V.92 support

Valid Parameter Syntax:

+PMHR=<value>

+PMHR?

+PMHR=?

This command will determine if the modem will accept a Modem on Hold (MOH) request and will set the MOH Timeout. This command is only valid if MOH is enabled and the modem is off-hook or in data mode. Otherwise, ERROR will be returned.

---

**Table A-8: +PMHR=<value> Values**

Value	Description
0	Deny MOH Request (default).
1	Grant MOH Request with 10 sec timeout.
2	Grant MOH Request with 20 sec timeout.
3	Grant MOH Request with 30 sec timeout.
4	Grant MOH Request with 40 sec timeout.
5	Grant MOH Request with 1 min timeout.
6	Grant MOH Request with 2 min timeout.
7	Grant MOH Request with 3 min timeout.
8	Grant MOH Request with 4 min timeout.
9	Grant MOH Request with 6 min timeout.
10	Grant MOH Request with 8 min timeout.
11	Grant MOH Request with 12 min timeout.
12	Grant MOH Request with 16 min timeout.
13	Grant MOH Request with indefinite timeout.

---



## **+PIG PCM Upstream Ignore**

Added for V.92 support

Valid Parameter Syntax:

+PIG=[<value>]

+PIG?

+PIG=?

This command will control the use of PCM upstream in a V.92. PCM upstream is supported for Mercury based modems with 12 ns (or faster) RAM.

---

**Table A-9: Valid +PIG=[<value>] Values**

<b>Value</b>	<b>Description</b>
0	Enable PCM upstream.
1	Disable PCM upstream (default).

---

## +PQC V.92 Phase 1 and Phase 2 Control

Added for V.92 support

Valid Parameter Syntax:

+PQC=<value>

+PQC?

+PQC=?

This command will control the enabling or disabling of the V.92 shortened Phase 1 and Phase 2 startup. This command is used in conjunction with the +PSS command. Changes to the value of either S109 or +PQC will affect the values of the other AT command.

---

**Table A-10: Valid +PQC=<value> Values**

Value	Description
0	Enable Short Phase 1 and Short Phase 2.
1	Enable Short Phase 1.
2	Enable Short Phase 2.
3	Disable Short Phase 1 and Short Phase 2 (default).

---

## +PMHF V.92 Modem Hook Flash

Added for V.92 support

Valid Parameter Syntax:

+PMHF

This command causes the DCE to go on-hook for a specified period of time, and then return off-hook for at least a specified period of time. The specified period of time is normally one-half second, but may be governed by national regulations. "ERROR" is returned if MOH is not enabled.

## +DS44 V.44 Data Compression

Added for V.44 support

Valid Parameter Syntax:

+DS44=<direction>,<0>,<0>,<max\_codewords\_tx>,<max\_codewords\_rx>,<max\_string\_tx>,<max\_string\_rx>,<max\_history\_tx>,<max\_hostory\_rx>

+DS44?

+DS44=?

This command will control the V.44 data compression function.

The <direction> parameter specifies the DTE direction of the data compression.

---

**Table A-11: Valid <direction> Values**

---

Value	Meaning
0	No compression.
3	Both directions (default).

---

The `<max_codewords_tx>` specifies the maximum number of code words to be negotiated in the transmit direction. The `<max_codewords_rx>` specifies the maximum number of code words to be negotiated in the receive direction. The valid range for the receive and transmit values is shown in Table 12.

---

**Table A–12: Valid Range of `<max_code_words_tx>` and `<max_code_words_rx>` Values**

---

Value	Meaning
1024	Default.
256-2048	Number of codewords in tx/rx direction.

---

The `<max_string_tx>` specifies the maximum string length to be negotiated in the transmit direction. The `<max_string_rx>` specifies the maximum string length to be negotiated in the receive direction. The valid range for both the receive and transmit values is shown in Table 13.

---

**Table A–13: Valid Range of `<max_string_tx>` and `<max_string_rx>` Values**

---

Value	Meaning
255	Default.
31-255	String length in tx/rx direction.

---

The `<max_history_tx>` specifies the maximum length of the history buffer to be negotiated in the transmit direction. The `<max_history_rx>` specifies the maximum length of the history buffer to be negotiated in the receive direction.

---

**Table A-14: Valid Range of `<max_string_tx>` and `<max_string_rx>` Values**

---

<b>Value</b>	<b>Meaning</b>
5120	Transmit direction default.
4096	Receive direction default.
512-11008	History buffer size in tx/rx direction.

---