

Preparing the DaqPRO Shipping Case

The DaqPRO logger is used to perform the ink sealing test on the FB10000 Industrial Press. This document describes the preparations that must be made before the logger is delivered in its shipping case to HP Scitex.

1. Open the case of the DaqPRO logger.



2. Remove the power adapters provided with the logger and dispose of them.




3. Attach the NiMH battery safety sticker (P/N CX196-01060) to the outside of the case.



4. Insert the logger case into the shipping case.




5. Insert the cables (P/N CX161-07670, CX161-07740, CX161-07770) inside the power supply unit.



6. Insert the power supply unit inside the shipping case.



7. Wrap the pressure sensor (P/N CX189-04400) in a plastic bag, and place it inside the shipping case.



8. Attach the sealing tester label (P/N CX196-01090) to the top of the shipping case.

