



hp digital
home networking



Ethernet gateway
hn200e
quick start guide

The Hewlett-Packard® Company makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

The information in this document is subject to change without notice.

HP shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

This document contains proprietary information that is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of HP.

Hewlett-Packard Company
Home Networking Solutions Organization
3000 Hanover St
Palo Alto, Ca 94304

© Hewlett-Packard Company, 2001. All rights reserved.

Hewlett-Packard is a registered trademark of Hewlett-Packard Company in the United States of America and other countries.


Microsoft, MS, MS-DOS, and Windows are registered trademarks of Microsoft Corporation.

Other brand or product names are trademarks of their respective holders.

Ethernet gateway

hn200e

Thank you for choosing the Hewlett-Packard Digital Home Networking Ethernet Gateway. This *quick start guide* provides easy set-up instructions. For additional information, see the *user's guide* included on the CD-ROM.



box contents

- One Ethernet Gateway
- One installation and documentation CD-ROM
- One AC Power Adapter
- One Ethernet cable (blue)
- One *quick start guide*
- One warranty sheet

before you begin

- 1 Verify that all of the box contents are included.
- 2 Confirm that:
 - The computers you intend to connect to the Gateway are running either Windows 98, 98SE, Me, 2000, or XP (Windows 2000 and XP Professional require administrative privileges to install this software— see your user documentation for details).
 - Each computer has a CD-ROM drive.
 - Each computer has an Ethernet network adapter (internal or external) installed.
 - A broadband (DSL or cable) modem has been installed and is connected to one of the computers via an Ethernet cable.

- 3 To avoid conflicts, uninstall or disable any connection-sharing software, such as 3COM HomeClick, Microsoft Internet Connection Sharing (ICS), Intel Anypoint ISS, or proxy software such as WinGate, Sygate, or other similar applications. You no longer need this type of application when you install the Ethernet Gateway.


To uninstall a program:

- a) Select **Start > Settings > Control Panel**.
- b) Double-click **Add/Remove Programs**.
- c) Select the connection-sharing or proxy software application to be removed.
- d) Click **Add/Remove**, then click **Yes**.


2

installing the Ethernet gateway and connecting the first computer

- 1 Remove the CD-ROM from the box.
- 2 If the computer is off, turn it on.
- 3 Insert the CD-ROM into the CD-ROM drive of the computer that is connected to your broadband (DSL or cable) modem.




- 4 The HP welcome screen appears:



Note: This screen appears only if Autorun is enabled. If you don't see this screen, double-click **My Computer**. Right-click **Compact Disc**. Then click **AutoPlay** to launch the installed program.


- 5 Select **installation**. The installation wizard screen appears.



- 6 Follow the onscreen instructions to set up and configure the Ethernet Gateway, and to connect the cables. Select **First PC** when you are prompted to set up either a first PC or an additional PC.
- 7 You will be asked to make cable connections with all equipment powered on. This is necessary to interactively detect that each connection has been properly made. There is no danger to you or to your equipment.

4

8 Use this diagram to help you connect the cables:



registering the Ethernet gateway

Make sure you register your product with HP after the installation process is complete. The registration option has been pre-selected for you. HP registration provides you with automatic notification of updates to the firmware installed on the Gateway and to the software installed on the PC.

If you choose to register your product at a later date, enter the following into the address window of your Web browser (such as Internet Explorer or Netscape):

<http://register.hp.com>

Then press Enter.


installing additional network computers

- 1** Turn on the computer to be connected and insert the CD-ROM in the CD-ROM drive.
- 2** When the welcome screen appears, click **installation**.
- 3** Follow the onscreen instructions. Select **Add additional computer** when you are prompted to install either a first PC or an additional PC.
- 4** When the installation is completed, click **Finish**.
- 5** Repeat Steps 1 to 4 for each additional computer on your home network.

Note: *Keep the CD-ROM in a safe place for future use.*

accessing additional documentation

- 1 Insert the CD-ROM into the CD-ROM drive of the computer.
- 2 Click **documentation** on the HP welcome screen.



- 3 Click **user's guide** or any other option you want to review.

Note: *Keep the CD-ROM in a safe place for future use.*

product and support information

- HP Customer Care: (208) 323-2551;
<http://www.hp.com/cposupport>
- Online product information and technical support: **<http://www.hp.com/go/homenetworking>**
(includes a home networking tutorial, FAQs, and other information)