



# LaserJet Pro Color MFP M570

## Use the Control Panel



- 1 HP Web Services button. Provides quick access to HP Web Services features, including HP ePrint.
- 2 Setup button. Provides access to the main menus.
- 3 Wireless button (wireless models only). Provides access to the **Wireless** menu and wireless status information.
- 4 Network button (for products connected to a network only). Provides access to network settings and information. From the network settings screen, you can print the **Network Summary** page.
- 5 Information button. Provides product status information. From the status summary screen, you can print the **Configuration Report** page.
- 6 Supplies button. Provides information about supplies status. From the supplies summary screen, you can print the **Supplies Status** page.



### USB

Touch the **USB** button for the following:

Supported file types: .PDF, .JPG

- Printing documents from a USB drive
- Viewing and printing photos from a USB drive
- Scanning to a USB drive



### Fax (if available and configured)

Send a document to one or more fax numbers.

1. Place the original document face-up in the document feeder, or face-down on the upper left corner of the glass.
2. Touch **Fax**.
3. Type a fax number on the key pad.
4. Touch the **Start Fax** button.

Touch the **Fax Menu** button to customize fax settings.



## Copy

Make copies from an original document.

1. Place the original face-up in the document feeder, or face-down on the upper-left corner of the glass.
2. Touch the **Start Copy** button.

Touch the **Settings** button to customize copy settings.



## Apps

Use the **Apps** menu to access applications downloaded from the HP ePrintCenter Web site. Web services must be enabled on the product before downloading applications from the HP ePrintCenter Web site.

### More Help

- HP ePrint Center: [www.hp.com/go/eprintcenter](http://www.hp.com/go/eprintcenter)
- Product support: [www.hp.com/go/lj500colormfpm570pro\\_cdrom](http://www.hp.com/go/lj500colormfpm570pro_cdrom)



## Scan

1. Place the original document face-up in the document feeder, or face-down on the upper left corner of the glass.
2. Select a location to scan to:
  - USB drive
  - Network Folder (Requires additional configuration)
  - E-mail (Requires additional configuration)
3. Touch the **Scan** button.

