Interactive Part Locator

HP Elite c1030 Chromebook

Welcome to the interactive part locator for the HP Elite c1030 Chromebook

Here's how to use it...

External Views (Click the link to navigate to the views) On this page you will find large icons of each of the external views of this product. To view a specific view in greater detail, simply click that view.


<u>Parts List</u> (Click the link to navigate to the parts)

On this page, you will find a list of all of the replaceable parts for this product. To view a specific part and its location in the product, click the part name in the list.

That's it! On every page there is a link that brings you back to either the External Views or the Parts List, enabling you to navigate to whatever view or part you wish to review.

External Views

Back to Welcome page




Front View




Back to External Views

Left View




Right View



Back to External Views


Display View

Back to External Views




Rear View

Back to External Views




Top View



Back to External Views


Internal View



Go to Parts List

Speakers


Bottom View



Base Enclosure

Base Enclosure

Battery M.2 Solid State Drive Wireless WAN Module **IR Sensor Board** Heat Sink and Fan Assembly Speakers Touchpad **Fingerprint Reader** System Board (Top) System Board (Bottom) USB Door **Volume Button Power Button** Camera Privacy Switch Top Cover with Keyboard **Display Panel Assembly**



Battery


Base Enclosure

Battery

M.2 Solid State Drive Wireless WAN Module IR Sensor Board Heat Sink and Fan Assembly Speakers Touchpad Fingerprint Reader System Board (Top) System Board (Dop) System Board (Bottom) USB Door Volume Button Power Button Camera Privacy Switch Top Cover with Keyboard Display Panel Assembly








M.2 Solid State Drive

Base Enclosure Battery M.2 Solid State Drive

Wireless WAN Module IR Sensor Board Heat Sink and Fan Assembly Speakers Touchpad Fingerprint Reader System Board (Top) System Board (Bottom) USB Door Volume Button Power Button Camera Privacy Switch Top Cover with Keyboard Display Panel Assembly






Wireless WAN Module

Base Enclosure Battery M.2 Solid State Drive Wireless WAN Module

IR Sensor Board Heat Sink and Fan Assembly Speakers Touchpad Fingerprint Reader System Board (Top) System Board (Bottom) USB Door Volume Button Power Button Power Button Camera Privacy Switch Top Cover with Keyboard Display Panel Assembly








IR Sensor Board

Base Enclosure Battery M.2 Solid State Drive Wireless WAN Module **IR Sensor Board** Heat Sink and Fan Assembly Speakers Touchpad **Fingerprint Reader** System Board (Top) System Board (Bottom) USB Door **Volume Button Power Button** Camera Privacy Switch Top Cover with Keyboard **Display Panel Assembly**




Heat Sink and Fan Assembly

Base Enclosure Battery M.2 Solid State Drive Wireless WAN Module **IR Sensor Board** Heat Sink and Fan Assembly Speakers Touchpad **Fingerprint Reader** System Board (Top) System Board (Bottom) USB Door **Volume Button Power Button** Camera Privacy Switch Top Cover with Keyboard **Display Panel Assembly**









Speakers

Base Enclosure Battery M.2 Solid State Drive Wireless WAN Module IR Sensor Board Heat Sink and Fan Assembly

Speakers

Touchpad Fingerprint Reader System Board (Top) System Board (Bottom) USB Door Volume Button Power Button Camera Privacy Switch Top Cover with Keyboard Display Panel Assembly






Touchpad


Base Enclosure Battery M.2 Solid State Drive Wireless WAN Module IR Sensor Board Heat Sink and Fan Assembly Speakers

Touchpad

Fingerprint Reader System Board (Top) System Board (Bottom) USB Door Volume Button Power Button Camera Privacy Switch Top Cover with Keyboard Display Panel Assembly








Fingerprint Reader

Base Enclosure Battery M.2 Solid State Drive Wireless WAN Module **IR Sensor Board** Heat Sink and Fan Assembly Speakers Touchpad

Fingerprint Reader

System Board (Top) System Board (Bottom) USB Door **Volume Button Power Button** Camera Privacy Switch Top Cover with Keyboard **Display Panel Assembly**



System Board (Top)

Base Enclosure Battery M.2 Solid State Drive Wireless WAN Module IR Sensor Board Heat Sink and Fan Assembly Speakers Touchpad Fingerprint Reader

System Board (Top)

System Board (Bottom) USB Door Volume Button Power Button Camera Privacy Switch Top Cover with Keyboard Display Panel Assembly







System Board (Bottom)

Base Enclosure Battery M.2 Solid State Drive Wireless WAN Module **IR Sensor Board** Heat Sink and Fan Assembly Speakers Touchpad **Fingerprint Reader** System Board (Top)

System Board (Bottom)

USB Door **Volume Button Power Button** Camera Privacy Switch Top Cover with Keyboard **Display Panel Assembly**







USB Door

Base Enclosure Battery M.2 Solid State Drive Wireless WAN Module **IR Sensor Board** Heat Sink and Fan Assembly Speakers Touchpad **Fingerprint Reader** System Board (Top) System Board (Bottom) USB Door

Volume Button Power Button Camera Privacy Switch Top Cover with Keyboard **Display Panel Assembly**






Volume Button

Base Enclosure Battery M.2 Solid State Drive Wireless WAN Module **IR Sensor Board** Heat Sink and Fan Assembly Speakers Touchpad **Fingerprint Reader** System Board (Top) System Board (Bottom) USB Door Volume Button

Power Button Camera Privacy Switch Top Cover with Keyboard **Display Panel Assembly**








Power Button

Base Enclosure Battery M.2 Solid State Drive Wireless WAN Module IR Sensor Board Heat Sink and Fan Assembly Speakers Touchpad Fingerprint Reader System Board (Top) System Board (Bottom) USB Door Volume Button **Power Button**


Top Cover with Keyboard Display Panel Assembly



Camera Privacy Switch

Base Enclosure Battery M.2 Solid State Drive Wireless WAN Module IR Sensor Board Heat Sink and Fan Assembly Speakers Touchpad Fingerprint Reader System Board (Top) System Board (Dop) System Board (Bottom) USB Door Volume Button Power Button

Top Cover with Keyboard Display Panel Assembly



Top Cover with Keyboard

Base Enclosure Battery M.2 Solid State Drive Wireless WAN Module **IR Sensor Board** Heat Sink and Fan Assembly Speakers Touchpad **Fingerprint Reader** System Board (Top) System Board (Bottom) USB Door **Volume Button Power Button** Camera Privacy Switch Top Cover with Keyboard **Display Panel Assembly**





Display Panel Assembly

Base Enclosure Battery M.2 Solid State Drive Wireless WAN Module **IR Sensor Board** Heat Sink and Fan Assembly Speakers Touchpad **Fingerprint Reader** System Board (Top) System Board (Bottom) USB Door **Volume Button Power Button** Camera Privacy Switch Top Cover with Keyboard Display Panel Assembly



